

# **OPERATION OF** *FrigoPack* E FMV WITH RS485 MODBUS RTU

Reliable operation is only possible if the following parts are mounted and the recommended following settings made:

Required serial interface module and cable for operation with RS485:

- MotorMaster O-FM-RS232/485
- Accessory PCC-4-1mBlck (1 m for connection to the RS232-Port, other cable lengths are available)

## Connections:

RS485 screw Terminals:

A (Data + / P):	Data
<b>B</b> (Data - / N):	Data
Scn:	Screen

#### Parametersettings to enable RS485 operation with Modbus RTU

Small	Alternative keypads	Large
SEL   SEFL	←Navigation→ Explanation: Setting Action	SETUP   SERIAL COMMS
5ED I	Standard setting for refrigeration: <b>0</b> (verify *)	REMOTE COMMS SEL
5602	Standard setting for refrigeration: <b>0.0 s</b> (verify *)	COMMS TIMEOUT
5E03	Address in fieldbus network: 2 (modify if necessary *)	COMMS ADDRESS
5E04	Communication speed: <b>4</b> / <b>9600</b> (verify *)	COMMS BAUD RATE
5E05	Communication parity: <b>0</b> / <b>NONE</b> (verify *)	COMMS PARITY
5E06	Reply delay:0 / 0 ms(increase if necessary *)	REPLY DELAY
5ED7	Alternative selection: <u><b>3</b></u> / MODBUS (Betrieb mit RS485 Modbus RTU *) <u><b>0</b> / AUTOMATIC (Standard (normaler Betrieb *)</u>	PROTOCOL, (OP)
5E08	Standard setting for refrigeration:0 / AUTOMATIC(verify *)	PROTOCOL, (P3)

\* Refer to next page for information on password protection.



## Password

Modifyingthere settings is only possible after entering a special password. When the following is displayed:

PH55 PASSWORD

then enter the password as shown below:

0000	0000
$\uparrow$ $\uparrow$ $\uparrow$ $\uparrow$	44444
8670	8670

followed by pressing key 'E'

### Restoring passwrod protection

It is urgently recommended that the password is reset after making this modification. There are two alternative methods of doing this, see the following:

- Disconnect the power supply to *FrigoPack*, wait until the display is dark and then reconnect the power again
- Navigate to the top of the parameter tree by pressing the key 'E' many times, then navigate to the following menu

**RPP** 

APPLICATION.

by pressing key 'M'.