

Product Manual

MotorMaster Frequency Inverter

MM407...422-EMC

MM515...540-EMC

MM655...6110

Software Version: 5.X



This Product Manual includes the following important information in connection with the CE marking:

- Validity
- Planning the installation, mounting and wiring, commissioning, servicing



NOTE: The setting-up and commissioning of MM45 and MM6 Frequency Inverters is almost identical to that with the MM3SV range. Reference is therefore made to both MM6 and MM3SV.

Software version

This Product Manual is compatible with MM456 Frequency Inverters with version 5.X software. Contact your supplier should MM456 Frequency Inverter indicates a different software version on power-up.

Installation details

Serial number:

(see product label or name plate)

Where installed:

(for your own information)

MM456 Frequency Inverter as in
EMC DIRECTIVE used as:

Component

Relevant Apparatus

Mounting:

Wall-mounted

Enclosure

For your personal notes

© Copyright KIMO 1999

All rights strictly reserved. No part of this document may be stored in a retrieval system, or transmitted in any form or by any means without written permission from the copyright holder. None observance of this copyright will result in liability for damages.

Although every effort has been taken to ensure the accuracy of this document it may be necessary, without notice, to make amendments or correct omissions, the manufacturer cannot accept responsibility for damage, injury, or expenses resulting therefrom.

Available product documentation

MM456 Frequency Inverters use a revolutionary software concept which provides for:

- Easy use and programming for normal applications
- High level of flexibility and sophistication for complex volume applications

To cater for the needs of these two user groups the product documentation is structured as follows:

Documentation	Contents	Chapters	Status
Product Manual TMM456E-9906	<ul style="list-style-type: none"> • Technical data, installation, CE, EMC, LVD and UL issues, options • Setting-up and commissioning for all normal applications 	0...11	Supplied with every MM456 Frequency Inverter
Parameter List TMM456/3SV-PMLE-9906 (supplied separately as part of product manual)	<ul style="list-style-type: none"> • Complete parameter list 		
Software and Application Manual TMM456/3SV-SAM 9908	<ul style="list-style-type: none"> • Setting-up and commissioning for all normal applications • Detailed description of all function blocks • Application information for various applications (available soon) 	21...27* 28.1...28.8	Must be ordered separately
Application Software ASM-K02	<ul style="list-style-type: none"> • Variable-speed control of fans in ventilation applications (HVAC) 		

* Chapters 24...26 are identical to chapters 4...6 in the Product Manual

WARNINGS, RISKS AND IMPORTANT INFORMATION

SOFTWARE VERSION 0-2
 WARNINGS, RISKS 0-9



Read before proceeding

SPECIAL INSTRUCTIONS 0-10
 SCOPE OF THIS PRODUCT MANUAL 0-11
 TECHNICAL CHANGES 0-11
 WARRANTY 0-11

Chapter 1 - PRODUCT OVERVIEW

GENERAL DESCRIPTION 1-2
 TECHNICAL DATA
 General 1-5
 Environmental requirements 1-6
 Safety 1-7
 EC-Directives 1-7
 Power circuit 1-8
 Voltage supply 1-10
 Control circuit 1-10
 Special Considerations for installation in compliance with UL 1-11
 ORDERING INFORMATION 1-12

Chapter 2 - PRE-INSTALLATION PLANNING

FUNCTIONAL OVERVIEW 2-2
 WIRING AND BLOCK DIAGRAMS
 Fig. 2.1: General wiring diagram of power sections MM4, MM5, MM6... 2-4
 Fig. 2.2a: General wiring diagram of control circuit MM45..... 2-5
 Fig. 2.2b: General wiring diagram of control circuit MM6..... 2-5
 Fig. 2.3: Block diagram of supplied configuration..... 2-5
 Fig. 2.4: Application functional block diagram with..... 2-6
 software links as in MACRO1(default supply condition)
 TERMINAL DESCRIPTIONS
 Power terminals of MM45 2-8
 Power terminals of MM6..... 2-9
 Control terminals of MM45 2-9
 Control terminals of MM6..... 2-11
 Configurable digital inputs and outputs 2-13

Chapter 3 - MOUNTING AND INSTALLATION

PRECAUTIONS 3-2
 EQUIPMENT INSPECTION 3-2
 MOUNTING 3-2
 OUTLINE AND MOUNTINGDRAWINGS 3-3
 INSTALLATION..... 3-5
 Using screwless cage-clamp terminals..... 3-5

CONTENTS	Page
Gland for screened motor cable.....	3-6
Power wiring	3-7
Overload and short-circuit protection.....	3-7
Earthing	3-8
Control wiring	3-8
EMC INSTALLATION INSTRUCTIONS	3-9
Introduction	3-9
EMC filters to reduce line-conducted noise.....	3-9
Interaction and safety considerations with earth-fault monitoring systems.	3-12
Minimising radiated emission.....	3-12
Screening and earthing when mounted in an enclosure	3-13
Screening and earthing when mounted	3-15
Motor cable-length limitations.....	3-17
Other layout considerations	3-17
Chapter 4 - SETTING-UP AND COMMISSIONING	
PROGRAMMING PAD	4-2
Introduction	4-2
LCD plain-language display	4-3
Function keys for programming the drive.....	4-4
Function keys for LOCAL control mode.....	4-4
Indicating LEDs.....	4-6
Menu Structure	4-6
IMPORTANT OPERATIONS WITH THE PROGRAMMING PAD	4-7
Changing the language of the Programming Pad.....	4-7
User reset to factory default values.....	4-7
Displaying and changing parameters	4-8
Saving parameters in the MM456/MM3SV Frequency Inverter	4-8
Storing parameters in the programming pad.....	4-8
Loading parameters from the programming pad.....	4-8
Loading preset configuration	4-8
SETTING-UP	
First-time check of electrical system	4-9
Safety considerations	4-9
Setting up the drive before energizing	4-9
Energizing the drive.....	4-11
Chapter 5 - PROGRAMMING THE APPLICATION	
MAIN MENU - OPERATOR	
Set-value.....	5-2
Operating point.....	5-3
Password.....	5-3
MAIN MENU - DI AGNOSTI CS - Information in more detail.....	refer to chapter 6
MAIN MENU - SETUP PARAMETERS	
QUI CK SETUP.....	5-4
Base frequency	5-4
Maximum and minimum speeds	5-4
Ramps	5-4
V/f shape.....	5-5

CONTENTS	Page
Operation with quadratic torque at higher power (HVAC).....	5-5
Motor data	5-5
Voltage boost.....	5-6
Run stop mode.....	5-7
Jog	5-7
Analog inputs MM45.....	5-8
Disabled trips.....	5-8
VECTOR SETUP	5-9
FUNCTION BLOCKS	5-10
MAIN MENU - PASSWORD.....	5-11
MAIN MENU - TRIPS STATUS	5-12
MAIN MENU - MENUS.....	5-12
MAIN MENU - SAVE PARAMETERS and SYSTEM	5-13
Saving parameter	5-14
Restoring default value and loading application MACROS	5-15
Loading parameters from memory or programming pad	5-16
Links	5-16
Configuration mode	5-16
Other functions and parameters	5-16
Chapter 6 - TRIPS, DIAGNOSTICS AND FAULT FINDING	
INTRODUCTION	6-2
TRIPS	
When using the Blank Cover (standard inverter).....	6-3
When the Programming Pad (OPTION) is fitted.....	6-3
Resetting a trip conditions	6-3
Automatic trip reset (AUTO RESTART)	6-4
Setting trip conditions.....	6-4
MAIN MENU - DIAGNOSTICS	
Set-value	6-5
Operating data	6-6
Trips	6-7
Inputs/Outputs	6-9
MAIN MENU - TRIPS STATUS	6-11
TRIPS AND WARNINGS	
Trip messages and fault finding	6-13
"KEY INACTIVE" messages.....	6-15
"CHECKSUM FAIL"	6-15
OTHER FAULT FINDING	6-16
Chapter 7 - SERVICING	
MAINTENANCE	7-2
REPAIR	7-2
SAVING APPLICATION DATA BEFORE RETURNING EQUIPMENT.....	7-2
RETURNED EQUIPMENT	7-2
Chapter 8 - EEC DIRECTIVES, THE CE MAR, UL, CSA	
BASICS OF 'CE' MARKING	8-2
EMC DIRECTIVE	
Responsibility for EMC and 'CE' marking.....	8-3

CONTENTS	Page
Consideration of EMC environment.....	8-5
'CE' marking with built in EMC filters	8-7
'CE' marking with external EMC filters.....	8-7
Specification of achievable EMC emission and immunity	8-8
EMC responsibility of installers and users of	8-9
MM456 Frequency Inverters in installations	
EMC responsibility of manufacturers of apparatus	8-9
and machines sold as complete functional units	
EC Declaration of Conformity for EMC	8-10
Manufacturer's EMC Declaration	8-11
LOW VOLTAGE DIRECTIVE.....	8-12
MACHINERY DIRECTIVE	
Manufacturer's Declaration.....	8-13
UL FOR USA AND CANADA	8-14
Chapter 9 - OPTIONS	
POWER RELATED OPTIONS	
Summary of available options	9-2
Glands for screened motor cables.....	9-2
External EMC filters type FB	9-3
Line- and motor chokes	9-4
NEMA 1 top cover	9-6
External braking resistors	9-7
OTHER OPTIONS	
Programming pad	9-9
Operating panel	9-10
Relais module	9-10
RS232 serial-interface connecting cable.....	9-10
RS485/422 serial-interface	9-11
PROFIBUS-DP option module	9-11
CAN option module.....	9-12
KIMOVIS PC software	9-13
Encoder option module for MM6.....	9-16
Chapter 10 - APPLICATION NOTES	
APPLICATION NOTES.....	
General	10-2
EMC considerations	10-2
Minimum connection requirements	10-2
Brake motors	10-5
Synchronous motors with reluctance or permanent magnet rotors	10-5
Slip-ring induction motors.....	10-5
High-speed motors.....	10-6
Pole-change motors	10-6
Using line chokes.....	10-6
Using motor chokes	10-6
Using multiple motors on a single drive MM456 Frequency Inverter	10-7
Switching at the inverter output.....	10-8
High starting torque	10-8
Operation at higher-rating quadratic torque (HVAC) for fans and pumps .	10-9

SETTING UP THE SENSORLESS VECTOR FLUXING MODE

CONTENTS	Page
Required motor parameters.....	10-10
Auto identification of motor parameters using Autotune-.....	10-10
Entering motor parameters from known equivalent circuit.....	10-11
Entering motor parameters from simple measurement.....	10-11
Chapter 11 - APPLICATION MACROS	
GENERAL ABOUT APPLICATION MACROS	11-2
APPLICATIONS MACRO 1 - Factory default setting	
Use of MACRO 1	11-2
Block diagrams	11-2
Operator menu	11-2
Terminal allocation.....	11-2
APPLICATIONS MACRO 2 - Run, Reverse commands	
Use of MACRO 2.....	11-3
Block diagrams	11-3
Operator menu	11-3
Terminal allocation.....	11-3
APPLICATIONS MACRO 3 - Motorpotentiometer	
Use of MACRO 3	11-6
Block diagrams	11-6
Operator menu	11-6
Terminal allocation.....	11-6
APPLICATIONS MACRO 4 - PID process controller	
Use of MACRO 4	11-9
Block diagrams	11-9
Operator menu	11-9
Terminal allocation.....	11-10
APPLICATIONS MACRO 5 - Selectable preset speeds	
Use of MACRO 5	11-13
Block diagrams	11-13
Operator menu	11-13
Terminal allocation.....	11-14
APPLICATIONS MACRO 6 - Closed-loop speed control	
Use of MACRO 6	11-17
Block diagrams	11-17
Operator menu	11-17
Terminal allocation.....	11-18
Chapter 12 - APPENDICES	
DATA OF MM407-3...440-3 FOR OPERATION AT 3AC 230 V.....	12-3
MM655-5...6110-5 FOR OPERATION AT 3AC 500 V.....	12-2
ORDERING INFORMATION	12-4
Chapter 13 - INDEX	
GENERAL	13-2
MENU PARAMETERS.....	13-4
PARAMETER LIST	Removable appendix

WARNINGS, RISKS

The following warnings and risks are included to enable the user to obtain the maximum effectiveness and to alert the user to safety issues.



WARNING

Installation, operation, programming and maintenance of the equipment should be carried out by qualified personnel. A qualified person is someone who is technically competent and familiar with all safety information and established safety practices; with the installation process, operation and maintenance of this equipment; and with all the hazards involved. Non-compliance with this warning may result in lethal personal injury and/or equipment damage.

Never work on any control equipment without first isolating all power supplies from the equipment.

The capacitors in the d.c. link carry high voltages also after switching off. Wait at least 3 min before removing the protective cover, otherwise there is a high risk of electric shock. Measure the DC+ and DC-terminal voltage to confirm that the voltage is less than 50 V.

The drive motor must be connected to an appropriate safety earth. Failure to do so presents an electrical shock hazard.

The heat sink can reach a temperature of up to 90 °C.



CAUTION

These MM456 inverters were tested before they left our factory. However, before installation and start-up, inspect all equipment for transit damage, loose parts, packing materials etc.

Never perform high voltage resistance checks on the wiring without first disconnecting the MM456 Frequency Inverter from the circuit being tested.



ELECTROSTATIC SENSITIVE COMPONENTS

This equipment contains electrostatic discharge (ESD) sensitive components.

Observe static control precautions when handling, installing and servicing this product.



REPLACING EQUIPMENT

When replacing a MM456 Frequency Inverter it is essential that all user defined parameters that determine drive operation are correctly installed before putting back into service.

Failure to do so may create a hazard or risk of lethal injury.



INSTALLATION

This product conforms to IP20 protection. Due consideration should be given to the appropriate regulations of safety and protection in accordance with the environmental conditions of installation. To maintain compliance with the European LOW-VOLTAGE DIRECTIVE as in EN50178, the MM456 Frequency Inverter should preferably be mounted in a suitable enclosure requiring a tool for opening.

Ensure that

- mechanically secure fixings are used as recommended.

- cooling and air flow around the product are as recommended.
- cables and wire terminations are as recommended and clamped to required torque.
- the installation and commissioning of this product are carried out by a qualified competent person.
- the product rating is not exceeded.

This equipment must be permanently earthed due to the relatively high leakage current.

Refer to **SPECIAL INSTRUCTIONS**, page 0-12 should the MM456 Frequency Inverter be wall mounted.



APPLICATION RISK

The integration of this product into other system is not the responsibility of the supplier or manufacturer as to its applicability, effectiveness or safety of operation or of other apparatus or systems.

Where appropriate the user should consider the relevant aspects of the following risk assessment



RISK ASSESSMENT

Under fault conditions or conditions not intended:

- The motor speed may be incorrect.
- The motor speed may be excessive.
- The direction of rotation may be incorrect.
- The motor may be energized (unless suitable precautions are taken in the installation).

In all situations the user should provide sufficient guarding to prevent risk of injury and/or install suitable monitoring and safety systems in accordance with safety regulations.

SPECIAL INSTRUCTIONS

APPLICATION AREA:

Speed control of three-phase induction or synchronous motors in industrial applications (non consumer)

APPLICATIONS ADVICE:

Applications advice and training is available from your supplier.

POWER LOSS:

During power loss the MM456 inverter will not operate as specified. The power should not be reapplied for a period of 30 s to allow the inverter limit circuit to operate correctly.

MAINTENANCE:

Maintenance should only be performed by trained competent persons in accordance with the manufacturer's instructions using only the recommended spares (or return to supplier for repair). Use of unapproved spare parts may create a hazard and risk of injury. Refer to **MAINTENANCE**, page 7-2 for more details.

REPAIRS

The supplier should be contacted if a MM456 Frequency Inverter is defect. A repair can be arranged at the manufacturer of authorized agent.

Repair reports can only be given if a sufficient and accurate defect report is returned with the defect inverter.

PACKAGING:

The packaging is combustible and if disposed of in this manner incorrectly may lead to the generation of toxic fumes which are lethal.

WEIGHT:	Consideration should be given to the weight of the product when handling.
PROTECTIVE INSULATION:	All exposed metal parts are protected by basic insulation and bonding to earth i.e. Class I. Earth bonding is the responsibility of the installer. All signal terminals are protected by double insulation, i.e. Class II insulation. The purpose of this protection is to allow safe connection to other low voltage equipment.
WALL MOUNTING:	The matching NEMA 1 cover (see page 9-6) must be used to conform to the European LOW-VOLTAGE DIRECTIVE as in EN50178.
RISK OF ELECTRIC SHOCK OR INJURY:	MM456 Frequency Inverter used without the required precautions can represent an electrical hazard and risk of severe personal injury. Rotating or moving parts or structures powered by the inverter also represent a mechanical hazard with risk of severe personal injury or damage to machinery or property.

SCOPE OF THIS PRODUCT MANUAL

This Product Manual describes the operation of MM456 Frequency Inverters.

It is **not** intended that this Product Manual describes the function of the apparatus or system into which the MM456 Frequency Inverter is installed.

This Product Manual is to be made available to all persons who are required to design an installation using the MM456 Frequency Inverter or to install, set up, commissioning, service operate or are in any way involved with the MM456 Frequency Inverter itself.

These persons who must be suitably qualified must read this Product Manual thoroughly and completely before beginning with the installation and commissioning.

TECHNICAL CHANGES

The manufacturer reserves the right to change the content and product specification without notice.

WARRANTY


This piece of equipment is warranted against defects in design materials and workmanship for a period of 12 month from the date of delivery as detailed in the general terms of supply and payment of the ZVEI (Federation of the German Electrical Industry).

Chapter 1 - PRODUCT OVERVIEW

	Page
GENERAL DESCRIPTION	1-2
TECHNICAL DATA	
General	1-5
Environmental requirements.....	1-6
Safety.....	1-7
EC-Directives	1-7
Power circuit	1-8
Voltage supply.....	1-10
Control circuit	1-10
Special Considerations for installation in compliance with UL.....	1-11
ORDERING INFORMATION	1-12

GENERAL DESCRIPTION

MM456 Frequency Inverters:	<ul style="list-style-type: none"> ◆ Suitable for the speed control of standard 3-phase induction motors (squirrel-cage motors with fixed or variable speed) ◆ Universally suitable for general industry applications with a constant torque requirement as well as for fans and pumps with a quadratic load characteristic ◆ Can be supplied for the following supply voltages: <table style="margin-left: 20px; border: none;"> <tr> <td></td> <td></td> <td style="text-align: right;">for motors up to</td> <td></td> </tr> <tr> <td>• 1/N AC: - 230 V</td> <td>±15 %</td> <td>2.2 kW</td> <td></td> </tr> <tr> <td>• 3AC: - 380...460 V</td> <td>±10 %</td> <td>11 kW (15 kW with HVAC)</td> <td></td> </tr> <tr> <td></td> <td>±15 %</td> <td>7.5 kW (11 kW with HVAC)</td> <td></td> </tr> </table> ◆ Universally suitable for nearly all drive applications ◆ Optimum cost/performance 			for motors up to		• 1/N AC: - 230 V	±15 %	2.2 kW		• 3AC: - 380...460 V	±10 %	11 kW (15 kW with HVAC)			±15 %	7.5 kW (11 kW with HVAC)	
		for motors up to															
• 1/N AC: - 230 V	±15 %	2.2 kW															
• 3AC: - 380...460 V	±10 %	11 kW (15 kW with HVAC)															
	±15 %	7.5 kW (11 kW with HVAC)															
Powerful microprocessor control and software:	<ul style="list-style-type: none"> ◆ Simple programming and diagnostics with an operating panel consisting of 2x16 character plain multilanguage LCD display, 5 function keys for programming and 5 additional keys to allow basic operation control in LOCAL MODE. ◆ Sine-wave PWM modulation in the full speed range ◆ Special low-noise quiet-pattern PWM ◆ Advanced protection functions with auto-restart control ◆ Many powerful application-orientated software functions, see page 1-4 ◆ RS232 serial link ◆ Input for 2 track incremental encoder for speed detection 																
EMC:	<ul style="list-style-type: none"> ◆ All MM456 Frequency Inverters are supplied with a built-in EMC filter to class B interference protection or can be supplied with external EMC filters. Please refer to supplier for difficult applications (e.g. long cable runs). 																
Options MM45:	<ul style="list-style-type: none"> ◆ Removable operating panel ◆ Mounting kit for separate mounting programming pad, e.g. in a door of an enclosure ◆ NEMA 1 top cover ◆ RS 485/422 serial link (technology box) ◆ PROFIBUS-DP Bussystem (technology box) ◆ CANBUS Devicenet and CANopen (technology box) ◆ ECHELON bus interface ◆ Braking resistors ◆ KIMOVIS software for operating and programming (WINDOWS and DOS) 																
Options MM6:	<ul style="list-style-type: none"> ◆ Options as with MM45 ◆ Digital speed feedback (technology box) 																
Standard supply:	<ul style="list-style-type: none"> ◆ MM456 Frequency Inverter ◆ Product Manual TMM456 including parameter list 																
Further documentation:	<ul style="list-style-type: none"> ◆ Software and application manual TMM456/3SV-SAM ◆ EMC Compendium AF-MM-02 ◆ Product information CE marking of electronic drive equipment PI-LKTM-005 																



**Fig. 1.1a: Main parts of MM45 Frequency Inverter
(Main inverter assembly MM422, MM515...540 lower right)**




Fig. 1.1b: Main parts of MM6 Frequency Inverter

TECHNICAL DATA

General

Control;	Full local control via the operating panel or with external analog and digital control inputs
Output frequency:	0...120 Hz, 0...240 Hz or 0...480 Hz (selectable)
Switching frequency:	3, 6 or 9 kHz (selectable, available frequencies depends on rated size)
Stopping modes:	Ramp, Ramp with d.c.holding pulse, d.c. injection braking , coast, FRAMP (fast ramp)
Ramps:	Ramp up, ramp down, fast stop and S-Ramps
Flux control:	<ul style="list-style-type: none"> - v/f-control with linear and quadratic torque including fixed and auto boost, - dynamic sensorless Vektor control with autotune for dynamic operation with high torque at small speed, Slip compensation
Skip frequencies:	4 with adjustable band widths (e.g. to avoid mechanical resonances)
Parameter sets:	4 x 16 parameters, 8 x 8, software connectable to any relevant parameter
Application software:	Universal function blocks can be software wired to suit almost any application
PID-Controller:	Universally programmable PID controller
Link:	Serial link RS232 integrated
Hoisting and travel drives:	Integrated ramp functions and brake control
Password:	Integrated password protection for customer setted parameters
Speed control:	Processing of 2 track incremental encoder or analog tachogenerator (Technology box for digital speed feedback required with MM6)
Digital MOP:	Digital motor potentiometer
Jog:	Adjustable jog speed
Logic functions:	10 configurable Logik function blocks each with 3 Inputs, programmable as NOT, AND, NAND, OR, NOR, XOR
Processing function:	10 programmable processing functions each with 3 inputs for 21 functions such as ABSOLUTE VALUE, SWITCHING, ADDING, SUBTRACTING
Other:	Autostart control, fly catching
Programming pad: (Option)	Removeable, 2x16 character LCD display (illuminated), (Option) 5 function keys for programming, 5 additional function keys for load operation, 7 LED's

Protection; Trip conditions:	Short circuit line - line, or line - earth, Peak current >250 % rated current, I x t overload 50...105 % (adjustable), Heat sink overtemperature, overvoltage, undervoltage , input for external trips (e.g. for connection of an external thermistor relay)
Current limit:	0...150 % rated current adjustable

V/f characteristic:	Linear: for constant torque Quadratic: pumps and fans Adjustments: base frequency and voltage
----------------------------	---

Diagnostics:	with LCD display and status LED's
---------------------	-----------------------------------

Inputs/outputs;		MM45:	MM6:
	Analog inputs:	2	4
	Analog output:	1	2
	Digital inputs:	7	8
	Digital outputs:	2x 24 V Industry logic	3 x Relays
	Thermistor input:	Refer to supplier	1

Environmental requirements

Permissible temperature:	0 ...+45 °C	Operation: - at constant torque (CT) - with quadratic torque at higher power (HVAC)
	0 ...+40 °C	
	0 ...+40 °C	with NEMA1 top cover (CT)
	0 ...+35 °C	with NEMA1 top cover (HVAC)
	-25 ...+55 °C	Storage
	-25 ...+70 °C	Transport (short term)
Climatic condition:	Class 3K3 (EN60721-3-3)	5...85 % relative humidity
	Other requirements:	Dust free (see pollution) non corrosive and non flammable
Pollution:	Degree 2 pollution (IEC 664-1):	Dry non-conducting dust or particles, infrequent light condensation when switched off permissible
Altitude:	≥1000 m above sea level	1 % / 100 m power derating

Safety

Relevant standards:	Europe: North America, Canada:	EN50178 (1998) valid for - Enclosure mounting - Wall mounting provided the NEMA1 top cover is securely fitted UL508C valid for: - Enclosure mounting as "Open-type Drive" - Wallmounted provided the NEMA 1 top cover is securely fitted as "Type 1 Enclosed"
Overtoltage category (IEC664-1 (1992)):	III	Only for use with TT/TN voltage supplies with an earthed neutral
Rated insulation voltage to PE:	AC 460 V	
Protective class: (IEC 536 (1976))	I	Basic insulation with PE connection (protective earth). The user is responsible for the PE connection
IP- Protection: (EN 60529 (1991))	Enclosure mounted: Wall mounted with top cover fitted:	All surfaces IP20 Top cover IP40, Other surfaces IP20
UL (c-UL): Enclosure rating	Enclosure mounted: Wall mounted with top cover fitted:	Open type Type 1
Prospective short circuit current:	MM45: ≤5 kA MM6: ≤10 kA	
Earthing:	Permanent earthing is mandatory. One of the two following methods can be used: - Use a copper conductor of at least 10 mm ² cross-sectional area - Use a two independent earth conductors each connected to a parallel to a separate earth terminal of the MM456 Frequency Inverter. NOTE: Each conductor itself must meet the local requirements for a protective earth conductors.	

EC-Directives

EMC-DIRECTIVE:	The requirements of the European EMC-DIRECTIVE are met as follows: - MM407...422-EMC integrated EMC filters - MM515...540-EMC integrated EMC filters - MM655...6110 with approved external EMC filters The EMC Installation Instructions (page 3-9...18) and information on applying the EMC DIRECTIVE (page 8-3...11) must be observed.
LOW VOLTAGE DIRECTIVE:	The requirements of the European LOW VOLTAGE DIRECTIVE for CE marking are adhered to

Power circuit

Product code	MM407-EMC	MM415-EMC	MM422-EMC
Supply voltage:	1/N AC 230 V	±15 %, 50...60 Hz ±5 Hz	

Normal operation with 150 % overload (CT)

◆ Typical applications:	Motor power	0.75 kW	1.5 kW	2.2 kW
	- Machinery	Motor current I _n	4.0 A	7.0 A
- Transport technology	Motor cable E rope ⁵⁾	1 mm ²	1 mm ²	1/1.5 mm ²
	Motor cable North America ⁶⁾	14 AWG	14 AWG	14 AWG
- Long-travel and hoisting	Switching frequency	3/6/9 kHz	3/6/9 kHz	3/6/9 kHz
	◆ Overload capability:	Approx. losses 6 kHz	52 W	97 W
150 % I _n / 60 s	Supply current	8 A	15 A	23 A
	Supply fuse / Circuit breaker ¹⁾	10 A	20 A	25 A
	Supply cable I rope ⁵⁾	1/1.5 mm ²	2.5/4 mm ²	4/6 mm ²
	Supply cable North America ⁶⁾	14 AWG	12 AWG	10 AWG
	Earth leakage current	>10 mA	>10 mA	>10 mA
	Fuse for UL compliance ²⁾	10 A ¹⁾	20 A ¹⁾	25 A ¹⁾

Operation at higher power with 110 % overload(HVAC)

◆ Main applications:	Motor power	1.1 kW ⁴⁾	2.2 kW ⁴⁾	3 kW ⁴⁾
	- Pumps	P _{shaft} typical 2-pole	1.0 kW	1.9 kW
- Fan	P _{shaft} typical 4 pole	0.9 kW	1.4 kW	2.8 kW
	◆ Overload capability:	Max. current I _n	4.0 A	7.0 A
110 % I _n / 10 s	Motor cable E rope ⁵⁾	1 mm ²	1 mm ²	1/1.5 mm ²
	Motor cable North America ⁶⁾	14 AWG	14 AWG	14 AWG
	Approx. losses 3 kHz	52 W	97 W	143 W
	Switching frequency	3 kHz	3 kHz	3 kHz
	Supply current	8 A	15 A	23 A
	Supply fuse / Circuit breaker ¹⁾	10 A	20 A	25 A
	Supply cable I rope ⁵⁾	1/1.5 mm ²	2.5/4 mm ²	4/6.0 mm ²
	Supply cable North America ⁶⁾	14 AWG	12 AWG	10 AWG
Special setting for higher-rating necessary, see page 10-9	Earth leakage current	>10 mA	>10 mA	>10 mA
Fuse for UL compliance ²⁾	10 A ¹⁾	20 A ¹⁾	25 A ¹⁾	

Integrated braking chopper:

Max. current	- ED ≤30 %, 10 s max.	4 A	4 A	10 A
Ext. braking resistor	- Minimum value	100 Ω	100 Ω	56 Ω
Available braking resistors for	- Light braking	200BR0004	100BR001	100BR001
	- High braking torque short term	100BR001	100BR001	100BR006
	- High braking torque with heavy braking operation	100Ω/0.04kW	100Ω/0.08kW	100Ω/0.08kW
		100Ω/0.08kW	100Ω/0.08kW	100Ω/0.08kW
		100BR006	100BR012	100Ω/1.2kW

Installation, Mounting:

		Convection	Convection	Fan
Cooling				
Weight approx.:	- MotorMaster Frequency Inverter	2.8 kg	2.9 kg	4.1 kg
	- Programming Pad (Option)	0.1 kg	0.1 kg	0.1 kg
Dimensions:	- Height	198 mm	198 mm	233 mm
	- Height with top cover	198 mm	198 mm	233 mm
	- Width	155 mm	155 mm	171 mm
	- Depth	155 mm	155 mm	181 mm
Air flow clearance:	- Above, below	80 mm	80 mm	80 mm
	- Left, right	15 mm	15 mm	15 mm
	- Front with wall mounting ⁷⁾	15 mm	15 mm	15 mm
Power terminals:	- Max. conductor size	4 mm ² /10 AWG	4 mm ² /10 AWG	4 mm ² /10 AWG
	- Max. torque	1.0 Nm	1.0 Nm	1.0 Nm
Terminals for braking chopper:	- Max. conductor size	4 mm ² /10 AWG	4 mm ² /10 AWG	4 mm ² /10 AWG
	- Max. torque	1.0 Nm	1.0 Nm	1.0 Nm
Outline drawing:		3.1a	3.1a	3.1b

1) Fuse or circuit breaker with delayed release

2) UL Listed JDDZ, class K5 or H; UI Listed JDRX, class H

3) For operation to UL

4) Reduced shaft power

MM515-EMC		MM522-EMC		MM540-EMC		MM655		MM675		MM6110	
3AC 380...460 V ±10 %, 50...60 Hz ±5 Hz											
Operation with constant torque (CT)											
1.5 kW	2.2 kW	4.0 kW	5.5 kW	7.5 kW	11 kW	12 A	16 A	23 A	12 A	16 A	23 A
4.5 A	5.5 A	9.5 A	12 A	16 A	23 A	1.5/2.5 mm ²	2.5/4 mm ²	4/6 mm ²	1.5/2.5 mm ²	2.5/4 mm ²	4/6 mm ²
14 AWG	14 AWG	14 AWG	12 AWG	12 AWG	10 AWG	3/6/9 kHz	3/6 kHz	3/6 kHz	3/6/9 kHz	3/6 kHz	3/6 kHz
77 W	106 W	175 W	220 W	260 W	330 W	6 A	8 A	11 A	15 A	22 A	28 A
3x10 A	3x10 A	3x16 A	3x20 A	3x25 A	3x32 A	1/1.5 mm ²	1/1.5 mm ²	1.5/2.5 mm ²	2.5/4 mm ²	4/6 mm ²	6/10 mm ²
14 AWG	14 AWG	14 AWG	12 AWG	10 AWG	8 AWG	>10 mA	>10 mA	>10 mA	>10 mA	>10 mA	>10 mA
3x10 A ¹⁾	3x10 A ¹⁾	3x15 A ¹⁾	3x20 A ¹⁾	3x20 A ¹⁾	3x20 A ¹⁾						
Operation with quadratic torque at higher power (HVAC)											
2.2 kW ⁴⁾	3.0 kW ⁴⁾	5.5 kW ⁴⁾	7.5 kW	11 kW	15 kW	2.0 kW	2.8 kW	4.3 kW	7.5 kW	11 kW	15 kW
1.9 kW	2.5 kW	4.2 kW	7.5 kW	11 kW	15 kW	4.5 A	5.5 A	9.5 A	16 A	23 A	31(27 ³⁾ A
1 mm ²	1 mm ²	1/1.5 mm ²	2.5/4 mm ²	4/6 mm ²	6/10 mm ²	14 AWG	14 AWG	14 AWG	12 AWG	10 AWG	8 AWG
77 W	106 W	175 W	270 W	350 W	450 W	3 kHz	3 kHz	3 kHz	3 kHz	3 kHz	3 kHz
6 A	8 A	11 A	20 A	28 A	35(32 ³⁾ A	3x10 A	3x10 A	3x16 A	3x25 A	3x32 A	3x40 A
1/1.5 mm ²	1/1.5 mm ²	1.5/2.5 mm ²	4/6 mm ²	6/10 mm ²	10 mm ²	14 AWG	14 AWG	14 AWG	10 AWG	8 AWG	8 AWG
>10 mA	>10 mA	>10 mA	>10 mA	>10 mA	>10 mA	3x10 A ¹⁾	3x10 A ¹⁾	3x15 A ¹⁾	3x32 A ¹⁾	3x32 A ¹⁾	3x40 A ¹⁾
Integrated braking chopper											
10 A	10 A	10 A	7.5 A	15 A	15 A	56 Ω	56 Ω	56 Ω	100 Ω	50 Ω	50 Ω
200BR0004	200BR0004	100BR001	100BR001	100BR001	100BR006	200Ω/0.04 kW	200Ω/0.04 kW	100Ω/0.08 kW	100Ω/0.08 kW	100Ω/0.08 kW	100Ω/0.6 kW
100BR001	100BR006	100BR006	100BR006	39BR006	39BR012	100Ω/0.08 kW	100Ω/0.6 kW	100Ω/0.6 kW	100Ω/0.6 kW	39Ω/0.6 kW ⁸⁾	39Ω/1.2 kW ⁸⁾
100BR006	100BR012	100BR012	100BR012	39BR012	39BR050	100Ω/0.6 kW	100Ω/1.2 kW	100Ω/1.2 kW	39Ω/1.2 kW ⁸⁾	39Ω/5.0 kW ⁸⁾	
Installation, Mounting											
Convection	Convection	Fan	Fan	Fan	Fan	4.0 kg	4.2 kg	4.2 kg	8.8 kg	8.9 kg	9.0 kg
0.1 kg	0.1 kg	0.1 kg	0.1 kg	0.1 kg	0.1 kg	233 mm	233 mm	233 mm	348 mm	348 mm	348 mm
233 mm	233 mm	233 mm	365 mm	365 mm	365 mm	181 mm	181 mm	181 mm	201 mm	201 mm	201 mm
200 mm	200 mm	200 mm	208 mm	208 mm	208 mm	80 mm	80 mm	80 mm	70 mm	70 mm	70 mm
15 mm	15 mm	15 mm	20 mm	20 mm	20 mm	15 mm	15 mm	15 mm	0 mm	0 mm	0 mm
15 mm	15 mm	15 mm	0 mm	0 mm	0 mm	4 mm ² /10 AWG	4 mm ² /10 AWG	4 mm ² /10 AWG	2.5 mm ² /12 AWG	6 mm ² /8 AWG	6 mm ² /8 AWG
1,0 Nm	1,0 Nm	1,0 Nm	1,5 Nm	1,5 Nm	1,5 Nm	4 mm ² /10 AWG	4 mm ² /10 AWG	4 mm ² /10AWG	2,5 mm ² /12 AWG	2,5 mm ² /12 AWG	2,5 mm ² /12 AWG
1.0 Nm	1.0 Nm	1.0 Nm	1.0 Nm	1.0 Nm	1.0 Nm	3.1b	3.1b	3.1b	3.1c	3.1c	3.1c

Size of cables in accordance with: 5) EN60204-1 (see page 3-7) 7) With NEMA1 top cover 8) Only with 3AC 400 V, otherwise refer to supplier

Voltage supply

Frequency Inverter MM...-EMC with integrated EMC filter are only for TT/TN supplies with an earthed neutral, use with IT-supplies is not permissible.

Other voltages (refer to supplier before use):

MM407...422-EMC:	2AC 220...240 V	±10 %	50...60 Hz ±5 Hz
	DC 220...340 V	±10 %	
MM515...540-EMC, MM655...6110:	3AC 380...460 V	±10 %	50...60 Hz ±5 Hz
	DC 380...650 V	±10 %	

Control circuit

Reference and auxiliary supplies

Reference supplies for analogue inputs	+10 V ± 5 %, 10 mA max. load
Auxiliary supply for digital inputs	+24 V ±15 %, 150 mA max. load

Analogue I/O

	Inputs		Outputs	
Range	0...+10 V	0/4...20 mA	0...+10 V	0...20 mA
Impedance	94 kΩ	220 Ω	100 Ω	100 Ω
Limit value	+24 V	7,9 V	5 mA	20 mA
Resolution	10 bit (1 in 1024)		8 bit (1 in 256)	
Sample rate	20 ms		20 ms	

Digital I/O

		Inputs	Outputs
		IM45:	IM6:
Logic system		DC 24 V Industry logic	DC 24 V Industry logic Isolated relay contacts
Switching levels	'0'	<+6 V	open (+24 V auxiliary supply)
	'1'	>+18 V	activated (auxiliary supply +24 V - 1 V)
Absolute max. voltage range		-30...+30 V	0...+ 30 V AC 230 V
Impedance		47 kΩ	10 Ω -
Max. output current		/	50 mA 3 A - res. load 250 VA - ind. load
Sample rate	20 ms		20 ms 20 ms


Thermistor motor protection

An input for connecting to an external motor thermistor device is available with the MM6 Frequency Inverter. Conductors of up to 2.5 mm² (12 AWG) may be connected. The use of 1...2.5 mm² as in EN 60204-1 is recommended.

Control terminals

"Cage-clamp" terminals without screws for 0.08...2.5 mm² conductors (ferrules not required). The use of 0.2...0.75 mm² as in EN 60204-1 is recommended

Special considerations for installation in compliance with UL

- Solid state motor overload protection: ♦ These MM456 Frequency Inverters provide Class 10 motor overload protection. The maximum internal overload protection level (current limit) is 150 % for 60 s. Refer to **Chapter 4 - SETTING UP AND COMMISSIONING, I*T TRIP** for user current limit adjustment information.
- An external motor overload protective device must be provided by the installer where the motor has a full load ampere rating of less than 50 % of the Inverter output rating.
- Short circuit rating of supply: ♦ All MM45 Frequency Inverters are suitable for use on a circuit capable of delivering not more than 5,000 RMS Symmetrical Amperes, 240 V / 460 V maximum (as appropriate).
- ♦ All MM6 Frequency Inverters are suitable for use on a circuit capable of delivering not more than 10,000 RMS Symmetrical Amperes, 480 V maximum (as appropriate).
- Solid state short-circuit protection: ♦ These MM456 Frequency Inverters are provided with Solid-State Short-Circuit (output) Protection. Branch circuit fusing requirements must be in accordance with the latest edition of the National Electric Code NEC/NFPA 70.
- Recommended branch circuit protection: ♦ It is recommended that UL Listed (JDDZ) non-renewable cartridge fuses, Class K5 or H; or UL Listed (JDRX) renewable cartridge, Class H, are installed upstream of the Inverter. Refer to page 1-8/9 for recommended fuse ratings.
- Motor base frequency: ♦ The maximum settable base frequency is 480 Hz.
- Field wiring temperature rating: ♦ MM409...422-EMC: Use 60 °C or 60/75 °C copper conductors only,
MM655...611: Use 75 °C copper conductors only.
- Field wiring terminal markings: ♦ For correct field wiring connections that are to be made to each terminal refer to **Power terminals**, page 2-8/9, and **Control terminals**, page 2-9...12.
- Power wiring terminals: ♦ Refer to the table on page 1-8/9 for maximum conductor sizes.
- Terminal tightening torque: ♦ Refer to the table on page 1-8/9 for maximum tightening torques.
- Field grounding terminals: ♦ The field grounding terminals are identified with the International Grounding Symbol  (IEC Publication 417, Symbol 5019). Refer to page 2-4/8 and 3-5/6 for further information.
- Operating ambient temperature: ♦ The maximum operating ambient temperature rating is 45 °C (40 °C for inverters with a Type 1 enclosure), refer to page 1-6.
- Direct wall-mountable inverters: ♦ All MM456 Frequency Inverters fitted with a NEMA 1 cover are suitable for direct wall mounting applications as they have a "Type 1 Enclosure" rating.
- In order to preserve this enclosure rating, it is important to maintain the environmental integrity of the enclosure. Therefore, the installer must provide correct Type 1 closures for all unused clearance holes provided within the inverter's glandplate.
- Type 1 enclosed inverters are suitable for use in no worse than a Pollution Degree 2 environment.

ORDERING INFORMATION

Function	Order code	Technical data	Order no.
Frequency Inverters with built-in EMC filter for class B interference protection and for operation with 1/2AC 220...240 V or 3AC 380...460 V	MotorMaster MM407-EMC	0.75 kW, 1AC 220-240 V, 4.0 A	8671.207-100
	MotorMaster MM415-EMC	1.5 kW, 1AC 220-240 V, 7.0 A	8671.212-100
	MotorMaster MM422-EMC	2.2 kW, 1AC 220-240 V, 10.5 A	8671.213-100
	MotorMaster MM515-EMC	1.5 kW, 3AC 380-460 V, 4.5 A	8672.312-100
	MotorMaster MM522-EMC	2.2 kW, 3AC 380-460 V, 5.5 A	8672.313-100
	MotorMaster MM540-EMC	4.0 kW, 3AC 380-460 V, 9.5 A	8672.315-100
Frequency Inverters for operation with 3AC 380...460 V	MotorMaster MM655	5.5 kW, 3AC 380-460 V, 12 A (HVAC: 7.5 kW, 16 A)	8672.316
	MotorMaster MM675	7.5 kW, 3AC 380-460 V, 16 A (HVAC: 11 kW, 23 A)	8672.317
	MotorMaster MM6110	11 kW, 3AC 380-460 V, 23 A (HVAC: 15 kW, 31 A)	8672.320
Removable Programming Pad	OPTION MM-PROG	Programming pad/Prog.-Einheit	8629.001

FUNCTIONAL OVERVIEW

MM456 Frequency Inverters are microprocessor based d.c.-link 3-phase inverters used to control the speed of standard 3-phase induction motors (standard squirrel-cage). A removable programming pad based on an illuminated 2x16 character LED display with operating keys allows easy access to operating function and adjustable parameters. The hierarchical menu allows parameters to be directly changed and provides access to many configurable optional functions for special application.

Fig. 2.1 is a general wiring diagram. The functional block diagram of Fig. 2.2 explains the control circuit in more detail in the basic configuration as supplied (default setting).

Many function blocks which can be freely wired with software links such as a PID controller, auto-start logic are available with MM456 Frequency Inverter. Fig. 2.3 shows an application functional block diagram with software links as in MACRO 1. A separate detailed description with many application examples is available as **TMM456/3SV-SAM Software and Application Manual**.

The basic functions of the MM456 frequency inverters are described in the following:

Power input circuit and d.c. link: The two-phase or three-phase supply voltage on terminals L1, L2 and L3 or L1, N is rectified to provide a d.c. output voltage. The connection between the rectifier and inverter is called the d.c. link and comprises a charging circuit and a d.c. link capacitor. The d.c. capacitors smooth the d.c. voltage fed to input to the inverter power stage.

Inverter output circuit: The inverter circuits convert the d.c. input from the d.c. link to the 3-phase output required to supply the motor with variable frequency. The gate drive signals generated by the control circuits control the IGBT output transistors to produce the required 3-phase output. The frequency and amplitude are determined by the control inputs and by the parameters set up via the programming pad.

Dynamic braking with external braking resistors: During motor deceleration or at other times when the motor acts as a generator, energy flows from the motor into the d.c. link capacitors and causes the d.c. link voltage to rise. Small amounts of regenerative energy can be absorbed by the d.c. link. The MM456 Frequency Inverter trips with "Overvoltage" if the d.c. link voltage exceeds the over-voltage trip level (approx. 400 V) in order to protect the inverter.

Most standard industrial motors when operated below the rated speed can provide a significant torque on braking due to the higher terminal voltage (i.e. overfluxing).

Higher braking powers can be catered for using an external braking resistor. The external braking resistor is switched to be in parallel with the link capacitors when the d.c. link voltage exceeds the brake threshold level.

- Control circuits and software:** The function of the control circuits and software as supplied (function default condition) is shown in the functional block diagram Figure 2.2.
- Inputs to the control circuit are provided by connections to the control board terminals (identified on the left hand side of the block diagram) and by parameters set via the operating panel.
- Parameters:** Parameters are values or options that are programmed via the operating panel. These are usually set up during installation and commissioning and are not changed during normal operation.
- Refer to **Chapter 4** for further information on the programming pad and parameter descriptions.
- Diagnostics:** Diagnostic parameters are values that can be displayed in the diagnostic menu within the operating panel. These values are read-only and are provided for the user to determine operating or fault conditions. Refer to **Chapter 5** for further information and descriptions of the diagnostics.
- Analogue inputs/outputs:** The analog inputs and outputs are freely configurable. For this purpose both the DIL switch (see page 2-13) and the associated software parameter (see page 5-8) must be correctly set to suit the particular application.
- Digital inputs and outputs:** Digital inputs to the control circuit are usually provided by externally switched contacts. An +24 V auxiliary supply is available between terminals 6 and 12 for this purpose. The maximum loading is 150 mA.
- The digital outputs with MM45 Frequency Inverters are "Active High" outputs in 24 V industry logic. The maximum output load is 50 mA.
- With MM6 Frequency Inverters isolated contacts of three output relays are available.
- Refer to page 2-9 for further information on digital inputs and outputs which are freely configurable.

BASIC WIRING AND BLOCK DIAGRAMS





Fig. 2.1: General wiring diagram of power sections of MM4, MM5 und MM6 Frequency Inverters



WICHTIG:
IMPORTANT:

- . Brücke 6-10 wenn externe Überwachung nicht angeschlossen/
Link 6-10 if external Trip not used
- . OPTION MM-PROG-PM (3m) nur für Fernmontage der Programmier-Einheit/
OPTION MM-PROG-PM (3m) only for distant mounting of the Programming Pad
- . Klemme 6, +24 V auf keinen Fall mit externer 24 V Spannungsversorgung verbinden/
Terminal 6, +24V must not be connected to an external 24 V supply voltage

Fig. 2.2a: General wiring diagram of control circuit of MM45 Frequency Inverters




Fig. 2.2b: General wiring diagram of control circuit of MM6 Frequency Inverter




Fig. 2.3: Functional block diagram of supplied configuration of control circuit (Digital outputs with MM45, MM6 has relay outputs)





Fig. 2.4: Application functional block diagram with software links as in MACRO 1



(default supply condition)





TERMINAL DESCRIPTIONS



WARNINGS !




- Frequency Inverters with integrated or external EMC filters may only be used with TT/TN voltage supplies with an earthed neutral.
The use with IT supplies is not permissible.
- The power terminals carry high voltages which can be lethal.
- Never work on any control equipment or motors without first removing all power supplies from the equipment and waiting for the drive to be stationary.
- Always wait until the link capacitors are discharged (at least 3 min).

Power terminals with MM45

Terminal	Designation	Function	Explanation
	 	Two connections for protective earth of voltage supply, see Fig. 3.2, page 3-4 (must be used)	Observe all safety and EMV requirements as described in Chapter 3.
1 2	L1 L2/N	Connection for single-phase voltage supply with MM407...422-EMC	L/N AC 230 V ± 15 %/ 2AC 230 V ± 15 %
1 2 3	L1 L2 L3	Connection for three-phase voltage supply with MM515...540-EMC	3AC 380...460 V ± 10 %
4	DC-	Negative connection to d.c. link	Applications (terminals 4 and 6): - D.C. supply - Parallel connection of d.c. links of two or more inverters (only after referring to supplier)
5	DBR	Connection for external braking resistor	
6	DC+	Positive connection to d.c. link also for connection to external braking resistor	
7 8 9	M1/U M2/V M3/W	Motor connection (three-phase)	3-phase supply voltage: - 3AC 0...supply voltage - 0... f_{max}
		Connection for protective earth of motor	Observe all safety and EMV requirements as described in Chapter 3.
	Clamp	Connection for screen of control cable	
		Clamp for screen of motor cable	

Refer to the General wiring diagram of power sections, Fig. 2.1 (page 2-4) for further information on connections to the power terminals.

Power terminals with MM6

Terminal	Designation	Signal, function	Explanation
	 	Two connections for protective earth of voltage supply, see Fig. 3.2, page 3-5/6 (must be used)	Observe all safety and EMV requirements as described in Chapter 3 .
	L1 L2 L3	Connection for three-phase voltage supply with MM6	3AC 380...460 V $\pm 10\%$
	DC+	Positive connection to d.c. link	Applications: - D.C. supply - Parallel connection of d.c. links of two or more inverters (only after referring to supplier) - Connection of additional external braking chopper
	DC-	Negative connection to d.c. link	
	M1/U M2/V M3/W	Motor connection (three-phase)	3-phase supply voltage: - 3AC 0...supply voltage - 0...f _{max}
		Connection for protective earth of motor and screen	Observe all safety and EMV requirements as described in Chapter 3 .
	DBR+	Connection for external braking resistor when using internal braking chopper	Observe minimum value of braking resistance, see page 1-9
	DBR-		

Refer to the General Wiring Diagram, Fig. 2.1 (page 2-4) and Block Diagram, Fig. 2.3 (page 2-5) for further information on connections to the power terminals.

Control terminals of MM45

All MM45 Frequency Inverters have the identical control terminals. The functions of the control terminals as supplied (factory default condition) are described in the following table. Refer to "Control Terminals" for details on cable sizes on page 1-10.

NOTE: In the following table, parameters are indicated by a special bold type, e.g. MAX SPEED. These parameters can be changed using the programming pad (refer to **chapter 4**).

Terminal	Designation	Signal, function	Explanation
1	0 V REF	Zero volt reference for analog signals or 20 mA current-loop connection	- Do not use for other purposes !!
2	AIN1	Configurable analog input in the range 0...+10 V, +2...+10 V, 0...+5 V, +1...+5 V, -10...+10 V, 0...20 mA, 4...20 mA, 20...4 mA, 20...0 mA usually used as speed setpoint: 0 V = MIN SPEED +10 V = MAX SPEED forwards	- As set by the DIL switch and QUICK SETUP AIN 1 TYPE (see page 5-8) - MAX and MIN SPEED see page 5-4 - Input impedance = 94 k Ω .
3	+10 V REF	Internal +10 V reference voltage for analog inputs	- 5 mA max. load - Tolerance approx. $\pm 3\%$
4	AIN2	Configurable analog auxiliary-input usually used as a trim set-value, otherwise as AIN1	- As AIN 1

Terminal	Designation	Signal, function	Explanation
5	AOUT	Analog output in the range 0...+10 V, or 0...20 mA, usually used as output frequency: 0 V = 0 Hz +10 V = MAX SPEED	- 5 or 20 mA max. load - Accuracy $\pm 3\%$
6	+24 V	+24 V auxiliary supply for digital inputs	- 150 mA max. load together with terminal 24 - Tolerance approx.. $\pm 10\%$ <u>Not to be connected to an external 24 V supply voltage</u>
7	DIN1	Configurable digital input, usually used as command "Run", for starting and stopping the drive: 0 V = Stop +24 V = Run	- Stopping as set in RUN STOP MODE (see page 5-7)
8	DIN2	Configurable digital input, usually used to reset trips: 0 V = Normal +24 V = Reset	- Edge triggered
9	DIN3	Configurable digital input, usually used to control the direction of motion: 0 V = Forwards +24 V = Reverse	
10	DIN4	Configurable digital input, usually used for an external monitoring circuit: 0 V = Fault +24 V = No fault	- Connect to +24 V (terminal 6) if not used
11	DIN5	Configurable digital input, usually used to select the jog speed: +24 V = Jog speed 0 V = Normal	
12	0 V	0 V Reference point for digital inputs	
13	DOUT1	Configurable digital output usually used for "Health": Open = No supply, fault or alarm Activated = Health	- "Active high" outputs, e.g. to excite external DC 24 V relays, max. load 50 mA
14	DOUT2	Configurable digital output usually used for "Running": Open = No supply, fault or alarm Activated = Running	
15	0 V	0 V intended for incremental encoder or return of output relays	
16	DIN6	Configurable digital input, intended for connection to A track of incremental encoder	- Can be used as further inputs - Used as preset inputs with MACRO 5
17	DIN7	Configurable digital input, intended for connection to B track of incremental encoder	
18	+24V	24 V supply intended for incremental encoder	- 150 mA max. load together with terminal 6 - Tolerance approx.. $\pm 10\%$ <u>Not to be connected to an external 24 V supply voltage</u>

Control terminals with MM6

All MM6 Frequency Inverters have the identical control terminals. The functions of the control terminals as supplied (factory default condition) are described in the following table. Refer to "Control Terminals" for details on cable sizes on page 1-10.

NOTE: In the following table, parameters are indicated by a special bold type, e.g. MAX SPEED. These parameters can be changed using the programming pad (refer to **Chapter 4**).

Terminal	Designation	Signal, function	Explanation
1	AIN1	Configurable analog input in the range 0...+10 V, +2...+10 V, 0...+5 V, +1...+5 V, -10...+10 V, 0...20 mA, 4...20 mA, 20...4 mA, 20...0 mA usually used as speed setpoint: 0 V = MIN SPEED +10 V = MAX SPEED forwards	- As set by the DIL switch and QUICK SETUP AIN 1 TYPE (see page 5-8) - MAX and MIN SPEED see page 5-4 - Input impedance = 94 kΩ.
2	AIN2	Configurable analog auxiliary-input in the range 0...+10 V, +2...+10 V, 0...+5 V, +1...+5 V, -10...+10 V, 0...20 mA, 4...20 mA, 20...4 mA, 20...0 mA usually used as a trim set-value: 0 V = MIN SPEED +10 V = MAX SPEED forwards	- As set by the DIL switch and QUICK SETUP AIN 2 TYPE (see page 5-8) - MAX and MIN SPEED see page 5-4 - Input impedance = 94 kΩ.
3	AIN3	Configurable analog input in the range 0...20 mA, 4...20 mA, 20...4 mA, 20...0 mA	- As set by the DIL switch QUICK SETUP AIN 3 TYPE(see page 5-8)
4	0V	0 V for digital inputs	
5	AIN4	Configurable analog input in the range 0...+10 V, +2...+10 V, 0...+5 V, +1...+5 V,	- As set by the DIL switch QUICK SETUP AIN 4 TYPE(see page 5-8)
6	AOUT1	Analog output in the range 0...+10 V, 0...20 mA, 4...20 mA, usually used as output frequency: 0 V = 0 Hz +10 V = MAX SPEED	- As set by the DIL switch SW2 and ... AOUT 2 TYPE (see page 28.1-8) - 5 or 20 mA max. load - Accuracy ± 3 %
7	AOUT2	Analog output in the range -10...+10 V, 0...+10 V, not used in factory default setting (MACRO 1)	- 5 mA max. load - Accuracy ± 3 %
8	+10 V REF	Internal +10 V reference voltage for analog inputs	- 5 mA max. load - Tolerance approx. ±3 %
9	0 V	Zero voltage reference for analog signals	
10	-10 V REF	Internal +10 V reference voltage for analog inputs	- 5 mA max. load - Tolerance approx. ±3 %
11	+24 VC	+24 V auxiliary supply for digital inputs	- 150 mA max. load together with terminal 24 - Tolerance approx.. ±10 % <u>Not to be connected to an external 24 V supply voltage</u>
12	0V	Reference point for digital inputs	

Terminal	Designation	Signal, function	Explanation
13	DIN1	Configurable digital input, usually used as command "Run", for starting and stopping the drive: 0 V = Stop +24 V = Run	- Stopping as set in RUN STOP MODE (see page 5-7)
14	DIN2	Configurable digital input, usually used to reset trips: 0 V = Normal +24 V = Reset	- Edge triggered
15	DIN3	Configurable digital input, usually used to control the direction of motion: 0 V = Forwards +24 V = Reverse	
16	DIN4	Configurable digital input, usually used for an external monitoring circuit: 0 V = Fault +24 V = No fault	- Connect to +24 V (terminal 6) if not used
17	DIN5	Configurable digital input, usually used to select the jog speed: +24 V = Jog speed 0 V = Normal	
18	DIN6	Configurable digital input, not used in factory default setting (MACRO 1)	- Can be used as further inputs - Used as preset inputs with MACRO 5
19	DIN7	Configurable digital input, not used in factory default setting (MACRO 1)	
20	DIN8	Configurable digital input, not used in factory default setting (MACRO 1)	
21	DOUT1-A	Configurable digital output usually used for "Health":	Isolated relay contact
22	DOUT1-B	Open = No supply, fault or alarm Activated = Health	
23	DOUT2-A	Configurable digital output usually used for "Running":	Isolated relay contact
24	DOUT2-B	Open = No supply, fault or alarm Activated = Running	
25	DOUT3-A	Configurable digital output, not used in factory default setting (MACRO 1)	Isolated relay contact
26	DOUT3-B		
	MOT/ TEMP	Connection for thermistor motor protection	Input in double isolated

Configurable inputs and outputs

MM456 Frequency Inverters use a completely new concept of freely connectable function blocks. The analog and digital outputs can now be connected without restraint to the available internal analog and digital function blocks by means of software. As an example, Fig. 2.4 shows the application functional block diagram with software links corresponding to the default factory set conditions (MACRO 1).

With the inputs and outputs, the range must also set using the DIL switch. Fig. 2.5 shows the switch settings for available ranges of these inputs and outputs. In addition the software must be set accordingly, see page 5-8.

		DIL-Schalterstellung / DIL switch setting			Signalart / Signal type
SW1	1	0 ...+10 V	0...+10 V	0...20 mA	Analoger Eingang AIN1
	2	+2...+10 V	0...+10 V	4...20 mA	Analog input AIN1
	3	0 ...+10 V	0...+10 V	0...20 mA	Analoger Eingang AIN2
	4	+2...+10 V	0...+10 V	4...20 mA	Analog input AIN2
SW2	1	0 ...+10 V	0...+10 V	0...20 mA	Analoger Ausgang AOUT
	2	0 ...+10 V	0...+10 V	4...20 mA	Analog output AOUT
	3	0 ...+10 V			
	4	0 ...+10 V			
		frei free			

Fig. 2.5: DIL switch setting for analog inputs (AIN1, AIN2) and analog output (AOUT1)

With MM6 Frequency Inverters switch SW2 is to the right of switch SW1.

Chapter 3 - MOUNTING AND INSTALLATION

	Page
PRECAUTIONS	3-2
EQUIPMENT INSPECTION	3-2
MOUNTING	3-2
OUTLINE AND MOUNTINGDRAWINGS.....	3-3
INSTALLATION.....	3-5
Using screwless cage-clamp terminals.....	3-5
Gland for screened motor cable.....	3-6
Power wiring.....	3-7
Overload and short-circuit protection.....	3-7
Earthing	3-8
Control wiring.....	3-8
EMC INSTALLATION INSTRUCTIONS	3-9
Introduction	3-9
EMC filters to reduce line-conducted noise.....	3-9
Interaction and safety considerations with earth-fault monitoring systems.....	3-12
Minimising radiated emission.....	3-12
Screening and earthing when mounted in an enclosure	3-13
Screening and earthing when mounted	3-15
Motor cable-length limitations.....	3-17
Other layout considerations	3-17

PRECAUTIONS



CAUTION!

This product conforms to IP20 protection. Due consideration should be given to environmental conditions of installation for safe and reliable operation.

- ◆ The installation and commissioning of the MM456 Frequency Inverter is carried out only by competent personnel in accordance with safe working practices
- ◆ The enclosure into which the MM456 Frequency Inverter is mounted must be suitable for the working environment
- ◆ Use of mechanically secure fixings as recommended in the following
- ◆ The cooling and airflow are as recommended in the following outline and mounting drawings
- ◆ The cables and wire terminations are as recommended and securely clamped. The power connections should be tightened to the recommended torque.

EQUIPMENT INSPECTION

Check the following before mounting or storing the MM456 Frequency Inverter:

- Signs of transit damage
- The type code and ratings on the name plate conform to the requirement (refer to **Chapter 2 - PRODUCT OVERVIEW** for more information).

If the unit is not being installed immediately, store the unit in a well-ventilated place away from high temperatures, humidity, dust, or metal particles.

Refer to **Chapter 7 - SERVICING** for information on returning damaged equipment.

MOUNTING

MM456 Frequency Inverters should be mounted vertically on a flat vertical surface with 4 suitable screws. With MM407 and MM415 the two lower fixing holes are accessible after removing the terminal cover plate. The overall dimensions of the MM456 Frequency Inverter and the positions of the fixing points are given in Figure 3.1 (page 3-3).

MM456 Frequency Inverters must be mounted to allow the free flow of air vertically through the inverter. Care should also be taken to ensure that the mounting surface is cool and that any heat generated by adjacent equipment is not transmitted to the MM456 Frequency Inverter.

For adequate natural ventilation of the MM456 Frequency Inverter, minimum clearance for cooling as defined in Fig. 3.1, must be maintained. Side-by-side mounting of two or more MM456 Frequency Inverters or other power electronic equipment is permissible provided the vertical clearance for cooling with each Frequency Inverter is adhered to and the ambient operating temperature is not exceeded (page 1-6).

OUTLINE AND MOUNTING DRAWINGS




Fig 3.1a: Outline drawing and mounting MM407/415-EMC




Fig. 3.1b: Outline drawing and mounting MM422-EMC und MM515...540-EMC





Fig. 3.1c: Outline drawing and mounting MM655...6110

INSTALLATION

Using screwless cage-clamp terminals

- ◆ Prepare wire ends:
 - strip to 5...6 mm
 - ferrules are not required but can be used
- ◆ Insert a flat-bladed (size 3.5 mm max.) inside the smaller hole of the cage-clamp terminal
- ◆ Lever screwdriver keeping it firmly pressed into the hole. The cage will open
- ◆ Insert wire into cage keeping the screwdriver in position
- ◆ Remove screwdriver. The terminal will now provide the correct clamping force for a secure connection.




Fig. 3.2a: MotorMaster MM45
Wiring with instruction for using screwless cage-clamp terminals
and for connection of protective earth and screening of motor cables




Fig. 3.2b: MotorMaster MM6
Wiring with instruction for using screwless cage-clamp terminals
and for connection of protective earth and screening of motor cables

Gland for screened motor cable

A special cable gland with good EMC properties for screened motor cables is available as OPTION MM-MOT-GLAND, see page 9-2.

Power wiring



CAUTION!

Never perform high-voltage insulation measurements on the wiring without first disconnecting the MM456 Frequency Inverter from the circuit being tested.

All relevant national standards and local electricity board regulations must be observed at the installation. Power cables must have a minimum rating of 1.1 x full load current. Power cables (particularly 3-phase motor cables) must be routed well away from cables carrying setpoints or feedback signals, screened motor feedback cables, and cables from other electronic equipment in the same plant.

The single-phase or three-phase main power supply should be within the voltage tolerances specified in **Chapter 1, POWER CIRCUIT** (page 1-6). Connect the voltage supply to terminals (L1, L2/N or L1, L2 and L3). The protective earth must be connected to the protective earth connections of the inverter.

Refer to page 3-7 and following and also to **Chapter 7, EMC, THE 'CE'-MARK, UL, CSA** for information on EMC wiring requirements.

Overload and short-circuit protection

The incoming voltage supply and cable to the motor should be wired and protected to the appropriate regulations such as are shown in the following table in accordance with the European regulations:

MM456 Frequency Inverter	Operation	Power cable			Motor cable	
		Supply fuse ¹⁾ / Circuit breaker ²⁾	Size of power cable	Type of installation	Size of power cable	Type of installation
MM407-EMC	QT	10 A	1 mm ²	B1, C, E	1 mm ²	B1, B2, C, E
	HVAC		1.5 mm ²	B2		
MM415-EMC	QT	20 A	2.5 mm ²	C, E	1 mm ²	B1, B2, C, E
	HVAC		4 mm ²	B1, B2		
MM422-EMC	QT	25 A	4 mm ²	B1, C, E	1 mm ²	C, E
	HVAC		6 mm ²	B2	1.5 mm ²	B1, B2
MM515-EMC	QT	10 A	1 mm ²	B1, C, E	1 mm ²	B1, B2, C, E
	HVAC		1.5 mm ²	B2		
MM522-EMC	QT	10 A	1 mm ²	B1, C, E	1 mm ²	B1, B2, C, E
	HVAC		1.5 mm ²	B2		
MM540-EMC	QT	16 A	1.5 mm ²	E	1 mm ²	C, E
	HVAC		2.5 mm ²	B1, B2, C	1.5 mm ²	B1, B2
MM655	QT	20 A	2.5 mm ²	C, E	1.5 mm ²	B1, C, E
	HVAC		4 mm ²	B1, B2	2.5 mm ²	B2
MM675		QT	25 A	4 mm ²	B1, C, E	2.5 mm ²
	HVAC	6 mm ²		B2	4 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²
	HVAC	10 mm ²		B2	6 mm ²	B2
MM6110		QT	32 A	6 mm ²	B1, C, E	4 mm ²

The listed cable sizes are taken from "Electrical equipment of machines", EN 60204-1 for continuous operation in air up to 40 °C ambient temperature and are valid in accordance with the indicated type of installation as defined in the following:

- B1 Round conduit or rectangular cable channel trunking with three separate single-core current-carrying conductors
- B2 Round conduit or rectangular cable channel trunking with three current-carrying conductors in a single or multi-core cable
- C Wall mount of three current-carrying conductors (single or multi core)
- E Free-air mount e.g. on cable bridges (single or multi core)

Other ambient temperatures, methods of installation, customer, national or supply-company regulations may require other cable sizes. It is the installers whole responsibility to verify in all cases.

NOTE: For compliance with UL standards other requirements may apply, refer to **Special considerations for compliance with UL** (see page 1-11).

Earthing



WARNING !

The motor must be connected to an appropriate protective earth. Failure to do so constitutes a potentially lethal electrical shock hazard.

All Frequency Inverters must be permanently earthed. In accordance with the European LOW-VOLTAGE DIRECTIVE as in EN50178 permanent earthing requires either:

1. The cross section of the protective conductor should be at least 10 mm² (copper). This minimum cross section was determined with regard to mechanical strength.
2. Laying of a second protective earth conductor through separate terminals and electrically parallel to the protective conductor, see Fig. 3.2 on page 3-5. Each protective earth conductor shall individually satisfy the requirements for a protective earth conductor (note this ensures the equipment is still protectively earthed if one conductor is damaged).

Control wiring

A general wiring diagram for the MM456 Inverter is provided as Fig. 2.1 on page 2-4.

For normal speed control operation, the speed demand signals are connected to the analog input AIN1 referenced to 0 V. The maximum speed, and other associated parameters, are set from the programming pad.

The command "Run" is provided by connecting a DC 24 V control voltage e.g. single holding contact between DIN1 (Run) and +24V - close contact to run, open to stop. The other inputs are to be connected as described in Chapter 2.

A control output "Health" is available at output DOUT1. This output is normally "high". Any trip which causes the healthy output to deactivate is internally latched by the MM456 Frequency Inverter and the cause of the trip displayed on the LCD display of the programming pad. Once latched, such an alarm can be cleared only by removing and re-applying the supply voltage to the drive by removing and reapplying the Run input DIN1, or removing and reapplying a Reset signal to DIN2.

A further output "Running" is available as DOUT2.

The function of all inputs and outputs may change if the configuration of the software is altered.

0.2...0.75 mm² (18 AWG) wire should be used for control cables. It is recommended that screened cable be used, with the screen connected at the MM456 Frequency Inverter end. In some installation it may be necessary to connect the screen of digital control inputs at both ends. Control wiring should be kept separate from power cables.

EMC INSTALLATION INSTRUCTIONS

Introduction

This section provides installation guidelines for MM456 Frequency Inverters and drive systems to maximise their 'Electro Magnetic Compatibility' (EMC) in their intended operating environment.

All installers must read this section and apply the advice which is relevant to their application.

Pass on this information to others as is appropriate.

All inverter-fed drive systems have the potential to produce electrical emissions, both radiated and conducted back into the AC supply. This is due to the inherent operation of all drives by switching large voltages and currents rapidly in order to control the motor. Because the drives internal controlling electronics operates continuously in very close proximity to electrically-noisy power-switching components, MM456 Frequency Inverters are inherently immune to most external sources of electrical noise.

Great care has been taken in the selection of suitable EMC filters for the voltage supply to provide the correct level of interface suppression, ease of installation and to ensure that electrical safety is not compromised.

MM6 Frequency Inverters require an external EMC filter. Use the specified EMC filters only to ensure that the required EMC performance is achieved.

The EMC performance can only be guaranteed to be within the limits specified when the MM456 Frequency Inverters are installed together with the EMC filters in accordance with the following installation instructions.

The subject of EMC is explored in more detail in a separate Application Note entitled "EMC Does and Don'ts", available from your supplier. Also a Product Information PI-LKTM-005 describing the requirements of the EMC DIRECTIVE of the EU is available.

EMC filters to reduce line-conducted noise

MM45 Frequency Inverters have integrated EMC filters to reduce mains-borne interference. The installation requirements to meet interference suppression level B and the Thermal Limitations are described in the following table.

The external EMC filter required by MM6 Frequency Inverters should be mounted as close to the inverter as possible. The connection between the MM6 Frequency Inverter and the EMC filter must always be as short as possible taking care not to obstruct any ventilation openings and **be segregated from all other cables**. If this cable exceeds 0.3 m in length then a screened/armoured cable, with the screen/armour earthed at both the filter and inverter ends with large-area contact surfaces (preferably with metal cable glands) must be used. The connection between MM456 Frequency Inverter and the motor must be installed away from other cables or wires and be

preferably also be screened. Ideally the filter will be mounted onto the same metallic panel as the drive. The RF connection between the inverter and filter and panel should be enhanced as follows:

- Galvanized mounting panels should be preferably used otherwise remove any paint/insulation between the mounting points of the EMC filter, MM456 Frequency Inverter and panel
- Liberally apply petroleum jelly over the mounting points and securing threads to prevent corrosion. Alternatively conducting paint could be used on mounting panels.
- If the proceeding is not possible then the RF earth bond between the EMC filter and MM456 Frequency Inverter is usefully improved by making an additional RF earth connection using wire braid of at least 10 mm² cross sectional area (due to skin effect).

Care should be taken to ensure that the protective earth conductor exiting from the filter is connected to the protective earth conditions of the MM456 Frequency Inverter. Any additional RF earth such as a cable screen **is not a protective earth**.

EMC filter must be **permanently connected to a protective earth** to prevent the risk of electric shock under abnormal operating instances (such as the loss of one phase of the AC supply).. Permanent earthing can be achieved installing a second conductor in parallel connection with the first protective conductor to separate protective earth terminals. Each conductor shall on its own meet the requirements for a protective earth conductor.

NOTE: Metal surfaces such as eloxized or yellow chromed e.g. with cable mounting or 35 mm DIN rails, screws and bolts have a high RF impedance which can be very detrimental for EMC performance.

On some specific customer sites the supply may not be balanced with respect to earth (non-earth referenced supplies). The earth leakage currents would increase and interfere with the operation of any earth-fault monitoring equipment on such installations. In addition the EMC performance of the filter would be degraded. For these reasons **the MM456 Frequency Inverter must not be used on none earth-referenced supplies**.

With all frequency inverters conducted and radiated interference increases with the inverter switching frequency. The emissions can therefore be reduced by selecting the lowest acceptable switching frequency which also reduces the losses in the EMC filter.

As with all power electronic drives the conducted emissions increase with motor cable length. The following relationship between switching frequency, cable length to motor, and thermal limitation of EMC filter losses should be considered.

Product Code	EMC-Filter Type	int./ext.	Switching frequency	Permissible maximum length of screened cable	
				In erference su ppression to limit B	Ther nal limitation of EMC filter
MM407-EMC		integrated	3 kHz	25 m	25 m
			6 kHz	25 m	25 m
			9 kHz	5 m	25 m
MM415-EMC		integrated	3 kHz	25 m	25 m
			6 kHz	25 m	25 m
			9 kHz	5 m	25 m
MM422-EMC		integrated	3 kHz	50 m	50 m
			6 kHz	50 m	50 m
			9 kHz	5 m	50 m

Product Code	EMC-Filter Type	int./ext.	Switching frequency	Permissible maximum length l of screened cable	
				In erference su ppression to limit B	Ther nal limitation of EMC filter
MM515-EMC		integrated	3 kHz	50 m	50 m
			6 kHz	50 m	50 m
			9 kHz	1 m	50 m
MM522-EMC		integrated	3 kHz	50 m	50 m
			6 kHz	50 m	50 m
			9 kHz	1 m	50 m
MM540-EMC		integrated	3 kHz	50 m	50 m
			6 kHz	50 m	50 m
			9 kHz	1 m	50 m
MM655			3 kHz		
			6 kHz		
			9 kHz		
MM675			3 kHz		
			6 kHz		
			9 kHz		
MM6110			3 kHz		
			6 kHz		
			9 kHz		

If one EMC filter is to be used in a metal enclosure for several MM456 or other frequency inverters, then this filters should be mounted as close to the incoming AC supply to the enclosure as possible.



IMPORTANT WARNINGS !

- MM456 Frequency Inverters with integrated or external EMC filters are only suitable for use with TT/TN voltage supplies with an to earthed neutral. The use with isolated supply systems (IT systems) is not permissible.
- The EMC filters contain capacitors phase-to-phase and phase-to-earth. Discharge resistors are fitted, but the filters, terminals and wiring must not be touched for a period of 3 min after the removal of the AC supply.
Not adhering to this warning can result in potentially lethal electric shock.
- The MM456 Frequency Inverter must only be used with a **permanent protective earth** connection making use of a second conductor in parallel with the protective conductor to a separate protective earth terminal on the MM456 Frequency Inverter. The conductor on its own shall meet the requirements for a protective earth conductor.
- Thermal performance of the EMC filter is influenced by switching frequency and cable length. Take note of limits summarized in the table above.
- Give important consideration to the following section regarding safety considerations when using earth-fault detection systems.

Interaction and safety considerations with earth-fault monitoring systems

Due to the internal phase-to-earth capacitors in the EMC filter, on initial connection of the supply voltage a pulse of current will flow in the earth. This has been minimised in the recommended EMC filters, but may still trip out any RCD (Residual Current Detector) in the earth system. In addition high frequency and DC components of earth leakage currents will flow under normal operating conditions.. Under certain fault conditions, larger DC protective earth currents may flow. The protective function of some RCDs cannot be guaranteed under such operating conditions. For these reasons the manufacturer does not recommend the use of RCDs, but where their use is mandatory, they should be capable of correct operation with DC and AC protective earth currents (e.g. type B RCDs as in amendment 2 of IEC755) and preferably have adjustable trip amplitude and time characteristics, to prevent tripping on initial power connection.

RCDs used with MM456 Frequency Inverters and other similar equipment are **not suitable for personnel protection**. Another means of providing personal safety must be provided for, see EN50178.

Minimising radiated emission

All MM456 Frequency Inverters will comply with the most stringent radiated emission limits of EN55011 Class B by mounting inside an enclosure with 10 dB attenuation between 30 and 100 MHz (which would typically be the attenuation provided by a metal enclosure with no aperture greater than 0.15 m) and screening any control and signal cabling outside of the enclosure in addition to the motor cables. The control and signal cables, if screened should be terminated at the entrance to the metal enclosure.

Inside the enclosure the radiated magnetic and electric fields will be high, due to proximity, and any components fitted inside the cubicle must be sufficiently immune. Remember that the EN55011 radiated emission measurements are made between 30 MHz and 1 GHz in the far field, at a distance of between 10 m and 30 m. No limits are specified lower than 30 MHz, or in close proximity. Emissions from individual components tend to be additive.

The cable between the enclosure and the motor must be screened or armoured and also contain the motor protective earth connection. When using screened cable only use high quality cable with a copper screen with a covering factor of at least 85 %. The screen/armour must be earthed at both ends by connecting it to both the entrance to the enclosure (or gland box for wallmount), and to the motor frame ideally in 360° termination's via cable glands (to meet the most stringent emission requirements). Screen-to-earth connections via 360° bonding is 75 % more effective than earthing via pigtailed from the screen.

Some motor terminal boxes and conduit glands are made of plastic, if this is the case then copper braid must be connected between the screen and the motor frame. This also applies to metal terminal boxes which are insulated from the frame with a gasket or paint.

At the enclosure end often the screens are terminated on a special power-screen rail at the entrance to the enclosure. The integrity of the screen must be maintained over the entire length of the cable between the enclosure and motor. If the cable is interrupted to insert terminals, contactors, chokes, fuses etc., then the screen must be connected over the shortest possible distance with a suitable connection with a good H.F. characteristic.

Note that some hazardous area installations may preclude direct earthing at both ends of the screen, in this case earth the none direct end via a 1 μF , 50 VAC capacitor.

If a shielded cable is not available, lay unshielded motor cables in a metal conduit which will act as a shield. The conduit must be continuous with a direct electrical contact to the drive module and motor housing. If links are necessary, use braid with a minimum cross sectional area of 10 mm^2 .



Safety earthing considerations always takes precedence over EMC earthing


The use of screened cable to the motor without an EMC filter in the voltage supply is not recommended, as line-conducted interference will increase substantially and the capacitive coupling of the output cable to earth will result in high earth-leakage currents.

To ensure the correct operation of the MM456 Frequency Inverter, some control and signal cables such as for a tacho, encoders or serial interface have to be screened back to the inverter terminals. The screen integrity must be continuous right back to the MM456 Frequency Inverter. Always minimise the length of screen stripped back to make this connection. The screen should only be connected at the MM456 Frequency Inverter. If high frequency noise is still a problem, earth at the non drive end via a 0,1 μF capacitor.

Screening and earthing when mounted in an enclosure

Make sure the requirements of EN60204-1 are adhered to with electrical equipment for machines. Satisfactory EMC performance is only achievable when the MM456 Frequency Inverter with associated equipment is mounted on a conducting metal mounting panel. Beware of constructions using insulating mounting panels or for EMC undefined mounting structures.

A single-point earthing strategy should be followed for a single MM456 Frequency Inverter mounted in an enclosure. Fig. 3-2a shows a typical arrangement of single-point earthing of screens and earth connections. The protective earth connection (PE) to the motor must run inside the screened cable between the motor and the inverter where it is to be connected to the protective-earth terminal of the inverter. In accordance with EN60204-1, only one protective earth conductor is permitted at each earth terminal. Local wiring regulations may require the protective-earth connection of the motor to be connected locally but this will not cause earth-loop problems due to the relatively high RF impedance of the local earth connection.



a 0.25 m spacing from "EMC hot area" to adjoining equipment, especially important with field-sensitive equipment (see page 3-12)

b Contact areas between metallic mounting panel and PE earthing bar, screens etc. to be free of paint and prepared as described on page 3-9/10

e Cable screen clamped to contact area on mounting panel

P Protective-earth cables:
2 separate parallel earth cables each to wiring regulations

H EMC hot area:
Avoid installing sensitive equipment in this area

Fig. 3.3: Screening and earthing when a MM456 Frequency Inverter is mounted in an enclosure

When more than one piece of electrical equipment is fitted inside an enclosure, care must be taken to ensure that noise flowing in the earth connections does not couple into other equipment. A star-point earthing policy separating noisy from quiet earths is highly recommended. Five separate earth branches should be provided for:

1. Clean earth bus bar (CEBB) The Clean earth bus bar used as a reference point for all signal and control cabling. This may be further subdivided into an analogue and a digital reference busbar, each separately connected to the star earthing point. The digital reference is also used for any 24 V controls.
2. Dirty earth bus bar (DEBB) The dirty earth busbar is provided for the earth connection to MM456 Frequency Inverters and other power electronic equipment (i.e. protective earth connections).
3. Enclosure metalwork bus bar (EMBB) The enclosure metalwork bus bar is used for connecting all parts of the enclosure including panels, doors and the back plate. It is also used as a reference for any 110 or 220 V control used and for the control transformer screen.

- 4. Power screen bus bar (PSBB) The power screen bus bar is only for the connection of screens of power cables which **do not** have to go directly to the MM456 Frequency Inverter (such as motor cables, braking choppers and their resistors) or to other drive modules (refer to appropriate Product Manual to identify these). Noise coupled onto the incoming screens must flow to earth directly so as not to contaminate the rest of the enclosure. Hence the power screen busbar should be placed as close to the point of cable entry as possible.
- 5. Signal/control screen bus bar (SCBB) The signal/control screen bus bar is to be used for external signal/control screened cables which do not have to go directly to the MM456 Frequency Inverter. This bus bar should also be placed as close as to the point of cable entry as possible.

For optimum EMC, copper rails with a substantial cross-section should be used for the bus bars. Screened cables are best 'u' clamped (remove any plastic spacers) to ensure an optimum HF connection.

The five separate earth bus bars should be isolated from the mounting panel and connected to a central earth busbar (star point) near the PE or PEN terminal of the main supply. Flexible large cross-section cable with short lengths to ensure a low HF impedance should be used. The arrangement of the bus bars should be such that the connection to the single earth point are as short as possible.

Fig. 3.4 shows an implementation of a star-point earthing policy described above.




Fig. 3.4: Implementation of star-point earthing policy for multi-drive installation

Screening and earthing when wall mounted

To provide for good EMC performance the recommended matching EMC filter must be fitted and the cables between the wall-mount MM456 Frequency Inverter and the motor screened or armoured. With the underfloor EMC filters a specially-designed pressed-steel conduit for the cables between the EMC filter and the MM456 Frequency Inverter is supplied with the gland box. Also screening of control and signal cables may be required. Refer to **Minimising radiated emission** (page 3-9). In addition any connections to the DC link must also be screened, with the screen connected at both ends (e.g. also to the protective earth protection of an external braking chopper).

All MM456 Frequency Inverters comply with the radiated emission limits of EN55011 (1991) Class A when wall mounted to these instructions, using the recommended matching underfloor EMC filters and screened motor, control and signal cabling. Compliance with the more stringent limits of Class B can be achieved by mounting inside an enclosure with 10 dB attenuation between 30 and 100 MHz (which would typically be the attenuation provided by a standard metal cabinet with no aperture greater than 0.15 m). Minimise the length of unshielded cable inside the cubicle to prevent increased radiated emission.

A single-point earthing policy such as that using the provided earthing terminals to the MM456 Frequency Inverter and underfloor EMC filter as shown in Fig. 3.5 should be used.

The protective earth connection to the motor must run inside the screened cable between the motor and MM456 Frequency Inverter where it is to be connected to the protective earth terminal in the gland box or on the inverter. Note that in accordance with EN60204-1 only one protective earth conductor is permitted at each earth terminal. Local wiring regulations may require the protective-earth connection of the motor to be connected locally but this will not cause shielding problems due to relatively high RF impedance of the local earth connection.

The EMC filter must be permanently protective earthed in accordance with recommendations and warnings in **EMC filters to reduce line-conducted noise**, page 3-9/10. Usually two separate earth connections are required with underfloor EMC filters.




Fig. 3.5: Screening and earthing when a MM456 Frequency Inverter is wall mounted

Motor cable-length limitations

Screened/armoured cable has significant capacitance between the conductors and the screen which increases linearly with cable length. Typically this is 200 pF per metre but this will vary with cable type and current rating. Long cable lengths may have the following undesirable effects:

- Tripping on "over current" as the cable capacitance is charged and discharged at the switching frequency.
- Producing increased conducted emissions which degrade the performance of the EMC filter due to saturation. EMC compliance is only guaranteed up to the cable lengths shown in the table on page 3-10/11.
- Causes RCDs (Residential Current Detection) to trip out due to increased high frequency earth current.
- Cause excessive thermal losses in the EMC filter. The table on page 3-10/11 summarises cable length limitations due to thermal considerations.

These effects can be overcome by adding motor chokes at the output of the MM456 Frequency Inverter. In applications where multiple motors are connected to a single MM456 Frequency Inverter, minimise the length of screened/armoured cable connected to the MM456 Frequency Inverter by using a single length of cable to a star junction point, from where all the other motor cables are attached. Maintain the integrity of the shield. If the cable is interrupted (e.g. to insert terminals, contactors or other components), the screen must be connected over the shortest possible route with a suitable connection with a good H.F. characteristic. The section **POWER RELATED COMPONENTS**, page 9-2, gives information on the recommended motor chokes for use with long cables, cables connected in parallel, or when EMC output filters are used with cables longer than those specified for EMC compliance.

Output filters can also be used to achieve EMC and filter thermal conformance with longer cable lengths than specified. These output (motor) filters also ensure a long motor life by reducing the high dV/dt and over voltage stresses applied to the motor windings by inverters. These filters should be mounted as close to the MM456 Frequency Inverter as possible. Refer to your supplier for advice in the selection of suitable filters.

Other layout considerations

The proximity between the source and victim circuit has a large effect on radiated coupling. The electromagnetic fields produced by inverters fall off rapidly with distance from the cabling/enclosure. It should be remembered that the radiated fields from EMC compliant drive systems are measured at least 10m from the equipment over the frequency band 30 to 1000 MHz (as required by EN55011, referenced by the generics and the drive product specific standard). Any equipment placed closer to the drive system than this will see larger magnitude fields, particularly very close to the drive. No magnetic/electric field sensitive equipment should be placed within 0.25 m of the following parts of a drive system using power electronics:

- EMC supply filters
- Output (motor) filters
- Input or output chokes/transformers
- Cable between MM456 Frequency Inverter and Motor (even when screened/armoured)
- Connections to external braking chopper and resistor (even when screened/armoured)
- C/DC brushed motors (and to their cooling fans)
- DC link connections (even when screened/armoured)
- Relays and contactors (even if they are suppressed)

Often the coupling between electrically 'noisy' and 'sensitive' cables is a problem. This can be minimised by separating parallel runs by at least 0.25m, and minimising the length of parallel runs. For long parallel runs (>10 m) the separation should be increased proportionally. For example if the parallel runs were 50 m then the separation would be $(50/10) \times 0.25 \text{ m} = 1.25 \text{ m}$.

In addition the coupling between two cables which must cross is minimised if they cross over at 90°. Hence sensitive cables should cross the cables to the motor at 90°, and should never be run close to them or in parallel for any great length.

Never run supply, DC link or motor cables in the same bundle as the signal/control and feedback cables, even if they are screened.

From experience the following equipment is defined as particularly sensitive and care must be taken in the installation:

- Any transducers which produce low level analogue outputs (<1 volt) e.g. load cells, strain gauges, torque measuring devices, thermocouples, thermistor temperature transducers, piezoelectric transducers, anometers, LVDT's
- A.M. radios (long and medium wave only)
- Video cameras and closed circuit TV
- Personal computers
- Capacitive devices such as proximity sensors and level transducers
- Mains borne communication systems
- Equipment not suitable for operation in the intended EMC environment i.e. with insufficient immunity to new EMC standards

Chapter 4 - SETTING-UP AND COMMISSIONING

	Page
PROGRAMMING PAD.....	4-2
Introduction	4-2
LCD plain-language display	4-3
Function keys for programming the drive.....	4-4
Function keys for LOCAL control mode.....	4-4
Indicating LEDs.....	4-6
Menu Structure	4-6
IMPORTANT OPERATIONS WITH THE PROGRAMMING PAD	4-7
Changing the language of the Programming Pad.....	4-7
User reset to factory default values.....	4-7
Displaying and changing parameters	4-8
Saving parameters in the MM456/MM3SV Frequency Inverter	4-8
Storing parameters in the programming pad.....	4-8
Loading parameters from the programming pad.....	4-8
Loading preset configuration.....	4-8
SETTING-UP	
First-time check of electrical system.....	4-9
Safety considerations	4-9
Setting up the drive before energizing.....	4-9
Energizing the drive.....	4-11

NOTE: The setting-up and commissioning of MM6 Frequency Inverters is almost identical to that with MM3SV range. Reference is therefore made to both MM6 and MM3SV Frequency Inverters in this chapter.

PROGRAMMING PAD

Introduction

Every MM456/MM3SV inverter is fitted with a cover plate as standard, see Fig. 1.1, page 1-3. This enables the inverter to be used for applications without any special requirements, e.g. operation with an external set-value for speed.

With many requirements it is advantageous to replace the cover plate with the optional removeable programming pad (Fig. 1.1). The programming pad consists of an illuminated 2x16 character plain-language Liquid Cristal Display (LCD), 10 function keys and 7 status LEDs. This enables simple programming and diagnostics as well as local control of the inverter.




Fig. 4.1: Programming pad OPTION MM-PROG (Option)

The programming pad may be mounted external to the MM456/MM3SV inverter. A panel mount kit with a 3 m cable is available as an OPTION-PROG-PM, see page 9-9.

Since the setting up and commissioning procedures rely on the use of the programming pad, its operation is described in the following. Users familiar with the programming pad may proceed directly to **SETTING-UP ENERGIZING THE DRIVE**, page 4-10).

LCD plain-language display

The LCD plain-language display shows information on the various menus and parameters. The following types of display are provided for:

- a:

AC MOTOR DRIVE 4.0 kW 400V 5. X

 — Power-up screen with rated data
(software version lower right)
- b:

QUICK SETUP menu at level 2

 — Typical menu of the menu level 2
- c:

MAX SPEED 50.0 Hz

 — Adjustable parameters. Factory default settings which depend on the rated inverter power are indicated in this manual as XX...
- d:

MAX SPEED → 50.0 Hz

 — "Modify parameters" mode
- e:

RUN FWD ← FALSE

 — Adjustable parameters which are software linked and therefore in this condition not adjustable
- f:

SPEED DEMAND = 0.0 %

 — Parameters corresponding to measured values. These are indicated in this manual by YY...
- g:

*** TRIPPED *** EXTERNAL FAULT

 — Fault message

The type faces **OPERATOR**, **DIAGNOSTICS** or **FUNCTION BLOCKS** indicate displays on the programming pad. The type face used indicates the View Level as follows:


	<table border="1" style="display: inline-table;"><tr><td>OPERATOR MENU menu at level 1</td></tr></table>	OPERATOR MENU menu at level 1	<table border="1" style="display: inline-table;"><tr><td>DIAGNOSTICS menu at level 1</td></tr></table>	DIAGNOSTICS menu at level 1	<table border="1" style="display: inline-table;"><tr><td>FUNCTION BLOCKS menu at level 2</td></tr></table>	FUNCTION BLOCKS menu at level 2
OPERATOR MENU menu at level 1						
DIAGNOSTICS menu at level 1						
FUNCTION BLOCKS menu at level 2						
View Level: (see page 5-12)	OPERATOR	BASIC	ADVANCED			

Function keys for programming the MM456/MM3SV

The following five function keys allow the user to move around the menu structure on the display and alter parameters:



MENU

This Menu key selects the next lower menu or function. If an adjustable menu has already been selected (example c, page 4-3), then pressing  again will select the alternative mode (example d, page 4-3).



ESCAPE

The ESCAPE key allows the user to revert to the preceding menu level or leave the parameter modification mode.

Also any displayed trip message will disappear on pressing this key. However the latched trip itself will not be reset, see  key.



UP

The UP key provides forward movement to explore the options available in the selected menu level. If a menu is already in the alternative mode (example d), then the present value can be decreased.



DOWN

The DOWN key provides backward movement to explore the options available in the selected menu level. If a menu is already in the alternative mode (example d), then the present value can be increased.



PROGRAMMING

This key has the functions as follows:

- toggles between the last position in the **OPERATOR** menu and the last position in the other menus.
- provides simple direct means of saving parameters by pressing for at least 2 s. There is no need to climb up and down the menu tree when testing or saving parameter settings, see page 4-9.
- when is **VIEW LEVEL | BASIC** enables **VIEW LEVEL** to be selected and changed, see page 5-12.

Function keys for manual operation (LOCAL mode)



The following 5 function keys allow the user to manually control the drive in LOCAL mode. These keys (apart from STOP/RESET) are only active when the drive is in LOCAL mode.



LOCAL

This key will toggle between the normal operating mode and the LOCAL control mode. This can only happen when the drive is stopped. The LEDs LOCAL (SEQ and/or REF) illuminated when LOCAL is selected. The menu **OPERATOR | SETPOINT (LOCAL)** is automatically selected as follows:

SETPOINT LOCAL
→ 0.0 %

Control function is now with the programming pad using the four following keys and  and .



FORWARD/REVERSE


This key will change the direction of motor rotation. The LEDs FWD (forwards) and REV (reverse) indicate the direction of rotation.



JOG

This key selects the JOG mode following selection of LOCAL mode. The menu **OPERATOR | JOG DMD (LOCAL)** is automatically selected:

JOG DMD (LOCAL)
= 10.0 %

With the  key the direction of rotation can be selected. This function is only active while the key is depressed. On releasing the drive will revert to a stopped condition.



(green)

RUN

This key will start the MM456/MM3SV Frequency Inverter in a similar manner to placing 24 V on terminal DIN1. In addition any latched trip messages will be reset if no longer active.




(red)

STOP/RESET

This key will stop the MM456/MM3SV Frequency Inverter when in LOCAL mode in a similar manner to removing the 24 V from input DIN1.

In addition any latched trip messages and trips will be reset if no longer active.

Indicating LEDs



⊗ HEALTH	⊗ RUN	Zustand	Condition
		In Betrieb mit Sollwert = 0%	Running with zero reference
		In Betrieb	Running
		Anhalten	Stopping
	Wie oben, as above	Bremschopper aktiv	Braking chopper in operation
		Gestoppt	Stopped
		Automatisches Wiedereinschalten	Auto restarting
		Störung	Tripped
		Neu-Konfigurieren oder NVRAM fehlerhaft beim Einschalten	Re-configuration or corrupted non-volatile memory power-up



⊗ HEALTH	⊗ RUN	⊗ STOP	Zustand	Condition
			In Betrieb mit Sollwert = 0%	Running with zero reference
			In Betrieb	Running
			Anhalten	Stopping
			Gestoppt	Stopped
			Autotune	Autotuning
			Störung	Tripped
			Neu-Konfigurieren oder NVRAM fehlerhaft beim Einschalten	Re-configuration or corrupted non-volatile memory power-up

⊗ FWD	⊗ REV	Richtung	Direction
		Gewünschte und aktuelle Richtung sind vorwärts	Requested direction and actual direction are forward
		Gewünschte Richtung ist vorwärts aktuelle Richtung ist rückwärts	Requested direction is forward but actual direction is reverse
		Gewünschte und aktuelle Richtung sind rückwärts	Requested direction and actual direction are reverse
		Gewünschte Richtung ist rückwärts aktuelle Richtung ist vorwärts	Requested direction is reverse but actual direction is forward

⊗ LOCAL SEQ	⊗ LOCAL REF	LOKAL/Normal (Fernsollwert)	LOCAL/Normal (Remote)
		Steuerbefehle: Klemmen Sollwert: Klemmen	Commands: Terminals Set-value: Terminals
		Steuerbefehle: Klemmen Sollwert: ▲ bzw. ▼	Commands: Terminals Set-value: ▲ and ▼
		Steuerbefehle: 1 0 JOC 0 Sollwert: Klemmen	Commands: 1 0 JOC 0 Set-value: Terminals
		Steuerbefehle: 1 0 JOC 0 Sollwert: ▲ bzw. ▼	Commands: 1 0 JOC 0 Set-value: ▲ and ▼

Fig. 4.2: Explanation of the indicating LEDs with Blank cover and Programming Pad


Menu structure




Refer to last fold-out side of this Product Manual.


IMPORTANT OPERATIONS WITH THE PROGRAMMING PAD

Changing the language of the Programming Pad

A change in language can be set as follows:




1. Remove supply voltage to MM456/MM3SV Frequency Inverter (see page 4-3) and wait until LCD display is dark.
2. Reapply power with keys  depressed until the following screen is displayed:




LANGUAGE	ENGLISH
----------	---------
3. Press  key to select "Modify parameters" mode.
4. Select desired language with the keys  and :


DEUTSCH
ENGLISH
ESPAÑOL
FRANÇAIS
5. Press key .
6. To ensure that the set language is retained on power down, use the save parameter function, see page 4-9/5-14.

If the factory default setting (MACRO 1) is selected, then the display will revert to the language of the factory default setting (see PRODUCT/COUNTRY in the following).

When MM456/MM3SV Frequency Inverters are exported to other countries it may be useful to modify the language and basic operating frequency of the factory default setting (MACRO 1). An example of this is with the American continent where English/60 Hz is usually required. This change can be accomplished as follows:

1. Remove supply voltage to MM456/MM3SV Frequency Inverter and wait until LCD display (see page 4-3) is dark.
2. Reapply power with keys ,  and  depressed until the following screen is displayed:

PRODUCT/COUNTRY	
GERMAN	50Hz
3. Press  key to select "Modify parameters" mode.
4. Select desired language with the keys  and :

GERMAN	50Hz
ENGLISH	60Hz
ENGLISH	50Hz
P LANGUAGE	60Hz
P LANGUAGE	50Hz
SPANISH	50Hz
FRENCH	50Hz
5. Press key  for 2 s to store change.

User reset to factory default settings

1. Remove supply voltage from MM456/MM3SV Frequency Inverter and wait until LCD display is dark.
2. With **▲** and **▼** keys depressed reapply power. Keep keys depressed until the following display appears:

AC MOTOR DRIVE
DEFAULTS LOADED

Factory default settings (MACRO1) is now loaded. If required, store this setting (see page 4-9). An alternative method is to load **MACRO 1** in the **SYSTEM | RESTORE DEFAULTS** menu, see page 5-15. See page 4-7 or page 5-15.

Displaying and changing parameters

Examples:

- Display of active setpoint **SPEED DEMAND** starting from the power-up screen: **M**, **M**, **▼**.
Increasing the ramp-up time **RAMP ACCEL RATE** starting from the power-up screen: **M**, 2 x **▼**, 2 x **M**, 4 x **▼**, **M**, **▲** as required followed by **E**.

Saving parameters in the MM456/MM3SV Frequency Inverter

1. Press **PROG** key for at least 2 s until the following screen is displayed: SAVE TO MEMORY
2. Press **M** key to select the command display **UP FOR ACTION** in the second row.
3. Press **▲** key to complete parameter store.
4. Press **PROG** key again to revert to original position in programming menu.

See page 5-14 for an alternative method of saving parameters.

Storing parameters in the programming pad

See page 5-14.

Loading parameters from the programming pad

1. Remove supply voltage to MM456/MM3SV Frequency Inverter and wait until LCD display is dark.
2. With **▼** key depressed reapply power. Keep key depressed until the following display appears:

ALL PARAMETERS

3. Press **▲** key to complete loading.

Loading preset configuration

Integrated MACROS for frequently used configurations are available for frequently used applications, see page 5-15.

SETTING-UP AND ENERGIZING THE DRIVE



WARNING!

Working on any part of the drive system or removing terminal covers is only allowed when the following is adhered to:

- complete and full **isolation** of the power and control voltage supplies
- **waiting** until the d.c. link is discharged (at least **3 min**)
- verification that all conducting parts are **free of voltage** before touching these parts
- taking measures to ensure that voltage supplies cannot be reapplied

Potentially lethal injury can occur if the above is not observed !

First-time check of electrical system

Before power is applied to the system the following items should be checked:

1. Single-phase voltage supply is correct and within the specification.
2. Motor is of correct voltage rating and is connected to the MM456/MM3SV Frequency Inverter in either star or delta as is appropriate.
3. All external wiring circuits; such as power connections, control connections, motor connections and in particular protective earth connections have been wired correctly.

NOTE: Completely disconnect the MM456/MM3SV Frequency Inverter before point-to-point checking with a buzzer or when checking insulation with a Meggar.

4. Check for visual damage to MM456/MM3SV Frequency Inverter or associated equipment.
5. Check for loose ends, clippings, drilling swarf, etc., lodged in the MM456/MM3SV Frequency Inverter or ancillary equipment.
6. If possible check that the motor can be turned freely and that the cooling fan is intact and free of obstructions.

Safety considerations

Ensure the safety of the complete system when the drive is energised. In particular ensure:

1. That rotation of the motor in either direction will not cause damage.
2. That nobody else is working on another part of the equipment which will be affected by powering up or drive movements.
3. That other equipment will not be adversely affected before energizing by powering up or drive movements.

Setting up the drive before energizing

1. Prevent application of the supply voltage to the MM456/MM3SV Frequency Inverter by removal of the input fuses or isolate via a suitable circuit breaker.
2. Disconnect the load from the motor shaft, if possible.

3. If any of the drive control terminals are not being used then refer to Fig. 2.1, on page 2-4 to check whether these unused terminals need to be connected. In particular make sure the following terminal connections are made:
 - MM45: Terminal 6-10 (Ext. trip)
 - MM6: Terminal 11-16 (Ext. trip), Terminal MOT/TEMP (Thermistor)
 - MM3SV: Terminal 18-23 (Ext. trip), Terminal 6-10 (Thermistor)
4. Check that the external contact to input DIN 1, Run is open:
 - MM45: Terminal 6-7
 - MM6: Terminal 11-13
 - MM3SV: Terminal 18-20
5. Check that the external speed setpoints are all zero.
6. Following careful adherence to 1... 5 above, connect main power supply to MM456 Frequency Inverter.
7. Make sure that important parameters in the menu SETUP PARAMETERS|QUI CK SETUP such as min/max speed, ramp times etc. all have factory default values (see Tabele 4.1 below). These values should be adequate for many applications, however it may be necessary to change some of the parameters to suit individual applications.
8. Disconnect power to MM456/MM3SV Frequency Inverter.

NOTE: Terminals indicated are valid for factory default setting as in MACRO 1.

PARAMETER	Factory setting	Explanation	MM6/MM3SV only	Further Info page
BASE FREQUENCY	50.0 Hz	Frequency at max. output voltage		5-4
MAX SPEED	50.0 Hz	Max. speed (frequency)		5-4
MIN SPEED	-100.0 %	Min speed (frequency))		5-4
RAMP ACCEL RATE	10.0 s	Acceleration time from 0 Hz to MAX SPEED		5-5
RAMP DECEL RATE	10.0 s	Deceleration time from MAX SPEED to 0 Hz		5-5
V/F-SHAPE	LINEAR LAW	Linear V/f characteristic		5-5
QUADRATIC TORQUE	FALSE	Constant torque operation (CT)	•	5-6
FULL LOAD CALIB	XXXX.X A	Rated motor current		5-6
NO LOAD CALIB	XXXX.X A	No-load motor current		5-5
POWER FACTOR	X.XX	cos ϕ at rated speed		5-5
MOTOR CURRENT	YYY.Y A	(measured current)		5-3/6
MOTOR LIMIT	100.0 %	Current limit in %		5-6
FIXED BOOST	6.00 %	Additional voltage boost at slow speed		5-6
RUN STOP MODE	RAMPED	Ramp down on removing the RUN command (terminal 20)		5-7
JOG SETPOINT	10.00 %	Jog set value		5-7
AE1 TYPE	0..+10 V	Analog input 1: range		5-8
AE2 TYPE	0..+10 V	Analog input 2: range		5-8
AE3 TYPE	0..20 mA	Analog input 3: range	•	5-8
AE4 TYPE	0..+10 V	Analog input 4: range	•	5-8
DISABLED TRIPS	0600 >>	Trips which are to be ignored		5-8
DISABLED TRIPS+	0000 >>	Further trips which are to be ignored	•	5-8

See page 4-3 for an explanation of XXX.X and YYY.Y:

Table 4.1: Basic parameters in the menu SETUP PARAMETERS|QUI CK SETUP

Energizing the drive

The following alternative methods of energizing the MM456/MM3SV Frequency Inverter are available:

- Energizing in the LOCAL mode with local control from the optional programming pad (useful for first drive tests or fault finding).
- Energizing in the REMOTE Mode i.e. with control via terminals

After completing and understanding of all preceding steps in this chapter the drive may be powered up as follows (preferably with the load disconnected):

1. Reconnect power. The following should be displayed:

With programming pad:

```
AC MOTOR DRIVE
4.0 kW 400V 5. X
```

LEDs: HEALTH, FWD, & TOP





With standard cover plat :

LED: HEALTH

Should the above not displayed then locate the cause of the fault (see page 6-16)

2. If any of the basic drive parameters need to be changed then this should be done now. Refer to **PROGRAMMING PAD** page 4-2 for a full explanation of how to use the Programming Pad, and Chapter 5 - **PROGRAMMING THE APPLICATION** for an explanation of specific parameters which can be changed (see page 5-4).

3. Energizing in LOCAL Mode

- Press  key, LEDs LOCAL | SEQ and REF should light
- Press  key
- Adjust local setvalue as required with  and  keys

Energizing in REMOTE mode
with terminal control

- Apply a small set value to AIN1:
 - MM45: Between terminals 2 - 1
 - MM6/ MM3SV: Between terminals 1 - 4
- Activate digital input by linking the following terminals:
 - MM45: Terminals 6 - 7
 - MM6: Terminals 11 - 13
 - MM3SV: Terminals 18 - 20

4. The shaft at the motor should rotate slowly.
5. If the motor rotates in the wrong direction exchange two of the output phases M1/U, M2/V, M3/W.
6. In applications where a high starting torque is required an increase in the parameter F I X E D BOOST (see page 5-6) may be necessary. Excessive F I X E D BOOST may cause the drive to trip on **OVERLOAD** or **I * T T R I P**.
7. If the motor current rating is smaller than the drive current rating then the FULL LOAD CALI B parameter (see page 5-5) should be reduced to match the motor rating.

Chapter 5 - PROGRAMMING THE APPLICATION

MAIN MENU - OPERATOR	
Set-value	5-2
Operating point	5-3
Password	5-3
MAIN MENU - DI AGNOSTICS - Information in more detail.....	refer to chapter 6
MAIN MENU - SETUP PARAMETERS	
QUI CK SETUP.....	5-4
Base frequency	5-4
Maximum and minimum speeds	5-4
Ramps	5-4
V/f shape.....	5-5
Operation with quadratic torque at higher power (HVAC).....	5-5
Motor data	5-5
Voltage boost.....	5-6
Run stop mode	5-7
Jog	5-7
Analog inputs.....	5-8
Disabled trips.....	5-8
VECTOR SETUP	5-9
FUNCTION BLOCKS	5-10
MAIN MENU - PASSWORD.....	5-11
MAIN MENU - TRIPS STATUS	5-12
MAIN MENU - MENUS.....	5-12
MAIN MENU - SAVE PARAMETERS and SYSTEM.....	5-13
Saving parameter	5-14
Restoring default value and loading application MACROS	5-15
Loading parameters from memory or programming pad	5-16
Links	5-16
Configuration mode	5-16
Other functions and parameters	5-16


NOTE: The setting-up and commissioning of MM6 Frequency Inverters is almost identical to that with MM3SV range. Reference is therefore made to both MM6 and MM3SV Frequency Inverters in this chapter.

MAIN MENU - OPERATOR


Operating conditions of the MM456/MM3SV Frequency Inverter which are important for the operator are brought together in the menu **OPERATOR**. Also the parameter **SETPOINT LOCAL** may be changed in this menu.

Special programming (see menus **FUNKTION BLOCKS | MENUE | OPERATOR | SETUP PARAMETERS** in the **Software and Application Manual TMM456-SAM**) enables up to any 14 parameters to be brought together in the **OPERATOR** menu. In addition two screens can be customized to display any process parameters, see menu **SETUP PARAMETERS | FUNKTION BLOCKS | MENUE | CUSTOM SCREEN 1** in the **Software and Application Manual TMM456/MM3SV-SAM**.



NOTE: Never forget to **save parameters** after modifying any parameter setting, see page 4-9/5-14.




Set-value

SETPOINT REMOTE = YYY.Y %	Range from: -300.00% to: 300.00% Default: YYY.Y%
or	Displays the remote setpoint of the <u>input</u> of the ramp function generator in % MAX SPEED provided LOCAL mode is <u>not</u> activated and the MM456/MM3SV Frequency Inverter is <u>not</u> in operation
DEMAND REMOTE = YYY.Y %	Range from: -100.0 % to: 100.0 % Default: YYY.Y %
or	Displays the active remote setpoint of the <u>output</u> of the ramp function generator in % MAX SPEED provided LOCAL mode is not activated and the MM456/MM3SV Frequency Inverter is in operation.
JOG REMOTE = 10.00 %	Range from: 0.0 % to: 100.0 % Default: 10.0 %
or	Displays the JOG value in % MAX SPEED provided the terminal JOG is activated and not in LOCAL mode.
SETPOINT LOCAL 0.0 %	Range from: 0.00% to: 100.00% Default: 0.00%
or	Displays the local setpoint at the input of the ramp function generator in % MAX SPEED provided LOCAL mode is activated.
JOG DMD LOCAL = 0.0 %	Range from: 0.0 % to: 100.0 % Default: 10.0 %
	Displays the active local jog setpoint in % MAX SPEED when the  key in local mode is pressed.
SPEED DEMAND = YYY.Y %	Range from: -100.00% to: 100.00% Default: YYY.Y%
	Displays the active setpoint in % MAX SPEED.

NOTE: The set values **SETPOINT REMOTE**, **DEMAND REMOTE**, **JOG REMOTE**, **SETPOINT LOCAL** and **JOG DMD LOCAL** displayed depends on the actual mode.

Keys  and  select the active mode of operation, see page 4-5.

Operating point



Range from: 0.00Hz **to:** 480.00Hz **Measured value:** YYY.Y Hz
 Displays the output frequency of the MM456/MM3SV Frequency Inverter. The addition of the individual setpoints, the slip-frequency correction function and the output of the PID controller can cause the output frequency to differ from the main setpoint.

Range from: 0.0 A **to:** 1000.0 A **Measured value:** YYY.Y A
 Displays the motor current in A.


Range from: 0.00% **to:** 200.00% **Measured value:** YYY.Y %
 Estimated MOTOR LOAD (torque) referred to the load at rated frequency with rated output current. It is assumed that 100 % load corresponds to 100 % output current. The displayed load can be scaled to read as a percentage of the rating of the motor using the parameter FULL LOAD CALIB (see page 5-5).

NOTE: The diagnostic parameters MOTOR CURRENT and LOAD do not generally agree with each other, especially under low load conditions. This is because the magnetizing current of a motor is typically 30 %, even with a motor at no load.

Range from: 0.0 V **to:** 800.0 V **Measured value:** YYY.Y V
 Measured d.c. link voltage.

Range from: FALSE **to:** TRUE **Measured value:** FALSE
 TRUE indicates current limiting.

Password



Range from: 0000 **to:** 9999 **Default:** XXXX
 Used to enter the password as a 4-digit hexadecimal number to regain access to the setup parameters. The password value entered must match the value previously set up in the parameter PASSWORD|ENTER PASSWORD., see page 5-11.


MAIN MENU - DI AGNOSTI CS

The main menu **DI AGNOSTI CS** customizes many useful parameters for diagnostics. Refer to **Chapter 6** for more details.


MAIN MENU - SETUP PARAMETERS | QUICK SETUP

Setup parameters used for the majority of applications are brought together in the menu **QUICK SETUP**. This menu is described in the following.


NOTE: Never forget to **save parameters** after modifying any parameter setting, see page 4-9/5-14.



QUICK SETUP




Base frequency



Range from:	to:	Default:
7.5 Hz	480.0 Hz	*50.0 Hz

Frequency at which the inverter produces maximum output voltage. This would be set at 50 Hz for a standard motor.

Maximum and minimum speeds



Range from:	to:	Default:
0.0 Hz	480.0 Hz	50.0 Hz*


Speed/frequency at maximum setpoint input (100.0 %).

Range from:	to:	Default:
-100.0 %	100.0 % von MAX SPEED	-100.0 %

Speed/frequency at minimum setpoint input.

* Can be 60.0 Hz with certain language settings, see page 4-6.

Ramps




Range from:	to:	Default:
0.1 s	600.0 s	10.0 s

Time taken to ramp the frequency from 0 Hz to **MAX SPEED**

Range from:	to:	Default:
0.1 s	600.0 s	10.0 s

Time taken to ramp from **MAX SPEED** to 0 Hz

Voltage / frequency shape



Range:
see below


Default:
LI NEAR

PUMP/FAN

Quadratic torque characteristic up to base frequency.

LI NEAR

Constant torque characteristic up to base frequency



U: Output voltage


f_B: BASE FREQUENCY

L: LI NEAR

Q: PUMP/fan

NOTE: With fans and pumps with a high starting torque or inertia it is often advantageous to use the LI NEAR setting.

Operation at higher power with 110 % overload (HVAC)



With MM6/
MM3SV only

Range from:
see below

to:

Default:
FALSE

FALSE


Normal operation with 150 % overload current

TRUE

Operation at higher power with 110 % overload current mainly for quadratic torque loads (HVAC)

Before a change of parameter is implemented confirmation 'UP' FOR CONFIRM is required. After confirmation QUADR. TORQUE will be displayed.

Motor data



Range from:
0.0 A

to:
1000.0 A

Default:
XXX.X A

Scaling of the output current of the MM456 Frequency Inverter to match the rated motor current. The effective value of FULL LOAD CALI B is internally clamped to the rated output current of the inverter.


Range from:
0.0 A

to:
1000.0 A

Default:
XXX.X A

Value of no-load motor current which is used for vector control. The effective value of NO LOAD CALI B is internally clamped to $\geq 10\%$ or $\leq 90\%$ of the rated inverter current.

This parameter is important for the correct determining of the parameter LOAD, see **Software and Application Manual TMM456-SAM**, page 28.4-6. The factory setting can be used for normal applications.




Range from:
0.50

to:
0.95

Default:
X.XX

Set to name-plate $\cos \phi$ rating.




Range from: 0.0 A **to:** **Default:** 0.0 A
Displays the measured phase current of the motor in A

Range from: 0.00 % **to:** 150.00 % **Default:** 150.00 %
Maximum motoring current. If the drive output current exceeds MOTOR I LIMIT value then the drive will attempt to reduce the motoring load by reducing the motor frequency. The effective current limit is clamped at 150 % of the rated output current of the MM456/MM3SV Frequency Inverter.


Voltage boost

FIXED BOOST is used to correctly flux the motor at low speeds and allows the drive to produce greater starting torque for high friction loads. Voltage boost increases the motor volts above the selected V/F characteristic at the lower end of the speed range.



Range from: 0.00 % **to:** 25.00 % **Default:** 0.00 %

Level of extra volts applied to the motor at low speeds:



U: Output frequency
f_B: BASE FREQUENCY
B: FIXED BOOST


Increase FIXED BOOST only as much as is necessary to provide the required starting torque. Excessive boost can cause the MM456 Frequency Inverter.

The required setting of FIXED BOOST depends on the application and on the type of size of motor. The following table gives some indication of typical maximum values.

Motor power	0.75 kW	2.2 kW	4 kW	11 kW	37 kW	75 kW	160 kW
FIXED BOOST	8...12 %	6...8 %	5...7 %	4...6 %	3...5 %	2...3 %	1...2 %

NOTE: For applications requiring very high motor starting torque, refer to page 10-7 for guidance on optimal settings for the FIXED BOOST Parameter.

Run stop mode



Range:
see below
▼ RAMPED

Default:
RAMPED

The motor speed is controlled down to zero at a rate set by the RAMP DOWN TIME 1/2 or **FRAMP** parameter. On reaching 0 Hz, d.c. current is injected for a length of time given by SETUP PARAMETER | **FUNCTION BLOCKS** | **SEQ & REF** | **STOP** | **STOP DELAY**, see page 28.2-17, (factory default setting 0.5 s).

DC-
INJECTION


On a stop command the motor volts are rapidly reduced at constant frequency to deflux the motor. If injection braking begins from a speed greater than 20 % of BASE FREQUENCY a low frequency braking current is applied until the motor speed is almost zero. This is followed by a timed d.c. pulse to hold the motor shaft. If injection braking begins from a speed below 20 % of base frequency, a d.c. pulse is applied to the motor.

NOTE: The lower menu **INJ BRAKING**, page 28.4-16, contains various parameters which allow the fine tuning of d.c. braking. However it is not usually necessary to modify these parameters.

▲ COAST

The motor is allowed to freewheel to standstill at zero current from the MM456/MM3SV Frequency Inverter.

Jog




Range from:
0.00%

to:
100.00% von
MAX SPEED


Default:
10.00%

Determines the speed that the drive will run at when the JOG terminal 11 is raised to +24 V (terminal 6) or the JOG key in the LOKAL mode is depressed.

Analog inputs



Disabled trips



VECTOR SETUP

The Menu VECTOR SETUP contains all adjustment parameters and several diagnostic parameters which allow the der MM456/MM3SV Frequency Inverter to be matched to the characteristics of settings of the motor. The advantage of vector operation is only available if the appropriate parameters are carefully set. The vector operation is only suitable for single-motor drives.

NOTE: Never forget to **save parameters** after modifying any parameter setting, see page 4-9/5-14.

VECTOR SETUP menu at level 2			
VECTOR ENABLE FALSE	Range: see below FALSE Standard V/f operation TRUE Vektor operation	Default: FALSE	
NAME PLATE RPM XXXX U/mi n	Range from: 0 U/mi n to: 15000 U/mi n Rated motor speed	Default: XXXX U/mi n	
MOTOR POLES 4	Range from: 2 to: 12 No. of motor poles	Default: 4	
MOTOR VOLTS XXX. X V	Range from: 198. 0 V to: 506. 0 V Rated motor voltage (230. 0 or 400. 0 V default value)	Default: XXX. X V	
SUPPLY VOLTAGE = YYY. Y V	Range from: 000. 0 V to: 506. 0 V Measured supply voltage	Measured value: YYY. Y V	
MOTOR CONNECTION XXXXX	Range: see below DELTA Motor winding connected in delta STAR Motor winding connected in star Important to enable the parameter STATOR RES, LEAKAGE I NDUC and MUTUAL I NDUC to be interpreted as <u>phase values</u> .	Default: XXXXX	
AUTOTUNE ENABLE FALSE	Range: see below FALSE VEKTOR-AUTOTUNE disabled TRUE VEKTOR-AUTOTUNE enabled	Default: FALSE	
STATOR RES XXX. X Ohm	Range from: 0. 00 Ohm to: 100. 0 Ohm Phase value of motor resistance.	Default: XXX. XX Ohm	

FIELD
= YYY. Y %

Range from:	to:	Default:
0.00 %	200.00 %	YYY. Y% %

Calculated magnetizing component of motor current in % of calibrated motor current.

LEAKAGE INDUC
XXX. X mH

Range from:	to:	Default:
0.0	1000.0 mH	XXX. X mH

Phase value of motor leakage inductance

MUTUAL INDUC
XXX. X mH

Range from:	to:	Default:
0.0	1000.0 mH	XXX. X mH

Phase value of motor mutual inductance

NOTE: If the parameter VECTOR ENABLE is enabled, the motor parameters relevant to vector operation will be automatically determined based on electrical measurements at the next power-up (lasts approx. 5 s). On completion of this process the parameter VECTOR ENABLE is automatically reset to FALSE.

Refer to **SETTING UP THE SENSORLESS VECTOR FLUXING MODE**, page10-9 for more information on vector setup.


FUNCTION BLOCKS

A large number of further parameters are available for special application in SETUP PARAMETERS | **FUNCTION BLOCKS**. To provide easier reading of the description of these parameters is not included in this Product Manual. Refer to **Software and Application Manual TMM456/MM3SV-SAM** for detailed information on all function blocks.

MAIN MENU - PASSWORD

A password system which can be used to prevent unauthorised access to the adjustable parameters. Once the user has programmed in a password then the setup parameters become read-only. In order to change the parameter values the correct password must first be entered.

All drives shipped from the factory have a default password value of 0000.



Range from:	to:	Default:
0000	FFFF	0000

Used to enter the password as a hexadecimal number to regain access to the setup parameters. The password value entered must match the value previously setup in the CHANGE PASSWORD parameter. When set to 0000 the programming pad is always unlocked.

Range from:	to:	Default:
0000	FFFF	0000

Used to change the password or to initially programme a user password. When a password has been set up, the **save parameter** command (see page 4-7/5-14) should be used to save the password in the non-volatile memory.

Example: Initial programming of password:

1. Access the CHANGE PASSWORD menu and press the **M** key.
The display will show:

CHANGE PASSWORD 0000

2. Using the **▲** and **▼** keys, set the password value required as a 4 digit hexadecimal number.
The display will show, for example:

CHANGE PASSWORD 89AB

NOTE: When you are happy with the password make a note of the value and keep it in a safe place!

3. Press the **E** key to leave the CHANGE PASSWORD menu.
The display will show:

CHANGE PASSWORD XXXX

4. Remember to use **save parameter** to store the password value in non-volatile memory, see page 4-7/5-14.


The level of password protection can be set using special programming (see menu SETUP PARAMETERS | **FUNCTION BLOCKS** | **MENUES** | **PASSWORD**, page 28.6-4).

MAIN MENU - TRIP STATUS

The main menu TRIP STATUS contains important parameters of the MM456/MM3SV Frequency Inverter relevant to trip monitoring. Refer to **Chapter 6 - TRIPS, DIAGNOSTICS AND FAULT FINDING**.

MAIN MENU - MENUS

The main menu MENUS contains parameters which govern the level of access (view level) to the parameters and determine the language of the LCD plain-language display on the programming pad:



Range:
see below

Default:
BASIC

▼ **BASIC**

All important menus for normal use are available, i.e.:

- OPERATOR
- DIAGNOSTICS
- SETUP PARAMETERS | QUICK SETUP
- | VECTOR-SETUP
- PASSWORD | ENTER PASSWORD
- | CHANGE PASSWORD
- TRIP STATUS | DISABLED TRIPS
- | ACTIVE TRIPS
- | TRIP WARNINGS
- | FIRST TRIP
- MENUS | **VIEW LEVEL**
- PARAMETER SAVE | **SAVE TO MEMORY**
- | **SAVE TO OP**

OPERATOR

Intended for the operator, i.e. limited to:

- OPERATOR
- MENUS | **VIEW LEVEL**
- PARAMETER SAVE | **SAVE TO MEMORY**

▲ **ADVANCED**

For experienced programmers all menus can be accessed.

NOTE: The type face of the menus and parameters in this Product Manual and associated parameter list are used to indicate the level of access i.e. VIEW LEVEL, see page 4-3).

Range:
see below

Default:
ENGLISH

- ▼ **ENGLISH**
- ESPANOL**
- FRANCAIS**
- ▲ **DEUTSCH**

MAIN MENU - PARAMETER SAVE and SYSTEM

The main menus **PARAMETER SAVE** and **SYSTEM** contain important command parameters to control the following storing and loading operations:

- Save parameters to Frequency Inverter:	PARAMETER SAVE SAVE TO MEMORY*
- Save parameters to programming pad:	PARAMETER SAVE SAVE TO OP
- Load default settings (MACRO 1) and other preprogrammed settings (MACRO 2...6):	SYSTEM RESTORE DEFAULTS LOAD MACRO 1* : 6 99□
- Load from non-volatile memory (NVRAM):	SYSTEM LOAD FROM MEMORY
- Load from programming pad:	SYSTEM LOAD FROM OP ALL PARAMETERS+ APPLICATION ONLY

* These command parameters are very frequently used. An alternative simplified short-cut command is available, see page 4-7.

+ Without motor parameters

□ With MM6/MM3SV only






Fig. 5.1: Explanation of storing and loading operations

On power-up the stored parameters are loaded into the working memory (RAM). The MM456/MM3SV Frequency Inverter uses these parameters when running. If any parameter values are changed, then the value in the main memory (RAM) **only** is modified.

On **SAVING** all parameters of the working memory RAM are copied to the non-volatile memory (NVRAM) overwriting the previous values. **Only then** are the changed parameters saved.


Saving parameters



Refer to **Saving parameters in the MM456/MM3SV Frequency Inverter**, page 4-9 for an alternative method of storing parameters using the  key.


NOTE: Never forget to **save parameters** after modifying any parameter setting.

Restoring default values and loading application MACROS



These application MACROS are described in more detail in **Chapter 11**.

Loading parameters from memory or from Programming Pad




The motor parameters which are not loaded are:

In menu QUICK SETUP	In menu VECTOR SETUP	In the menus FUNCTION BLOCKS	
BASE FREQUENCY	NAMEPLATE RPM	ENCODER LINES	INJ DC PULSE
FULL LOAD CALIB	MOTOR POLES	SLIP MOTOR LIMIT	INJ FINAL DC
NO LOAD CALIB	MOTOR VOLTS	SLIP REGEN LIMIT	INJ DC LEVEL
POWER FACTOR	MOTOR CONNECTION	AUTO BOOST	INJ BASE VOLTS
FIXED BOOST	STATOR RES	DEFLUX DELAY	FLY SEARCH VOLTS
	LEAKAGE INDUC	INJ DEFLUX TIME	FLY SEARCH BOOST
	MUTUAL INDUC	INJ FREQUENCY	FLY SEARCH TIME

Links

A detailed description of the **LINKS** menu is in **Chapter 27 - PROGRAMMING WITH FUNCTION BLOCKS**.

Configuration mode



Other functions and parameters

To provide for easier reading, a detailed description of all other functions and parameters is in **Chapter 27 - PROGRAMMING WITH FUNCTION BLOCKS**.

Chapter 6 - TRIPS, DIAGNOSTICS AND FAULT FINDING

	Page
INTRODUCTION	6-2
TRIPS	
When using the Blank Cover (standard inverter).....	6-3
When the Programming Pad (OPTION) is fitted.....	6-3
Resetting a trip conditions	6-3
Automatic trip reset (AUTO RESTART).....	6-4
Setting trip conditions.....	6-4
MAIN MENU - DI AGNOSTI CS	
Set-value	6-5
Operating data	6-6
Trips	6-7
Inputs/Outputs	6-9
MAIN MENU - TRI PS STATUS	6-11
TRIPS AND WARNINGS	
Trip messages and fault finding.....	6-13
"KEY INACTIVE" messages.....	6-15
"CHECKSUM FAIL"	6-15
OTHER FAULT FINDING	6-16

NOTE: The setting-up and commissioning of MM6 Frequency Inverters is almost identical to that with MM3SV range. Reference is therefore made to both MM6 and MM3SV Frequency Inverters in this chapter.

INTRODUCTION

The MM456/MM3SV Frequency Inverters provide comprehensive diagnostic, alarm and trip facilities. These facilities minimise the possibility of damage to the frequency inverter, motor and associated components under unusual or fault conditions. The diagnostics information, available at the operating panel, enables ready identification of these conditions.

In the event that a fault is traced to the Frequency Inverter, then the inverter should be **returned to the supplier** - no corrective maintenance should be attempted (see **Chapter 7, SERVICING**).

The following diagnostic information is available with MM456/MM3SV Frequency Inverters:

◆ Main Menu OPERATOR :	- Various measured values (see parameter list). These values are described in detail in the following main menu DIAGNOSTICS
◆ Main Menu DIAGNOSTICS : Various measured values for an in-depth analysis arranged according to their function, e.g.:	- Set values: SPEED DEMAND : JOG SETPOINT - Measured values: DRIVE FREQUENCY : DC LINK VOLTS
The following trip information is displayed:	- Trips present: ACTIVE TRIPS* ACTIVE TRIPS+* - First trips: FIRST TRIP
The value or level of all inputs and outputs is displayed:	- Analog MM45 AIN1/2 VALUE inputs: MM6/MM3SV AIN1...4 VALUE - Digital MM45 DIN1...7 VALUE inputs: MM6/MM3SV DIN1...8 VALUE - Analog MM45 AOUT1 VALUE outputs: MM6/MM3SV AOUT1/2 VALUE - Digital MM45 DOUT1/2 VALUE outputs: MM6/MM3SV DOUT1...3 VALUE
◆ Main Menu TRIPS STATUS : Ausführliche Information über den aktuellen Stöorzustand:	- Disabled trips: DISABLED TRIPS* DISABLED TRIPS+* - Active trips: ACTIVE TRIPS* ACTIVE TRIPS+* - Warnings: TRIP WARNINGS* TRIP WARNINGS+* - First trip: FIRST TRIP - Stack of last 10 trips: TRIP 1 (NEWEST) TRIP 10 (OLDEST)
◆ Trips which have inhibited the power stage to protect the MM456 Frequency Inverter are indicated as follows:	*** TRIPPED ***:
◆ Other alerts e.g. to indicate that inhibited key action has been attempted	* KEY INAKTIV *

* These trips are displayed as 4-digit hexadecimal numbers, see page 6-5.

+ These trips are only used in the MM6 and MM3SV Frequency Inverters.

TRIPS

When a trip occurs, the power stage of the MM456/MM3SV Frequency Inverter is immediately disabled causing the motor and load to coast to a stop. The trip is latched until action is taken to reset it. This ensures that trips due to transient conditions are captured and the inverter is made safe, even when the original cause of the trip is no longer present.

When using the Blank Cover (standard inverter)

If a trip condition is detected the following action will be taken:

- HEALTH LED flashes.
- The output **TRIPPED** of the function block **SETUP PARAMETERS | FUNCTION BLOCK | SEQ & REF | SEQUENCING LOGIC |** is set to **TRUE**. The **DIGITAL OUTPUT 1 (HEALTH)** digital output changes between **TRUE** and **FALSE** depending on the output logic.

When the Programming Pad (OptionMM-PROG) is fitted

If a trip condition is detected the following action will be taken:

- HEALTH LED flashes.
- Display of trip message in LCD display.

The displayed trip message(s) may be acknowledged by pressing the **E** key, see page 4-4. However the latched trip itself will not be reset, refer to **⊙** key for this purpose, see page 4-5.

Resetting a tripped condition

All trips must be reset before the Inverter can be enabled again. A trip can only be reset once the trip condition is no longer active, i.e. a trip due to a heatsink over-temperature will not reset until the temperature is below the trip level.

NOTE: More than one trip can be active at any time. For example, it is possible for both the **HEATSINK TEMP** and the **LINK OVERVOLTS** trips to be active. Alternatively it is possible for the Inverter to trip due to an **OVERCURRENT** error and then for the **HEATSINK TEMP** trip to become active after the Inverter has stopped (this may occur due to the thermal time constant of the heatsink).

The following procedure must be adapted to reset trips and restart the drive:

- Remove cause of trip
- Reset trips by one of the following alternative means:
 - Remove supply voltage to MM456/MM3SV Frequency Inverter and wait until LCD display (or LEDs with basic cover) is dark. Reapply power.
 - Press **STOP/RESET** key

- Activate remote trip reset input (Terminal DIN2 in factory default condition corresponding to MACRO 1)
- When in REMOTE MODE by reapplying RUN (terminal DIN1 in factory default condition corresponding to MACRO 1)
- When in LOCAL MODE by pressing . key to reset trips, clear messages and restart drive.
- Enable **AUTO RESTART** function block, see following

Success is indicated by the HEALTH LED (on the Blank Cover or Programming Pad) ceasing to flash and returning to an illuminated healthy state. The output **TRIPPED** of the function block **SETUP PARAMETERS | FUNCTION BLOCK | SEQ & REF | SEQUENCING LOGIC** output is reset to **FALSE**.

Automatic Trip Reset (AUTO RESTART)

Using the Programming Pad the MM456 Frequency Inverter can be programmed automatically attempt to restart the drive after a preset time once the trip conditions has occurred. The parameter **AC ENABLE** in function block **SETUP PARAMETERS | FUNCTION BLOCK | SEQ & REF | SEQUENCING LOGIC** is used to activate **AUTO RESTART**. Refer to page 28.2-8 for further information.

Setting Trip conditions


Certain trip conditions can be adapted for special applications. Parameter in the following function blocks which can be adapted are:

SETUP PARAMETERS | FUNCTION BLOCK | TRIPS | TRIPS STATUS | I/O TRIPS,
| I*T TRIPS,
| STALL TRIP.


Refer to **Chapter 28.5 - FUNCTION BLOCK DESCRIPTION** for further information.

MAIN MENU - DIAGNOSTICS

The main menu DIAGNOSTICS contains many diagnostics parameters which enable the MM456/MM3SV Frequency Inverter to be optimized for operation with the motor used and the machine to be driven.



Set-value



Range from: 0.00% **to:** 100.00% **Measured value:** YYY.Y%

Displays the active speed in % MAX SPEED

Range from: -300.00% **to:** 300.00% **Measured value:** 0.00%

Displays the remote setpoint in % MAX SPEED

Range from: -300.00% **to:** 300.00% **Measured value:** YYY.Y%

Displays the serial link setpoint in % MAX SPEED


Range from: 0.00% **to:** 100.00% **Measured value:** 0.00%

Displays the local setpoint at the input of the ramp function generator for **LOCAL** mode in % MAX SPEED

Range from: 0.00% **to:** 100.00% **Measured value:** 10.00%

Displays the jog setpoint in % MAX SPEED

Trips



Range:

The hexadecimal numbers represent the trip status of the drive (no trips).

- 0 No trip or warning present = NO TRIP
- 1 d.c. link voltage overvoltage = LINK OVERVOLTS
- 2 d.c. link voltage undervoltage = LINK UNDERVOLTS
- 4 Over current in motor = OVERCURRENT
- 8 Heat sink = HEATSINK TEMP
- 9

F Additive sum of above

- 0 No trip or warning in this range
- 1 External trip AIN1 = EXTERNAL TRIP S
- 2 Analog input AIN1 = INPUT 1 BREAK S
- 4 Analog input AIN2 = INPUT 2 BREAK S
- 8 Motor "stalled" = MOTOR STALLED S
- 9

F Additive sum of above

- 0 No trip or warning in this range
- 1 I*T trip = I*T TRIP
- 2 Brake resistor overloaded = BRAKE RESISTOR S
- 4 Braking chopper overloaded = BRAKE SWITCH S
- 8 Programming pad defect = OP STATION S
- 9


F Additive sum of above

- 0 No trip or warning in this range
- 1 Serial link faulty = LOST COMMS S
- 2 Not used
- 4 Not used
- 8 Not used
- 9

F Additive sum of above

The trips indicated with "S" can be disabled, see page 5-8, 28.5-2.


Example:



- 0 No trip or warning in this range
- 0 No trip or warning in this range
- 3 =
- 1 I*T trip
- +
- 2 Braking resistor overloaded
- 0 No trip or warning in this range

NOTE:

It is not necessary to learn the hexadecimal system. On pressing the key the individual trips are successively displayed. For further information on messages refer to **TRIPS AND WARNINGS** on page 6-13.




* Phase failure detection with MM6 Frequency Inverters only.

Inputs/Outputs

<table border="1"> <tr> <td colspan="2">AIN 1 VALUE</td> </tr> <tr> <td colspan="2">= YYY. Y %</td> </tr> <tr> <td>MM45: terminal 2</td> <td>MM6/ MM3SV: terminal 1</td> </tr> </table>	AIN 1 VALUE		= YYY. Y %		MM45: terminal 2	MM6/ MM3SV: terminal 1	<p>Range from: to: Measured value: -300.0 % 300.0 % YYY. Y %</p> <p>Displays the analog input AIN1 after processing by the function block ANALOG INPUT 1</p>
AIN 1 VALUE							
= YYY. Y %							
MM45: terminal 2	MM6/ MM3SV: terminal 1						
<table border="1"> <tr> <td colspan="2">AIN 2 VALUE</td> </tr> <tr> <td colspan="2">= YYY. Y %</td> </tr> <tr> <td>MM45: terminal 4</td> <td>MM6/ MM3SV: terminal 2</td> </tr> </table>	AIN 2 VALUE		= YYY. Y %		MM45: terminal 4	MM6/ MM3SV: terminal 2	<p>Range from: to: Measured value: -300.0 % 300.0 % YYY. Y %</p> <p>Displays the analog input AIN2 after processing by the function block ANALOG INPUT 2</p>
AIN 2 VALUE							
= YYY. Y %							
MM45: terminal 4	MM6/ MM3SV: terminal 2						
<table border="1"> <tr> <td colspan="2">AIN 3 VALUE</td> </tr> <tr> <td colspan="2">= YYY. Y %</td> </tr> <tr> <td></td> <td>MM6/ MM3SV : terminal 3</td> </tr> </table>	AIN 3 VALUE		= YYY. Y %			MM6/ MM3SV : terminal 3	<p>Range from: to: Measured value: -300.0 % 300.0 % YYY. Y %</p> <p>Displays the analog input AIN3 after processing by the function block ANALOG INPUT 3</p>
AIN 3 VALUE							
= YYY. Y %							
	MM6/ MM3SV : terminal 3						
<table border="1"> <tr> <td colspan="2">AIN 4 VALUE</td> </tr> <tr> <td colspan="2">= YYY. Y %</td> </tr> <tr> <td>With MM6/ MM3SV only</td> <td>MM6/ MM3SV: terminal 5</td> </tr> </table>	AIN 4 VALUE		= YYY. Y %		With MM6/ MM3SV only	MM6/ MM3SV: terminal 5	<p>Range from: to: Measured value: -300.0 % 300.0 % YYY. Y %</p> <p>Displays the analog input AIN4 after processing by the function block ANALOG INPUT 4</p>
AIN 4 VALUE							
= YYY. Y %							
With MM6/ MM3SV only	MM6/ MM3SV: terminal 5						
<table border="1"> <tr> <td colspan="2">DIN 1 VALUE</td> </tr> <tr> <td colspan="2">= YYYYY</td> </tr> <tr> <td>MM45: terminal 7</td> <td>MM6: terminal 13 MM3SV: terminal 20</td> </tr> </table>	DIN 1 VALUE		= YYYYY		MM45: terminal 7	MM6: terminal 13 MM3SV: terminal 20	<p>Range from: to: Measured value: TRUE FALSE YYYYYY</p> <p>Displays the digital input DIN1 after processing by the function block DIGITAL INPUT 1</p>
DIN 1 VALUE							
= YYYYY							
MM45: terminal 7	MM6: terminal 13 MM3SV: terminal 20						
<table border="1"> <tr> <td colspan="2">DIN 2 VALUE</td> </tr> <tr> <td colspan="2">= YYYYY</td> </tr> <tr> <td>MM45: terminal 8</td> <td>MM6: terminal 14 MM3SV: terminal 21</td> </tr> </table>	DIN 2 VALUE		= YYYYY		MM45: terminal 8	MM6: terminal 14 MM3SV: terminal 21	<p>Range from: to: Measured value: TRUE FALSE YYYYYY</p> <p>Displays the digital input DIN2 after processing by the function block DIGITAL INPUT 2</p>
DIN 2 VALUE							
= YYYYY							
MM45: terminal 8	MM6: terminal 14 MM3SV: terminal 21						
<table border="1"> <tr> <td colspan="2">DIN 3 VALUE</td> </tr> <tr> <td colspan="2">= YYYYY</td> </tr> <tr> <td>MM45: terminal 9</td> <td>MM6: terminal 15 MM3SV: terminal 22</td> </tr> </table>	DIN 3 VALUE		= YYYYY		MM45: terminal 9	MM6: terminal 15 MM3SV: terminal 22	<p>Range from: to: Measured value: TRUE FALSE YYYYYY</p> <p>Displays the digital input DIN3 after processing by the function block DIGITAL INPUT 3</p>
DIN 3 VALUE							
= YYYYY							
MM45: terminal 9	MM6: terminal 15 MM3SV: terminal 22						
<table border="1"> <tr> <td colspan="2">DIN 4 VALUE</td> </tr> <tr> <td colspan="2">= YYYYY</td> </tr> <tr> <td>MM45: terminal 10</td> <td>MM6: terminal 16 MM3SV: terminal 23</td> </tr> </table>	DIN 4 VALUE		= YYYYY		MM45: terminal 10	MM6: terminal 16 MM3SV: terminal 23	<p>Range from: to: Measured value: TRUE FALSE YYYYYY</p> <p>Displays the digital input DIN4 after processing by the function block DIGITAL INPUT 4</p>
DIN 4 VALUE							
= YYYYY							
MM45: terminal 10	MM6: terminal 16 MM3SV: terminal 23						
<table border="1"> <tr> <td colspan="2">DIN 5 VALUE</td> </tr> <tr> <td colspan="2">= YYYYY</td> </tr> <tr> <td>MM45: terminal 11</td> <td>MM6: terminal 17 MM3SV: terminal 24</td> </tr> </table>	DIN 5 VALUE		= YYYYY		MM45: terminal 11	MM6: terminal 17 MM3SV: terminal 24	<p>Range from: to: Measured value: TRUE FALSE YYYYYY</p> <p>Displays the digital input DIN5 after processing by the function block DIGITAL INPUT 5</p>
DIN 5 VALUE							
= YYYYY							
MM45: terminal 11	MM6: terminal 17 MM3SV: terminal 24						

<p>DIN 6 VALUE = YYYYY</p>	<p>MM45: terminal 16</p> <p>MM6: terminal 18 MM3SV: terminal 25</p>	<p>Range from: TRUE to: FALSE Measured value: YYYYYY Displays the digital input DIN6 after processing by the function block DIGITAL INPUT 6</p>
<p>DIN 7 VALUE = YYYYY</p>	<p>MM45: terminal 17</p> <p>MM6: terminal 19 MM3SV: terminal 26</p>	<p>Range from: TRUE to: FALSE Measured value: YYYYYY Displays the digital input DIN7 after processing by the function block DIGITAL INPUT 7</p>
<p>DIN 8 VALUE = YYYYY</p>	<p>With MM6/ MM3SV only</p> <p>MM6: terminal 20 MM3SV: terminal 27</p>	<p>Range from: TRUE to: FALSE Measured value: YYYYYY Displays the digital input DIN8 after processing by the function block DIGITAL INPUT 8</p>
<p>AOUT 1 VALUE = YYY.Y %</p>	<p>MM45: terminal 5</p> <p>MM6: terminal 6 MM3SV: terminal 7</p>	<p>Range from: -300.00 % to: 300.00 % Default: 0.0 % Displays the analog output AOUT1 before processing by the function block ANALOG OUTPUT 1</p>
<p>AOUT 2 VALUE = YYY.Y %</p>	<p>With MM6/ MM3SV only</p> <p>MM6: terminal 7 MM3SV: terminal 8</p>	<p>Range from: -300.00 % to: 300.00 % Default: 0.0 % Displays the analog output AOUT2 before processing by the function block ANALOG OUTPUT 2</p>
<p>DOUT 1 VALUE = FALSE</p>	<p>MM45: terminal 13</p> <p>MM6: terminal 21-22 MM3SV: terminal 12-13</p>	<p>Range from: TRUE to: FALSE Default: FALSE Displays the digital output DOUT1 before processing by the function block DIGIT OUTPUT 1</p>
<p>DOUT 2 VALUE = FALSE</p>	<p>MM45: terminal 14</p> <p>MM6: terminal 23-24 MM3SV: terminal 14-15</p>	<p>Range from: TRUE to: FALSE Default: FALSE Displays the digital output DOUT1 before processing by the function block DIGIT OUTPUT 1</p>
<p>DOUT 3 VALUE = FALSE</p>	<p>With MM6/ MM3SV only</p> <p>MM6: terminal 25-26 MM3SV: terminal 16-17</p>	<p>Range from: TRUE to: FALSE Default: FALSE Displays the digital output DOUT3 before processing by the function block DIGIT OUTPUT 3</p>

MAIN MENU - TRIPS STATUS



With MM6/ MM3SV only		MOTOR TEMP CURRENT LI MI T SHORT CI RCUI T 24V FAI LURE LOW SPEED I ▲ PHASE FAI L (with MM6 only)
TRIP 1 (NEWEST) = NO TRI P TRIP 10 (OLDEST) = NO TRI P		The FI RST TRI P is the trip which occurred the last shutdown of the inverter output stage. Not tripped: NO TRI P Trip: see page 6-7/8 Intermediate trips Not tripped: NO TRI P Trip: see page 6-7/8

The last ten trips are stored as a stock. For further information on trips messages refer to **Trips** on page 6-7/8 and **TRIPS AND WARNINGS** on page 6-13/14.

TRIPS AND WARNINGS

Trip messages and fault finding

The following trip messages indicate faults which have caused the MM456/MM3SV Frequency Inverter to trip:

	Possible cause	Cure	see page
*** TRIPPED *** LINK OVERVOLTS	Link overvoltage: - Supply voltage is too high - Deceleration too high with high inertia load	- Check supply voltage - Increase RAMP DECEL RATE - Fit a braking resistor - Check value and function	5-5
*** TRIPPED *** LINK UNDERVOLTS	Link undervoltage: - Supply voltage is too low - Supply phase missing (one or more phases)	- Check supply voltage	
*** TRIPPED *** OVER CURRENT	Overcurrent: - Acceleration or Deceleration too fast for large load inertia - Shock overload - Short circuit or earth fault at motor connection - Motor cables too long - too many parallel motors - FIXED BOOST or AUTO BOOST set to high	- Check parameter RAMP ACCEL RATE and RAMPE DECEL RATE - Check load - Check connection to motor - Refer to supplier - Check parameter settings	5-5, 28.4-9 5-6, 28.4-9
*** TRIPPED *** HEATSINK TEMP	Heatsink Temperature: - Ambient temperature too high - Specified cooling spacing not provided	- Check mounting	
*** TRIPPED *** EXTERNAL TRIP	+24V on terminal 10 not present	- Check external trip circuit	
*** TRIPPED *** INPUT 1 BREAK	Analog input AIN1 faulty at 4...20 mA setting: - Not correctly connected	- Check AI N1 TYPE - Check wiring	5-8, 28.1-2
*** TRIPPED *** INPUT 2 BREAK	Analog input AIN2 faulty at 4...20 mA setting: - Not correctly connected	- Check AI N2 TYPE - Check wiring	5-8, 28.1-3
*** TRIPPED *** MOTOR STALLED	Motor has been operated too long in current limit: - Motor load too high - MOTOR LIMIT parameter set too low - FIXED BOOST parameter set too high - STALL TIME set too short	- Check load - Check parameter settings	5-6, 28.4-7 5-6, 28.4-9
*** TRIPPED *** I*T TRIP	I*T monitoring function indicates overload: - Motor load too high - I*T THRESHOLD, I*T TIME and/or I*T-UPPER LIMIT set too low	- Check load - Check parameter settings	28.5-5
*** TRIPPED *** BRAKE RESISTOR	Monitoring function braking indicates overload: - Acceleration high with large inertia - Too frequent deceleration	- Check rating of resistor - Check brake resistor parameters	
*** TRIPPED *** BRAKE SWITCH	Monitoring function braking chopper indicates overload: - Acceleration high with large inertia - Too frequent deceleration	- Refer to supplier	

	Possible cause	Cure	see page
*** TRIPPED *** OP STATION	Programming pad disconnected when in LOCAL MODE	- Check connection	
*** TRIPPED *** LOST COMMS	Monitoring function for serial communication indicates lost communications: - Master not in operation - Setting incorrect	- Increase parameter COMMS TIMEOUT - Verify other COMM settings.	28.7-2
*** TRIPPED *** MOTOR TEMP	Thermistor input faulty: - No connection between terminals 6-10 Motor temperature too high: - Excessive load - Motor voltage incorrect - FIXED BOOST or AUTO BOOST set too high	- Check wiring - Check load - Check motor connection - Check parameter settings	6-3 5-6, 28.4-9
*** TRIPPED *** CURRENT LIMIT	Motor current $\geq 180\%$ rated current: - Shock load	- Remove cause for shock load	
*** TRIPPED *** SHORT CIRCUIT	IGBT-desaturation: - Motor output is short circuited - Earth fault	- Check motor circuit	
*** TRIPPED *** 24V FAILURE	24V control voltage ≤ 17 V: - External short circuit - Excessive load	- Check connection to 24 V control voltage	
*** TRIPPED *** LOW SPEED I	Motor current at zero frequency $> 100\%$: - FIXED BOOST or AUTO BOOST set too high	- Check parameter settings	5-6, 28.4-9
*** TRIPPED *** PHASE FAIL With MM6/ MM3SV only	Phase failure in supply (MM6 only): - Phase missing	- Check supply	

Refer to **Resetting a tripped condition**, page 6-3 for on how to reset a tripped condition.

"KEY INACTIVE" messages

The following messages indicate that an inhibited key action has been attempted:

* KEY INACTIVE * DRIVE RUNNING	Attempt modifying a parameter which can only be changed when drive is stopped.
* KEY INACTIVE * REMOTE SEQ	Attempt at giving a command which is correct be changed when in the REMOTE MODE.
* KEY INACTIVE * PARAMETER LINKED	Attempt at modifying a parameter which is already software-linked to a function module.
* KEY INACTIVE * LIMIT REACHED	Attempt at setting a parameter outside the permissible range.

"CHECKSUM FAIL"

Every time the MM456/MM3SV Frequency Inverter is powered up and initiated, the internal checksum is verified. Should a wrong checksum be produced, than is indicated as follows.

With Blank Cover:

LEDs: HEALTH and RUN flash

With Programming Pad:

All LEDs flash

CHECKSUM FAIL
DEFAULTS LOADED

Possible causes of this fault are:

- An internal assembly has been exchanged
- Power failure during **PARAMETER SAVE**
- MM456/MM3SV Frequency Inverter is faulty

A checksum fail fault can be best cured using the Programming Pad:

- Press key **Ⓜ** which will automatically reset the MM456/MM3SV Frequency Inverter to the factory default value to **MACRO 1**.

It may be necessary to reset the language of the LCD display (see page 4-6):

- On all account reprogramm the parameters for the particular applications with care before attempting to restart the drive.

Should the previous instructions for any reason not be successful then the MM456/MM3SV Frequency Inverter is probably damaged. See **Chapter 7 - SERVICING** for appropriate instructions.

OTHER FAULT FINDING

Problem	Possible Cause	Cure	see page
Inverter will not power up	<ul style="list-style-type: none"> ◆ Fuse blown ◆ Faulty cabling 	<ul style="list-style-type: none"> - Check supply details, replace with correct fuse - Check all connections are correct and secure - Check cable continuity 	
Inverter fuse keeps blowing	<ul style="list-style-type: none"> ◆ Faulty cabling or connections wrong ◆ Faulty inverter 	<ul style="list-style-type: none"> - Check for problem and rectify before replacing with correct fuse - Contact your supplier 	
Cannot obtain HEALTH state	<ul style="list-style-type: none"> ◆ Incorrect or no supply available 	<ul style="list-style-type: none"> - Check supply details 	
Motor will not run at switch-on	<ul style="list-style-type: none"> ◆ Motor jammed 	<ul style="list-style-type: none"> - Stop the inverter and clear the jam 	
Motor runs and stops	<ul style="list-style-type: none"> ◆ Motor becomes jammed 	<ul style="list-style-type: none"> - Stop the inverter and clear the jam 	
Motor runs at full speed only	<ul style="list-style-type: none"> ◆ Reversed tachogenerator or open circuit tachogenerator ◆ Open circuit speed reference potentiometer 	<ul style="list-style-type: none"> - Check tachogenerator connections - Check connections 	
Motor runs in wrong direction	<ul style="list-style-type: none"> ◆ Motor connection incorrect 	<ul style="list-style-type: none"> - Reverse two phases 	

Chapter 7 - SERVICING

	Page
MAINTENANCE	7-2
REPAIR	7-2
SAVING APPLICATION DATA BEFORE RETURNING EQUIPMENT	7-2
RETURNED EQUIPMENT	7-3
DISPOSAL.....	7-3

MAINTENANCE

MM456 Frequency Inverters are practically free of maintenance. However the following should be periodically inspected:

- Cooling system:
- MM422-EMC, MM522/540-EMC: Is the fan in operation?
 - MM6: Are all fans in operation?
 - Make sure cooling inlets of the enclosure are free from obstructions and dust build-up
 - As previous for cooling outlets
 - Verify that cooling air can circulate freely and that adequate enclosure cooling is available
- Mounting,
- Make sure the MM456 Frequency Inverter is securely mounted
- Terminals:
- Make sure all wires are securely clamped

REPAIR

The MM456 Frequency Inverters must not be repaired by the user. If repair is necessary return the unit to your supplier.



WARNINGS !

Before disconnecting the MM456 Frequency Inverter, ensure isolation of the main supply to terminals L1, L2, L3 and L1, N.

Wait for at least 3 minutes for the d.c. link terminals (DC+ & DC-) to discharge to safe voltage levels (<50 V), failure to do so constitutes a potentially lethal electrical shock hazard.

SAVING APPLICATION DATA BEFORE RETURNING EQUIPMENT

Although the MM456 Frequency Inverter retains parameter settings during power down, it is recommended that the Programming Pad is also used to record the valid settings and is not returned with the inverter. This is however possible if the inverter's microprocessor control is still functional. Use the PARAMETER SAVE | SAVE TO OP function (see page 5-14) to perform the parameter save to Programming Pad.

RETURNED EQUIPMENT

The following procedures are recommended in the unlikely event of a fault which necessitates return of a MM456 Frequency Inverter to your supplier:

- ◆ Contact your supplier to arrange return of the controller, if necessary. Your supplier will request the following information:
 - Type of MM456 Frequency Inverter
 - Serial number
- ◆ The return, repair or replacement procedure must be agreed with your supplier before returning equipment.
- ◆ Package and despatch the controller taking care that the packaging is environmentally suitable, recyclebar and provide ample transport protection.
- ◆ Make sure to include a detailed fault report. This will help shorten the repair time and reduce the repair cost.
- ◆ If polystyrene chips, or equivalent, are being used as a packing material then the MM456 Frequency Inverter must first be sealed in a polythene bag or similar, to prevent ingress of the packing material.

DISPOSAL

During transport, our products are protected by suitable packaging as far as necessary. The packaging consists entirely of environmentally compatible material that should be taken for central disposal as valuable secondary raw materials.

Contact the relevant Local Authority Department to obtain information on disposal facilities including disposal of old equipment.

Chapter 8 - EEC DIRECTIVES AND 'CE' MARKING, UL FOR USA AND CANADA

	Page
BASICS OF 'CE' MARKING	8-2
EMC DIRECTIVE	
Responsibility for EMC and 'CE' marking	8-3
Consideration of EMC environment.....	8-5
'CE' marking with built in EMC filters	8-7
'CE' marking with external EMC filters.....	8-7
Specification of achievable EMC emission and immunity	8-8
EMC responsibility of installers and users of	8-9
MM456 Frequency Inverters in installations	
EMC responsibility of manufacturers of apparatus.....	8-9
and machines sold as complete functional units	
EC Declaration of Conformity for EMC.....	8-10
Manufacturer's EMC Declaration	8-11
LOW VOLTAGE DIRECTIVE.....	8-12
MACHINERY DIRECTIVE	
Manufacturer's Declaration.....	8-13
UL FOR USA AND CANADA	8-14

BASICS OF 'CE' MARKING

The European Economic Community (EEC) has been created by the merger of the EC and EFTA countries. EEC represents one third of the world's electronic market. Unrestricted exchange of goods and products is ensured by having product specifications unified throughout Europe in the form of the EC Directives.

In addition to the MACHINERY DIRECTIVE, which has been in force since 1.1.1995, the EMC DIRECTIVE which has been obligatory since 1.1.1996, the LOW-VOLTAGE DIRECTIVE from 1.1.1997 is especially interesting when using AC drive converters.

Several basic comments are now explained which are the prerequisites for applying the 'CE' Mark.

- The 'CE' Mark is used as passport for products in the European Economic Community, and is only intended to secure unrestricted movement of products and goods. It is sufficient for the supervisory authorities as proof that the product was manufactured, with a high probability that all of the directives for a certificate of conformance, were fulfilled. This is certified using an EEC Declaration of Conformance, which refers to all of the applicable directives. The 'CE' Mark is only an administrative symbol which exclusively addresses the relevant supervisory authorities and demonstrates that all of the applicable legislation has been observed. Advertising with the CE Mark is considered as advertising with resource which is self-evident and is therefore not permissible (unfair competition).
- This means that the 'CE' Mark does not represent a symbol of quality to support product advertising.
- There is only one 'CE' Mark independent of the number of different Directives which are maintained (for instance, the extreme case involving toys which also have the 'CE' Mark due to the product standard which is valid for toys).
- Manufacturers or plant manufacturers may not subsequently withdraw a 'CE' Mark (e.g. if additional Directives are not fulfilled) (this step is for the exclusive use of the relevant authorities within the scope of sanctions)
- Manufacturers, distributors and users are responsible in observing the legislation directives regarding the selection of the associated regulation and standards with respect to the legislation.
- The product- and system/plant manufacturers are responsible in maintaining the EMC and additional specifications. These legal responsibilities cannot be transferred to suppliers, in this case business agreements apply.
- To support the system/plant manufacturer, appropriate declarations of conformance have been made available for the MM456.
- The product liability is exactly the same both with and without 'CE' Mark
- MM456 AC drive converters have been designed and manufactured so that the EMC Directive and other regulations are fulfilled. This is guaranteed using type tests and measurements which represent those typical for plants and systems.




EMC DIRECTIVE

Responsibility for EMC and 'CE' marking

The manufacturer is adhering to the CEMEP recommendations on 'CE' marking to the EMC DIRECTIVE with variable-speed power drive systems.

CEMEP is the "European Committee of Manufacturers of Electrical Machines and Power Electronics" and is the representative of the manufacturers of variable speed drives to the European Commission. A copy of these recommendations for the application of 'CE' marking to Power Drive Systems (PDS) including MM456 Frequency Inverters is available on request.

These CEMEP recommendations interpret the EEC DIRECTIVE 89/336/EWG for EMC (EMC-DIRECTIVE) in the application to Power Drive Systems are shown in Fig. 8.1.

Group definition with examples	EC Conformity, CE Marking, responsibility		
<p>Components</p>  <p>Components or spare parts which cannot be operated alone</p> <p>Electronic drive equipment such as MM456 Frequency Inverters</p>	<p>Intrinsic function *</p> <p>EC Declaration of Conformity CE mark</p> <p>Responsibility:</p> <ul style="list-style-type: none"> - Manufacturer/supplier of MM456 Frequency Inverter - User 	<p>Unrestricted distribution: e.g. Trade and retail outlets including DIY stores</p> <p>CEMEP-1 required</p> <p>CEMEP-2 not required</p> <p>CEMEP-3 not required</p> <p>CEMEP-4 required</p>	<p>Supply exclusive to EMC competent professional assemblers: e.g. manufacturers of machines, installers of industrial installations</p> <p>CEMEP-2 not required</p> <p>CEMEP-3 not required</p> <p>CEMEP-4 required</p> <ul style="list-style-type: none"> - Providing suitable EMC installation instructions - Final responsibility for EMC
<p>Installation</p>  <p>Installations which are assembled on site such as Pump stations, Chemical plants, Steel mills using MM456 Frequency Inverters</p>	<p>EC Declaration of Conformity CE mark</p> <p>Responsibility:</p> <ul style="list-style-type: none"> - Manufacturer/supplier of MM456 Frequency Inverter - Installation installer (and operating company) 	<p>CEMEP-3 not required</p> <p>CEMEP-4 required</p>	<p>CEMEP-3 not required</p> <p>CEMEP-4 required</p> <ul style="list-style-type: none"> - Not a mandatory requirement, but a suitable contribution to EMC is expected - The protection requirements of the EMC directive must be adhered to (EMC planning is recommended) - Final responsibility for EMC, in particular for preventing interference with neighbouring installations
<p>Apparatus, Machines</p>  <p>Apparatus and machines which are sold as a complete functional unit such as Vacuum cleaners, lathes, Palletising machines using MM456 Frequency Inverters</p>	<p>EC Declaration of Conformity CE mark</p> <p>Responsibility:</p> <ul style="list-style-type: none"> - Manufacturer/supplier of MM456 Frequency Inverter - Manufacturer of apparatus or machine 	<p>CEMEP-4 required</p>	<p>CEMEP-4 required</p> <ul style="list-style-type: none"> - Not a mandatory requirement, but a suitable contribution to EMC is expected - Final responsibility for EMC including issuing a Declaration of Conformity and 'CE' marking

* The term "intrinsic function" is being interpreted by the European Commission to mean components (such as MM456 Frequency Inverters) which have a function "directly usable" to the final user.

Fig. 8.11: Applying the EMC Directive according to the recommendations of CEMEP

According to the terminology of CEMEP, MM456 Frequency Inverters are "components". A clear distinction between the following two classes of components is required:

MM456 frequency inverters for exclusive supply to EMC competent professional assemblers, e.g. manufacturers of machines and apparatus and installers of industrial installations (CEMEP-2).

The majority of MM456 Frequency Inverters will be incorporated into a higher system consisting of a motor, cable, drive load and other drive or automation equipment by EMC competent professional assemblers.

The EMC DIRECTIVE **does not require** MM456 Frequency Inverters to be issued with an EMC Declaration of Conformity or 'CE' marked for supply to this type of user.

To assist EMC competent professional assembler using MM456 Frequency Inverters, the manufacturer confirms that a power drive system (PDS) using a MM45 Frequency Inverter with integrated EMC filter or MM6 with approved external EMC filter is EMC compliant to EN50081-1/2 and EN50082-1/2 (see tables on page 8-8 for more details) when installed in accordance with the **EMC INSTALLATION INSTRUCTIONS** on pages 3-9...18. A Manufacturer's EMC Declaration is included in the middle of this Product Manual. Professional assemblers may use this statement of compliance as the basis for their own justification of overall compliance with the EMC DIRECTIVE.

MM456 Frequency Inverter available to the general public e.g. through retail outlets, DIY stores, wholesales etc. (CEMEP-1)

For classification to CEMEP-1 for sale to end users, the MM456 Frequency Inverter must have an "intrinsic function". An example of such an intrinsic function where an existing fixed-speed motor application (such as a fan or a pump) is converted to variable speed drive by using a MM456 Frequency Inverter. In such an application the end user would not necessarily be expected to have EMC expertise. The MM45 Frequency Inverter with integrated EMC filter or MM6 with approved external EMC filter must be used. The 'CE' marking is valid provided the installation instruction on pages 3-9...18 are adhered to. The validity chart (Fig. 8.2) confirms the validity of the 'CE' mark for EMC (page 8-10).

'CE' mark on MM456 Frequency Inverter


The 'CE' mark for the LOW VOLTAGE DIRECTIVE is now mandatory, MM456 Frequency Inverters are corresponding 'CE' marked on the product rating label. This 'CE' mark only applies for EMC if the validity chart (Fig. 8.2) confirms validity (only possible with CEMEP-1 classification).

Validity of 'CE' mark for EMC

The validity chart in Fig. 8.2 provides the following EMC relevant information:

- Validity of EC Declaration of Conformity and 'CE' mark to EMC DIRECTIVE (page 8-9).
- Applying a 'CE' mark to the MM45 Frequency Inverter in accordance with the EMC DIRECTIVE in 1996.
- Requirements for obtaining 'CE' approval for apparatus or machines using MM456 Frequency Inverters

It must be clearly understood by the customer before installation commences who is legally responsible for 'CE' marking and conformance with the EMC DIRECTIVE. Misappropriation of the 'CE' mark is a criminal offence.



Please enquire for validity of wall mounted MM456 Frequency Inverters.

Fig. 8.2: Validity chart of the 'CE' mark for EMC with MM456 Frequency Inverter

Consideration of EMC environment

When considering the relevant EMC interference and immunity standards it is important to distinguish between the following classes of EMC environments:

	Supplied directly from the public electricity supply Commercial and light industry				Supplied from separate transformer station	
	Residential (including public buildings, banks, hospitals etc.)		Commercial and light industry where no residential are connected to same supply		Industrial installation	
	RF interference	Immunity	RF interference	Immunity	RF interference	Immunity
Basic and Generic Standards	EN55011 or EN50081-1 (Class B)	EN50082-1 see below for referenced standards	EN55011 or EN50081-1 (Class B)	EN50082-1 see below for referenced standards	EN55011 or EN50081-2 (Class A)	EN50082-2
EMC Product Standard for Power Drive Systems EN61800-3	Unrestricted distribution (CEMEP-1): < 25 A Class B > 25 A Class A Restricted distribution i.e. when installed by EMC competent professional assemblers (CEMEP-2): Class A permissible	see below for referenced standards ↓	EMC measures do not have to be implemented If interference in a neighbouring installation occurs, the operator is responsible for taking measures to prevent interference. In this case the required interference levels must be adhered to at the point of supply to the effected neighbouring installation.	see below for referenced standards ↓	EMC measures do not have to be implemented If interference in a neighbouring installation occurs, the operator is responsible for taking measures to prevent interference. In this case the required interference levels must be adhered to at the point of supply to the effected neighbouring installation.	see below for referenced standards ↓
Standards for immunity:	IEC1000-4-2:	Electrostatic discharge (e.g. from electrostatically charged persons)				
	IEC1000-4-3/6:	Electromagnetic fields (e.g. from portable telephones)				
	IEC1000-4-4:	Fast electrical transients (burst) (e.g. from opening contacts in inductive circuits)				
	IEC1000-4-5:	Voltage surges (e.g. on local lightning strikes, tripping large motor loads)				

NOTE: The EMC product drive standard is under review. More stringent limits for RF interference are expected soon.

Fig. 8.3: EMC Interference and Immunity Standards applicable to MM456 Frequency Inverters and similar equipment

The "Residential" and "commercial and light industry" **emission limits** (Class B) are more stringent than the "Industrial installation with a separate transformer station" limits, so equipment which meets EN50081-1 automatically meets EN50081-2.

The "Industrial" **immunity** requirements are more stringent than the "Residential" and "commercial and light industry" requirements, and equipment which meets EN50082-2 automatically meets EN50082-1.

More and more Product Specific standards are being released with less onerous EMC requirements than the Basic or Generic Standards. In accordance with EMC Drive Product Standard for Power Drive System EN61800-3 EMC filters are only **mandatory** in 'residential' type EMC environments.

The EMC Drive Product Standard and the CEMEP recommendations are discussed in more detail in the booklet MotorMaster "EMC Does and Don'ts" AF-MM-02 and in the Product Information PI-LKTM-005 available on request.

It is important for the customer to identify what EMC standards are to be applied to the final machine/system and in what EMC environment it will operate, so that any additional compliance costs can be minimised. It should be remembered that when two or more EMC compliant components are combined to form the final machine/system, the resulting machine/system may not be compliant. Emissions from combined components tend to be additive, while the immunity remains constant.

'CE' marking of MM45 with built-in EMC filter

MM45 Frequency Inverters with built-in EMC filter can be 'CE' marked (as in CEMEP-1) to comply with the mains terminal limits of EN55011 (or EN50081-1) Class B as indicated previously and when installed in accordance with the **EMC INSTALLATION INSTRUCTIONS** on pages 3-9...18. The Class B limit is the most stringent limit applied in Europe to date, and allows product to be used in either the "residential" and "commercial and light industrial" or "industrial" EMC environments. Refer to **Consideration of EMC environments**, page 8-5 for more details.

'CE' marking of MM6 with external EMC filter

MM6 Frequency Inverters can be 'CE' marked (as in CEMEP-1) when used with the specified matching EMC filters to comply with the mains terminal limits of EN55011 Class B (or EN50081-1) as indicated previously and when installed in accordance with the **EMC INSTALLATION INSTRUCTIONS** on pages 3-9...18. The Class B limit is the most stringent limit applied in Europe to date, and allows product to be used in either the "residential" and "commercial and light industrial" or "industrial" EMC environments. Refer to **Consideration of EMC environments**, page 8-5 for more details. Recommended matching EMC filters for MM6 Frequency Inverters are summarised in the table on page 8-2 and described in more detail on page 8-3. The fitment of the recommended matching EMC filter is **mandatory** where 'CE' marking is to be applied for EMC.

If the customer is treating the MM6 Frequency Inverter as a **Component for supply to EMC competent professional assemblers** (CEMEP-2) and is taking the EMC responsibility, then the EMC filters are optional and may assist the customer in achieving EMC compliance. Suitable filters are summarised in the table on page 8-2 and in more detail on page 8-3. In this situation the customer may also achieve compliance by less expensive more global measures depending on the limits to be achieved, such as the use of a combination of global or local filtering and screening methods, natural mitigation through distance or use of distributed parasitic elements of the existing installation.

The required EMC RF interference suppression and immunity for 'CE' marking of MM6 Frequency Inverter is only obtained when the **EMC INSTALLATIONS INSTRUCTIONS** on pages 3-9...18 are all carefully adhered to.

Specification of achievable EMC emission and immunity

MM456 Frequency Inverters with the option to be 'CE' marked meet the following EMC emission limits provided they are installed with the internal or recommended matching EMC filters for 'CE' marking in accordance with **EMC INSTALLATION INSTRUCTIONS**, page 3-9...18. Take note of the permissible cable length and restrictions on switching frequency as described on page 3-8.

Port	Phenomenon	Basic standard	Mounting	Level	Generic standard
Enclosure Port	Radiated	EN55011 (1998)	Suitable Metal enclosure+	Class B	EN50081-1 (1993)
			Wall mounting	Class A	EN50081-2 (1994)
Power Port	Conducted	EN55011 (1998)	all	Class B	EN50081-1 (1993) EN50081-2 (1994)

+ Ask your supplier for further information

All MM456 Frequency Inverters meet the following EMC immunity performance criteria as defined in EN50082-2 (1992) when installed and used as recommended.

Port	Phenomenon	Test standard	Test withstand level	Acceptance Criterion	Generic standard
Enclosure Port	ESD	IEC 801-2	6 kV CD, 8 kV AD	Self recovery	EN50082-1 (1993)
	RF Field	IEC 801-3	10 V/m, 1 kHz AM	No change	
Power Ports (supply voltage)	Fast Transient Burst	IEC 801-4	2 kV	Self recovery	EN50082-2 (1995)
	Surge	IEC 801-5	1 kV (P-P), 2 kV (P-E)	Self recovery	
Signal & Control	Fast Transient Burst	IEC 801-4	2 kV	Self recovery	
Power Interfaces	Fast Transient Burst	IEC 801-4	2 kV	Self recovery	

Internal or recommended matching EMC filters for MM456 Frequency Inverters may be flash tested in circuit up to d.c. 2850 V for 1 min. Ensure all other equipment that may be damaged by such flash testing has been suitably isolated/removed/short circuited as applicable. Due to the internal capacitors between phase and earth, the d.c. voltage should be wound up slowly, to prevent excessive earth current. For similar reasons a.c. flash testing cannot be performed due to the excessive earth leakage current. The repeated flash testing is not recommended as it may degrade the insulation.

EMC responsibility for installers and users of MM456 Frequency Inverters in installations

This section summarises the previous considerations for installers and users of MM456 Frequency Inverters in installations which are assembled on site (CEMEP-3).

For end users of MM456 Frequency Inverters, a correctly installed power drive system (PDS) created from the supplied MM456 Frequency Inverter together with integrated EMC filter will be compliant to the generic emission and immunity as previously indicated when installed in accordance to **EMC INSTALLATION INSTRUCTIONS** (see page 3-6).

EMC responsibility of manufacturers of apparatus and machines sold as complete functional units

This section summarises the previous considerations for manufacturers of apparatus and machines sold as complete functional units (CEMEP-4).

The manufacturer's confirmation that a correctly installed power drive system (PDS) consisting of a MM456 Frequency Inverter and recommended EMC filter (MM6 only) will be compliant to the relevant EMC standards (see page 8-8) can be used as the basis for justification of the overall compliance with the EMC DIRECTIVE. For this purpose a Manufacturer's EMC Declaration is included on page 8-11.

If the relevant apparatus or machine contains other electrical components than the PDS, then the complete apparatus or machine must be assessed against an appropriate EMC standards, since when two compliant pieces of electrical/electronic equipment are brought together, the whole may not be compliant.

If it is the responsibility of the manufacturer of the apparatus or machine sold as a functional unit to establish EMC conformity and to 'CE' mark. There are three methods of demonstrating EMC conformity:

- Self certification to a relevant standard
- Third party testing to a relevant standard
- Writing a technical construction file stating the technical rationale as to why the relevant apparatus is compliant. An EMC "competent body" must then assess this and issue a technical report or certificate to demonstrate compliance

Upon demonstrating EMC compliance an EC-Declaration of Conformity for the apparatus or machine may be issued and a 'CE' mark applied.

Professional end users with EMC expertise who are using MM456 Frequency Inverters and other equipment defined as components who supply, place on the market or install the relevant apparatus must take responsibility for demonstrating EMC conformance, applying the 'CE' mark and issuing an EC Declaration of Conformity.

EC Declaration of Conformity for EMC



Antriebstechnik

KIMO INDUSTRIE-ELEKTRONIK GmbH Am Weichselgarten 19 D-91058 Erlangen

KIMO INDUSTRIE-ELEKTRONIK GmbH

Am Weichselgarten 19
D-91058 Erlangen

TELEFON: (09131) 60 69-0
TELEFAX: (09131) 60 69-35

Ihr Zeichen:

Ihre Nachricht vom:

Unser Zeichen:
015er01a

Datum:

18. Juni 1999

EG-KONFORMITÄTSERKLÄRUNG

gemäss
**EG-RICHTLINIE 89/336/EWG,
ARTIKEL 10 sowie ANHANG I
(EMV-RICHTLINIE)**

Wir, KIMO INDUSTRIE-ELEKTRONIK GmbH,
Adresse wie oben, erklären in alleiniger
Verantwortung

EC DECLARATION OF CONFORMITY

in Accordance with the
**EEC DIRECTIVE 89/336/EEC,
ARTICLE 10 and ANNEX I
(EMC DIRECTIVE)**

We KIMO INDUSTRIE-ELEKTRONIK GmbH,
address as above, declare under our sole
responsibility that the following electronic equipment

**MotorMaster MM407-EMC, MM415-EMC
MotorMaster MM515-EMC, MM522-EMC, MM540-EMC**

bei Installation unter Berücksichtigung aller Anweisungen in der Produktbeschreibung (mit jedem Gerät geliefert) mit den folgenden Normen übereinstimmt: when installed in accordance with the instructions in the Product Manual (provided with each piece of equipment) is in Conformity with the following standards:

EN50081-1 (1992) (Leitungsgebundene Störungen)
EN50081-2 (1994) (Funkabstrahlung)
EN50082-1 (1992) & Entwurf prEN50082-2 (1992)

EN50081-1 (1992) (conducted emissions)
EN50081-2 (1994) (radiated emissions)
EN50082-1 (1992) & draft prEN50082-2 (1992)

gemäß den Bestimmungen der EG-RICHTLINIE

following provisions of the EEC-DIRECTIVE

**89/336/EWG mit Änderungen
92/31/EWG sowie 93/68/EWG.**

**89/336/EEC with amendments
92/31/EEC and 93/68/EEC.**

KIMO INDUSTRIE-ELEKTRONIK GmbH

John P. Gibson
Hr. Dr. John P. Gibson
Produktmanager - Product Manager

Roland Lutz
Dipl.-Ing (FH) Roland Lutz
Qualitätswesen - Quality Assurance

Managing directors:
Company reg.:
Dipl.-Ing. Klaus Recker
Dr.-Ing. Rolf Mayer
HRB 3933 Fürth

Sparkasse Erlangen
Konto Nr. 29-002120
BLZ 763 500 00



Manufacturer's EMC declaration

Not to be confused with a "Declaration of Conformity".



KIMO INDUSTRIE-ELEKTRONIK GmbH Am Weichselgarten 19 D-91058 Erlangen

ELEKTRONIK GmbH

Am Weichselgarten 19
D-91058 Erlangen

TELEFON: (09131) 60 69-0
TELEFAX: (09131) 60 69-35

Ihr Zeichen:

Ihre Nachricht vom:

Unser Zeichen:
015eh01a

Datum:
18. Juni 1999

EMV - HERSTELLERERKLÄRUNG

MANUFACTURER'S EMC DECLARATION

Die nach

**MotorMaster MM407-EMC, MM415-EMC
MotorMaster MM515-EMC, MM522-EMC, MM540-EMC**

sind konform mit den folgenden Normen:

are declared in conformity with the following standards:

EN50081-1 (1992) (Leitungsgebundene Störungen)

EN50081-1 (1992) (conducted emissions)

EN50081-2 (1994) (Funkabstrahlung)

EN50081-2 (1994) (radiated emissions)

EN50082-1 (1992) & Entwurf prEN50082-2 (1992)

EN50082-1 (1992) & draft prEN50082-2 (1992)

Vorausgesetzt alle Anweisungen der zugehörigen Produktbeschreibungen (geliefert mit jedem Gerät) wurden beachtet.

Provided all installation instructions in the Product Manual (provided with each piece of equipment) are adhered to.

KIMO INDUSTRIE-ELEKTRONIK GmbH

ppa. Dr. John P. Gibson
Produktmanager - Product Manager

Dipl.-Ing. (FH) Roland Lutz
Qualitätswesen - Quality Assurance

Managing directors:
Dr.-Ing. Rolf Mayer
Company reg.: HRB 3933 Fürth

Sparkasse Erlangen
Konto Nr. 29-002120
BLZ 763 500 00



LOW VOLTAGE DIRECTIVE

The LOW VOLTAGE DIRECTIVE requires 'CE' marking of all electrical equipment that is brought into service in the European Community. All MM456 Frequency Inverters are 'CE' marked on the name plate to indicate compliance with the LOW VOLTAGE DIRECTIVE.



KIMO INDUSTRIE-ELEKTRONIK GmbH, Am Weichselgarten 19, D-91058 Erlangen

KIMO INDUSTRIE-ELEKTRONIK GmbH

Am Weichselgarten 19
D-91058 Erlangen

TELEFON: (09131) 60 69-0
TELEFAX: (09131) 60 69-35

Ihr Zeichen:

Ihre Nachricht vom:

Unser Zeichen:
015nr01a

Datum:
18. Juni 1999

EG-KONFORMITÄTSERKLÄRUNG

gemäss
EG-RICHTLINIE 73/23/EWG,
und Änderung durch 93/86/EWG
ARTIKEL 13 sowie ANHANG III
(NIEDERSpannungs-RICHTLINIE)

Wir, KIMO INDUSTRIE-ELEKTRONIK GmbH,
Adresse wie oben, erklären in alleiniger
Verantwortung

EC DECLARATION OF CONFORMITY

in accordance with the
EEC DIRECTIVE 73/23/EEC,
and amended by 93/86/EEC
ARTICLE 13 and ANNEX III
(LOW VOLTAGE DIRECTIVE)

We KIMO INDUSTRIE-ELEKTRONIK GmbH,
address as above, declare under our sole
responsibility for the following electronic equipment

**MotorMaster MM407-EMC, MM415-EMC
MotorMaster MM515-EMC, MM522-EMC, MM540-EMC
MotorMaster MM655, MM675, MM6110
MotorMaster MM655, MM675, MM6110**

bei Installation unter Berücksichtigung aller Anwei-
sungen in der Produktschreibungs (mit jedem
Gerät geliefert) mit der folgenden Norm überein-

when installed in accordance with the instructions in
the Product Manual (provided with each piece of
equipment) is in conformity with the following

stimmt:

standard:

VDE0160 (1994) / prEN50178 (1996)

VDE0160 (1994) / prEN50178 (1996)

gemäß den Bestimmungen der EG-RICHTLINIE
72/23 EWG mit Änderung 93/68/EWG.

following the provisions of the EEC-DIRECTIVE
72/23 EWG with amendment 93/68/EWG.

KIMO INDUSTRIE-ELEKTRONIK GmbH

ppa. J. P. Gibson
ppa. Dr. John P. Gibson
Produktmanager - Product Manager

R. Lutz
Dipl.-Ing (FH) Roland Lutz
Qualitätswesen - Quality Assurance

Managing Director: Dipl.-Ing. Klaus Becker Sparkasse Erlangen

directors: Dr.-Ing. Rolf Mayer
Company reg.: HRB 3933 Fürth

Konto Nr. 29-002120
BLZ 763 500 00

DIN EN ISO 9001




TAW Cert
Zert.Nr.: 1902110

MACHINERY DIRECTIVE

The MACHINERY DIRECTIVE requires 'CE' marking of the complete machine. MM456 Frequency Inverters are classified as components and therefore 'CE' marking to the MACHINERY DIRECTIVE is not applicable.

However a "Manufacturer's Declaration" (not to be confused with a "Declaration of Conformity") defining safety consideration may be required by some machine builders.



Antriebstechnik

KIMO INDUSTRIE-ELEKTRONIK GmbH, Am Weichselgarten 19, D-91058 Erlangen

KIMO INDUSTRIE-ELEKTRONIK GmbH

Am Weichselgarten 19
D-91058 Erlangen

TELEFON: (09131) 60 69-37
TELEFAX: (09131) 60 69-35

Ihr Zeichen: _____ Ihre Nachricht vom: _____

Unser Zeichen: **015mr01a** Datum: **18. Juni 1999**

HERSTELLERERKLÄRUNG

gemäss
EG-RICHTLINIE 89/392/EWG,
ART. 4, ABS. 2, sowie ANH. II B
(MASCHINENRICHTLINIE)

Die nachfolgende
**MotorMaster MM407-EMC, MM415-EMC
MotorMaster MM515-EMC, MM522-EMC, MM540-EMC
MotorMaster MM655, MM675, MM6110**

MANUFACTURERS DECLARATION

in accordance with the
EEC DIRECTIVE 89/392/EEC,
CHAP. 4, PAR. 2, and APPENDIX II B
(MACHINERY DIRECTIVE)

sind nicht selbständig betreibbare Komponenten
und nur zum Einbau in Maschinen/Anlage bestimmt

Die Maschine oder Anlage darf erst dann in Betrieb genommen werden, wenn die Schutz- und Sicherheitsanforderungen der **RICHTLINIE 89/392/EWG** vollständig erfüllt sind.

Desweiteren wird auf
EN 60204-1 (Sicherheit von Maschinen - Elektrische Ausrüstung von Maschinen)

verwiesen. Die in der jeweiligen Produktbeschreibung aufgeführten Anweisungen, Warnungen und Sicherheitshinweise sind zusätzlich zu beachten.

KIMO INDUSTRIE-ELEKTRONIK GmbH

[Signature]
Hr. Dr. John P. Gibson
Produktmanager - Product Manager

are components to be incorporated into machinery
and may not be operated alone

The complete machinery or installation using this equipment may only be put into service when the safety considerations of the **DIRECTIVE 89/329/EEC** are fully adhered to.


Particular reference should be paid to
EN 60204-1 (Safety of Machinery - electrical Equipment of Machines).

All instructions, warnings and safety relevant information of the Product Manual must also be adhered to.

[Signature]
Dipl.-Ing (FH) Roland Lütz
Qualitätswesen - Quality Assurance

Managing directors: Dipl.-Ing. Klaus Recker
Company reg.: Dr.-Ing. Rolf Mayer
HRB 3933 Fürth

Sparkasse Erlangen
Konto Nr. 29-002120
BLZ 763 500 00



UL FOR USA AND CANADA

UL listing for the USA and c-UL listing for Canada in accordance with UL508C have been applied for. Without the top cover fitted MotorMaster MM456 Frequency Inverters meet the requirement of an "Open-Type" piece of equipment. With the top cover fitted, the requirements of "Type 1 Enclosed" for direct wall mounting are fulfilled. These listings are only valid if the **Special considerations for installation in compliance with UL**, page 1-11 are adhered to.

UL:



UL:



Chapter 9 - OPTIONS

	Page
POWER RELATED OPTIONS	
Summary of available options	9-2
Glands for screened motor cables	9-2
External EMC filters type FB	9-3
Line- and motor chokes	9-4
NEMA 1 top cover	9-6
External braking resistors	9-7
OTHER OPTIONS	
Programming pad	9-9
Operating panel	9-12
Relais module	9-12
RS232 serial-interface connecting cable.....	9-12
RS485/422 serial-interface	9-13
PROFIBUS-DP option module.....	9-13
CAN option module.....	9-14
KIMOVIS PC software	9-15
Encoder option module for MM6.....	9-18

POWER RELATED OPTIONS


Summary of available options

MM456 Frequency Inverter	Gland for screened motor cable	EMC Filter	Chokes Line	Motor	Top cover NEMA 1	Braking resistors		
						leichtes Bremsen	high braking torque	high braking torque and heavy braking operation
MM407-EMC	OPTION MM-MOT- GLAND- P16	integrated (Class B)	MM- L415/2	MM-L302	MM45-NA1	200BR0004	100BR001	100BR006
MM415-EMC						100BR001		
MM422-EMC			auf Anfrage	MM-L305	MM45-NA2		100BR006	100BR012
MM515-EMC			MM-L302	MM-L302		200BR0004	100BR001	100BR006
MM522-EMC						100BR001	100BR006	100BR012
MM540-EMC			auf Anfrage	MM-L302				
MM655	OPTION MM-MOT- GLAND- P21	FB311	MM-L305	MM-L305	MM6-NA3	100BR001	100BR006	100BR006
MM675			MM-L307	MM-L307		100BR006	39BR006	39BR012
MM6110			MM-L318	MM-L318		100BR012	39BR012	39BR050
Further Info	Page 9-2	Page 9-3	Page 9-5	Page 9-6	Page 9-7	Page 9-7	Page 9-7	

Refer to **EMC INSTALLATION INSTRUCTIONS** (pages 3-9...18) and **EMC DIRECTIVE** (pages 9-2...9) for important information on adhering to the EMC DIRECTIVE

GLANDS FOR SCREENED MOTOR CABLES

Equipment code	Electrical data	Order no.
OPTION MM-MOT-GLAND-P16	Motor cable gland	8629.005-116
OPTION MM-MOT-GLAND-P21	Motor cable gland	8629.005-121



External EMC filters type FB (Recommended matching EMC filters for the EC Declaration Conformity for EMC)

Equipment code	Electrical data	Order no.
FN 3258-30/07 FB311	7.5-15 kW, 480 V, 34 A, EMC filter	8613.320-400

Refer to **EMC INSTALLATION INSTRUCTIONS** (pages 3-6...14) and to **EMC DIRECTIVE** (pages 8-3...11) for important information on adhering to the EMC DIRECTIVE




Fig. 9.1: Outline drawings and mounting - OPTION FB311 (new type)

Line and motor chokes

Equipment code	Electrical data	Order no.
OPTION MM-L415/2	1.5-2.2kW, Line choke	8614.211-100
OPTION MM-L302	2.2-4.0kW, Line or motor choke	8614.312-100
OPTION MM-L305	4.0-7.5kW, Line or motor choke	8614.316-100
OPTION MM-L307	7.5-11 kW, Line or motor choke	8614.317-100
OPTION MM-L318	11-22 kW, Line or motor choke	8614.322-100




Fig. 9.2a: Outline drawings and mounting OPTION L415/2




Fig. 9.2b: Outline drawings and mounting OPTION L302/L305




Fig. 9.2c: Outline drawings and mounting OPTION L307





Fig. 9.2d: Outline drawings and mounting OPTION L318

NEMA 1 top cover

Equipment code	Electrical data	Order-no.
OPTION MM45-NA11	NEMA1 Cover 1	8629.011
OPTION MM45-NA12	NEMA1 Cover 2	8629.012
OPTION MM6-NA13	NEMA1 Cover 3	8629.013


The NEMA 1 top cover provides protection to IP4X on the upper surface (no falling part can enter the MM456 Frequency Inverter) and therefore satisfies the requirements of EN 50178 for wall mounting. This is particularly important in Europe as EN 50178 can serve as the basics for demonstrating conformance to the EC LOW-VOLTAGE DIRECTIVE responsible for the safety of electrical equipment.

Tighten top cover to 1.2 Nm torque.



**Fig. 9.3a: OPTION MM45-NA11
for MM407...MM415-EMC**

**Fig. 9.3b: OPTION MM45-NA12
for MM422...MM540-EMC**



**Fig. 9.3c: OPTION MM6-NA13
for MM655...MM6110**

Outline drawing and mounting for NEMA 1

External braking resistors

Equipment code	Electrical data	Order no.
OPTION 200BR004	200 Ohm, 0.044 kW, braking resistor	8601.207-100
OPTION 100BR001	100 Ohm, 0.08 kW, braking resistor	8601.213-100
OPTION 100BR006	100 Ohm, 0.6 kW, braking resistor	8381.101-601
OPTION 100BR012	100 Ohm, 1.2 kW, braking resistor	8381.101-122
OPTION39BR006	39 Ohm, 0.6 kW, braking resistor	8381.340-006
OPTION39BR012	39 Ohm, 1.2 kW, braking resistor	8381.340-012
OPTION39BR050	39 Ohm, 5.0 kW, braking resistor	8381.340-050

Braking resistors OPTION 100BR006...39BR050 have an integrated overtemperature thermostat which should be connected in the external monitoring circuit of the MM456 Frequency Inverter.




Fig. 9.4a: Outline drawing and mounting OPTION 200BR004





Fig. 9.4b: Outline drawing and mounting OPTION 100BR001






Fig. 9.4c: Outline drawing and mounting **OPTION 100BR006**





Fig. 9.4d: Outline drawing and mounting **OPTION 100BR012**



OPTION 39BR050: **b 395 mm**

Fig. 9.4e: Outline drawing and mounting **OPTION 39BR050**

OTHER OPTIONS

Programming pad (with Option for remote mounting)

Equipment code	Electrical data	Order no.
OPTION MM-PROG-PM	Programming pad	8629.001
OPTION MM-PROG	Programming pad	8629.002

Refer to Fig. 1.1, page 1-3 and PROGRAMMING PAD, page 4-2 for more details.


The mounting kit for remote mounting consists of a mounting frame which allows the programming pad to be mounted on the door of an electrical enclosure and a 3 m connecting cable to the MM456 Frequency Inverter. The protection class IP54 can be achieved with the recommended mounting instructions.



**Fig. 9.5: Mounting drawing for remote mounting of the Programming Pad
with OPTION MM-PROG-PM**

Operating panel

Equipment code OPTION MM-OP	Electrical data Operating panel	Order no. 8629.006
--------------------------------	------------------------------------	-----------------------



The operating panel consists of the blank cover with prewired ON/OFF switch and setpoint potentiometer mounted. These components should be connected as shown in Fig. 10.1a., page 10-3. This provides a complete functional inverter unit for application requiring easy basic control with wall-mounting (see also NEMA 1 top cover, page 9-6).

Fig. 9.6: Operating panel

Relais modules

Equipment code	Electrical data	Order no.
OPTION MM45-RELAY-DC24V	Relay module DC24V	8629.051
OPTION MM45-RELAY-DC12V	Relay module DC12V	8629.053
OPTION MM45-THERMISTOR	Motor protection	8629.052

The DC 24 V version is a miniature relay with LED for mounting on 35 mm DIN rails suitable as an interface relay for the two 24 V digital outputs.

The DC 12V version is similar to the previous relay but suitable for operation at 12 V. With appropriate programming the analog output of the MM456 Frequency Inverter can be used as a digital output with the help of this relay.

The thermistor protection relay is to provide motor protection based on a thermistor sensor in the motor winding for MM45 Frequency Inverters. This protection relay is also suitable for mounting on 35 mm DIN rails.

RS232 serial interface connecting cable

Equipment Code	Electrical data	Order no.
OPTION MM-RS232	RS232 Connecting cable	8616.001

To connect a Personal Computer to connector P3 of the MM456 Frequency Inverter this special cable is required. The connecting cable is 3 m long and terminates in a 9-pole Sub-D connector. A standard 25/9-pole adapter should be used to provide a 25-pole Sub-D connection if required.

P3 Port

Pin	1	2	3	4
Lead	Black	Red	Green	Yellow
Signal	0 V	5 V	T X	R X



9-pole Sub-D Connector

Pin	1	2	3	4
Lead	Black	Red	Green	Yellow
Female pin of 9-pole connector	5	not connected	3	2
Female pin of 25-pole connector*	7	not connected	2	3

*If 25/9-pole adapter used

Note: There is 5 V present on pin 2 of the P3 port. This may damage a PC to which the connection cable is connected. This lead should on no account be connected to the PC.


RS485/422 Serial Interface

Equipment Code	Electrical data	Order no.
OPTION MM45-RS485/422	RS485/422 Interface	8629.021
OPTION MM6-RS485/422	RS485/422 Interface	8629.026

This option provides an optoisolated RS422/485 serial data port to allow an intelligent device to monitor or update the parameters of a network of 32 MM456 Frequency Inverters.

As the ASCII mode is more commonly used this is used as the basis for the following information:

Transmission standard:	RS485 (RS422) (bi-directional)
Basic protocol:	ANSI-X3.28-2.5-B1
Data rates:	300, 600, 1200 ,2400, 4800, 9600 or 19200 baud
Character format (300 to 9600 baud):	ASCII + 1 start, 1 parity and 1 stop bit [10 bit]
Parity:	Defaults to Even



For further information refer to the Product Manual TMMRS485E.

Fig. 9.7: RS485/422 Serial Link Option Board

PROFIBUS-DP option module

Equipment Code	Electrical data	Order no.
OPTION MM45-PROFIBUS-DP	PROFIBUS-DP bus interface	8629.022
OPTION MM6-PROFIBUS-DP	PROFIBUS-DP bus interface	8629.027

PROFIBUS-DP is the performance-optimized version of PROFIBUS, specifically dedicated to time-critical communication between automation systems such as PLCs and distributed peripherals such as MM456 Frequency Inverters. It is suitable as a replacement for the costly parallel wiring of 24 V control and 4 (0)...20 mA analogue signals.

PROFIBUS-DP is based on DIN 19245 T1 and uses application-orientated extensions as defined in DIN 19245 T3. As part of the European standardisation of field bus systems PROFIBUS-DP is integrated in the draft standard for field bus systems pr EN 50170. The basic specification of PROFIBUS-DP as implemented by the OPTION MM456 PROFIBUS-DP option module is as follows:

- Transmission technology: - EIA RS485 twisted cable pair
- max. distance 200 m at 1.5 MBaud extendible with repeaters
- Basic protocol: - DIN 19245 part 3
- Data rates: - 1.5 MBaud (extension to 12 MBaud planned)
- PROFIBUS-DP services: - fast read/write
 - random access write
 - diagnostic read
 - broadcast/multicast (synchronise and freeze)
- Device type: - DP-Slave
- Status indication: - various LEDs

For further information refer to the Product Manual TMMPBDPEE.

CAN option module

Equipent code	Electrical data	Order-no.
OPTION MM45-	.	

Please enquire for details

KIMOVIS PC software

Equipment Code	Electrical data	Order no.
OPTION MM-KIMOVIS-W	PC program KIMOVIS f. WINDOWS	8618.001
OPTION MM-KIMOVIS-D	PC program KIMOVIS f. DOS	8618.002





Fig. 9.8a: Example for programming with OPTION MM-KIMOVIS-W for MS-WINDOWS








Fig. 9.8b: Example for programming with OPTION MM-KIMOVIS-D for MS-DOS

Encoder option module for MM6

Equipment code	Electrical data	Order-no.
OPTION MM6-ENCODER-RS422	Encoder input	8629.041
OPTION MM6-ENCODER-HTTL	Encoder input	8629.041-100

For further information refer to the Product Manual TMMENCE.

Chapter 10 -APPLICATION NOTES

	Page
APPLICATION NOTES.....	
General	10-2
EMC considerations	10-2
Minimum connection requirements	10-2
Brake motors	10-5
Synchronous motors with reluctance or permanent magnet rotors	10-5
Slip-ring induction motors	10-5
High-speed motors.....	10-6
Pole-change motors	10-6
Using line chokes.....	10-6
Using motor chokes	10-6
Using multiple motors on a single drive MM456 Frequency Inverter	10-7
Switching at the inverter output	10-8
High starting torque	10-8
Operation at higher-rating quadratic torque (HVAC) for fans and pumps..	10-9
SETTING UP THE SENSORLESS VECTOR FLUXING MODE	
Required motor parameters.....	10-10
Auto identification of motor parameters using Autotune-	10-10
Entering motor parameters from known equivalent circuit.....	10-11
Entering motor parameters from simple measurement	10-11

General


Relays:	Always use gold flash relays, or others designed for low current operation (5 mA), on all control wiring.
Analogue inputs and outputs:	Screened control cable should be used for analogue inputs and outputs. The screen should be connected to earth in the near vicinity of the inverter.
Digital inputs and outputs:	The control cable for digital inputs and outputs should be preferably screened. The screen should be connected to earth at the near vicinity of the inverter and also to earth at the far end.
Cable layout:	Make sure control cables are run separate from power cables.
Service isolator:	With some applications it is necessary or established practice to install an isolator between the inverter and the motor. This isolation should only be switched when the inverter is inhibited. RECOMMENDATION: Make use of an isolator with an advanced-timed auxiliary contact connected in the Ext. Trip Circuit. This will interrupt the current before the main isolator contacts open.
Power-factor correction equipment:	All power factor correction equipment must be removed from the motor before the MM456 Frequency Inverter can be used.
Suitable motors:	Motors with a low efficiency or $\cos \phi$ (power factor) should be avoided since they require a larger kVA rated inverter to produce the correct shaft power. Motors with an installation class F or above are recommended.

EMC considerations


Pay careful attention to the recommendations in Chapter 3 and 7 concerning EMC. Further information is available in the booklet MotorMaster EMC "Does and Don'ts" AF-MM-02.

Minimum connection requirements

The diagram below shows the minimum connection requirements in order to operate the MM456 Frequency Inverter.





MM45



MM6

Fig. 10.1: Minimum connection requirements without Programming Pad with switch and potentiometer (Blank cover with prewired switch and potentiometer is available as OPTION MM-OP)



MM6

Fig. 10.2: Minimum connection requirements with Programming Pad if LOCAL mode is selected

Brake motors

Brake motors are used in many applications requiring a mechanical brake for safety or other operational reasons. The brake motor is usually one or the two following types:

- ◆ Standard induction motor fitted with an externally-fed electromechanical brake. MM456 Frequency Inverters have an integrated brake-control logic which must be set correctly (refer to **Software and Application Manual TMM456/3SV-SAM**, page 28.3-12, **BRAKE CONTROL**).
- ◆ Conical brake motors utilize a brake activated by the axial displacement of the squired-cage rotor. With this type of motor, the starting current is relatively high due to the large air gap. Make sure the maximum inverter current is sufficient to pull-in the conical rotor. If in doubt refer to your supplier. It is important to set the **SETUP PARAMETERS |QUI CK SETUP |FIXED BOOST** parameter, see page 5-6, to ensure reliable brake release with conical-rotor brake motors.

Synchronous motors with reluctance or permanent magnet rotors

Although intended primarily for use with induction (asynchronous) motors, MM456 Frequency Inverters can also be used for speed control of synchronous motors. Synchronous motors can offer economic solutions in applications where tight control of speed is required together with the low maintenance characteristics of an AC motor.

MM456 frequency inverters are suitable for operation with synchronous motors. The correct setting of the V/f characteristic is essential for the correct operation.

Typical applications are in the glass, textile and man-made fibre industry or for simple positioning applications.

In contrast to induction motors, synchronous motors run at synchronous speed whether on no load or full load. Synchronous speed is set by the frequency of the supply applied to the stator. The stator flux can be kept constant by keeping the stator volts/frequency ratio constant as with an induction motor.

Torque is produced in the motor by a increase in load angle between the stator and rotor fluxes. Maximum torque occurs when the load angle approaches 90°. If the load angle exceeds this value then torque drops and the motor will stall. Systems involving synchronous motors need careful design to ensure that the motor can accelerate the load and handle transient load changes without stalling.

NOTE: Set **SETUP PARAMETERS |QUI CK SETUP |BASE FREQUENCY** to data on motor ratings plate, see page 5-4.

Slip-ring induction motors

There is no particular problem using a MM456 Frequency Inverter with a slip-ring induction motor provided the starting resistors are bridged.

High-speed motors

High speed motors with speed often greater than $15,000 \text{ min}^{-1}$ are often used in the wood making and other industries. Special high-frequency motors are required. These high-frequency motors usually have a very low inductance leakage and therefore require a motor choke installed between the inverter and the motor. Please refer to your supplier for advice with such applications.

Pole-change motors

Pole changing during operation is not permissible as high-energy voltage surges occur which can damage the MM3 Frequency Inverter. If pole-changing is required, control circuit to inhibit the inverter for at least 1 s during and following pole-changing must be provided for.

Using line chokes

MM456 frequency inverters are fitted with DC link chokes to limit the ripple current seen by the DC link capacitors and thus increase their working life. Line chokes are therefore not essential.

However line chokes may be used to further reduce the harmonic content of the supply current where this a particular requirement of the application or where greater protection from mains borne transients is required. This and other advantages are:

- High energy voltage transients such as can be caused by switching the steps of capacitor compensation equipment are reduced at the inverter input.
- With short-duration supply interruptions, the charging circuit for the link capacitors of the MM456 Frequency Inverter is not active. A very high charging current can flow with low supply impedance. An excessive charging current can overstress the input rectifier and link capacitors.
- The current harmonics in the d.c. link are reduced which can result in a longer working life of the link capacitors.

See page 8-4 for details on available line chokes.

Using motor chokes

Installations with motor cable runs in excess of 50 m may suffer from nuisance overcurrent trips. This is due to the capacitance of the cable causing current spikes to be drawn from the inverter output. A choke may be fitted in the inverter output which limits the capacitive current. Screened cable has a higher capacitance and may cause problems in shorter runs (typically in excess of 30 m). See page 8-4 for details on available motor chokes.

Using multiple motors on a single MM456 Frequency Inverter

It is possible to use a single large inverter to supply several smaller motors provided the following is taken into consideration:




Fig. 10.6: Multiple motors on a single MM456 Frequency Inverter

- The drive must be rated to supply the **total current of all motors**. It is not sufficient to simply sum the power ratings of the motors, since the drive has also to supply the magnetising current for each motor.

Sensorless vector control is not suitable for multi-motor drives. Make sure that VECTOR ENABLE, see page 5-9, is FALSE.

- Each motor must be overload protected e.g. with thermal overcurrent relays connected in series (EXT. TRIP, TERMINAL 23).
- With installation using motor powers of significantly different powers (e.g. 1:3), the smallest motor may have difficulty starting or running at low speed. This due to the relatively high stator resistance which would require a high boost level. Too high boost could cause the larger motor to saturate with a resulting loss in starting torque. A solution to this problem is to increase the frame size of the smaller motors.
- A current-based overload device will not prevent the motor overheating due to inadequate cooling at low speed. Force vented motors may be required. Consult your motor supplier.

- Individual motors may be switched and/or reversed using contactors provided that the peak transient currents do not exceed the maximum inverter current.



CAUTION!

With multiple motor installations the total cable length should not exceed the values given in EMC INSTALLATION INSTRUCTIONS, page 3-9...11. If in doubt refer to your supplier.

Switching at the inverter output

The use of contactors to disconnect a motor from an inverter operating under load is in principle possible. This method of disconnecting the load should however only be used for infrequent emergency purposes. The use of this method for normal operation would stress the power electronic components and reduce the working life.

The use of contactors in connection with an arrangement to inhibit the inverter at least 50 ms before closing or opening the contractor **is permissible**.

High starting torque

In development

Operation with higher-rating quadratic torque for fans and pumps (HVAC)

The HVAC higher rating for fans and pumps with a quadratic load characteristic has the disadvantage that a much lower overload capability is available. If problems occur the following recommendations should be of assistance:

Problem	Recommendation to overcome problem
Starting torque not sufficient, *** TRIPPED *** I * T TRIP with trip	<p>Check setting of FULL LOAD CALI B see page 5-5.</p> <p>Setting V/F SHAPE to LI NEAR (see page 5-5) will give a high starting torque at the expense of small reduction in efficiency at low speeds. This change is particularly recommended when 'V' belts are used.</p> <p>Increase FI XED BOOST (see page 5-6) as is required while avoiding excessive boost. Also activate SETUP PARAMETERS FUNCTION BLOCKS MOTOR CONTROL FLUXING BOOST AUTO to increase boost during starting.</p> <p>Increase RAMP ACCEL RATE (see page 5-5) to reduce starting-torque requirement to accelerate high inertia loads.</p>
Inverter trips with Alarm *** TRIPPED *** MOTOR STALLED after several minutes	<p>Motor load is too high, the inverter therefore operates in current limit with reduced frequency. To prevent this Trip increase parameter (see page 28.4-9) increase parameter SETUP PARAMETERS FUNCTION BLOCKS TRIPS STALL TRIP STALL LIMIT to 150.00 %</p>
Heavy duty starting or high ambient temperatures	<p>With applications involving heavy-duty starting (e.g. with high inertia fan) or with a high ambient temperature it is recommended that a MM456 Frequency Inverter rated for the motor power with constant torque is provided for.</p>
Automatic start on connecting power ?	<p>Set parameter SETUP PARAMETERS FUNCTION BLOCKS SEQ & REF SEQUENCING LOGIC POWER UP START to TRUE.</p>

NOTE: When using MM456 Frequency Inverter with larger motor for HVAC applications the settings as above should be used. Never forget to **save parameters** after modifying any parameter setting, see page 4-9 and 5-14.

The previous settings for operation with high-rating quadratic load with pumps and fans (HVAC) can also be set with the sets of the Application Software **ASM-K02 - Variable Speed Control of Fans in Ventilation Applications (HVAC)**. Also useful functions such as:

- Operation with preset speeds
- Operation with PID controller are configured and set suitable for most applications are provided for.
- Auto-restart logic preset for operation with pumps and fans.

SETTING UP THE SENSORLESS VECTOR FLUXING MODE

Required motor parameters

Before using the sensorless vector fluxing mode the MM456 Frequency Inverter must be tuned to the motor in use by matching the motor parameters in the Inverter to those of the motor being controlled. The most important motor parameters are:

- Per phase stator resistance
- Per phase leakage inductance
- Per phase mutual (magnetising) inductance

Tuning can be performed by one of the following methods:

- Auto identification of motor parameters using AUTOTUNE
- Entering motor parameters from known equivalent circuit
- Entering motor parameters determined from simple measurements each of which are described in detail in the following.

Before proceeding with one of these methods, the following basic motor parameters must be entered:

- In menu **SETUP PARAMETERS | QUICK SETUP**:
BASE FREQUENCY
FULL LOAD CALIB
POWER FACTOR
- In menu **SETUP PARAMETERS | VECTOR SETUP**:
NAMEPLATE RPM
MOTOR POLES
MOTOR VOLTS
SUPPLY VOLTAGE
MOTOR CONNECTION

Auto identification of motor parameters using AUTOTUNE

The Autotune feature can be used to identify, modify and store the following parameters:

VECTOR SETUP | STATOR RES
LEAKAGE INDUC
MUTUAL INDUC
QUICK SETUP | NO LOAD CALIB

The remaining important parameters are preset to a value depending on the overall "power-build as detailed in menu **SETUP PARAMETERS | VECTOR SETUP**, page 5-9.

Operating the MM456/MM3V Frequency Inverter with the Autotune function block enabled starts the autotune sequence. This is done as follows:

- Select view level **ADVANCED** in **MENUS | VIEW LEVEL**, see page 5-12.
- Select parameter **AUTOTUNE ENABLE** in menu **SETUP PARAMETERS | VECTOR SETUP** and set to **TRUE**.

- On starting the Inverter, the Autotune sequence is initiated. When complete (after a maximum of 10 seconds), the Inverter is returned to the stopped condition and the parameter **AUTOTUNE ENABLE** is reset to **FALSE**.
- Verify satisfactory vector performance with parameters determined by **AUTOTUNE**.
- Save parameters, see page 4-9/5-14.

Refer to the following for further information on AUTOTUNE:

- Menu VEKTOR SETUP :

Page 5-9/10

- Funktion block **AUTOTUNE**

Page 28.4-11

(in **Software and Applikation Manual TMM456/3SV-SAM**)

Entering motor parameters from known equivalent circuit




Fig. 10.4: The Motor Equivalent Circuit

Set the following parameters in the menu SETUP PARAMETERS | VECTOR SETUP to values calculated from the motor equivalent circuit as follows:

- STATOR RES = R_3 [Ohms]
- LEAKAGE I NDUC = $(L_1 + L_m) - \frac{(L_m)^2}{(L_2 + L_m)}$ [mH]
- MUTUAL I NDUC = $\frac{(L_m)^2}{(L_2 + L_m)}$ [mH]

Save parameters when all motor parameters have been entered, see page 4-9/5-14.

Entering motor parameters from simple measurement

Measure and enter motor parameters using the following procedure:

- Disable Vector operation by selecting parameter VECTOR ENABLE in menu SETUP PARAMETERS | VECTOR SETUP and setting to FALSE (if not already disabled).
- Run MM456 Frequency Inverter at base frequency (usually 50.0 Hz) with the motor connected without a load. Measure the motor current by observing the parameter MOTOR CURRENT in the OPERATOR MENU or DIAGNOSTICS menus. Set the parameter NO LOAD CALIB in the menu SETUP PARAMETERS | QUICK SETUP to this measured value.

- Re-enable vector operation by selecting parameter VECTOR ENABLE in menu SETUP PARAMETERS | VECTOR SETUP and setting to TRUE.
- Run MM456/MM3SV Frequency Inverter at approx. 50.0 Hz with the unloaded motor still connected. Trimm the parameter STATOR RES in the menu SETUP PARAMETERS | VECTOR SETUP until the diagnostic parameter FI ELD in the same menu shows approx. 70.0 . . . 80.0 %.

The following alternative method may also be used to provide a more accurate value of parameter STATOR RES:

- Set parameter STATOR RES in menu SETUP PARAMETERS | VECTOR SETUP to 0.0 Ohm and power up motor at zero speed.
- Measure the effective motor voltage by observing the parameter BOOST in menu SETUP PARAMETERS | FUNCTION BLOCKS | MOTOR CONTROL | PATTERN GEN. Calculate a new value of the parameter STATOR RES as follows and enter this value:

Star connection of Motor: STATOR RES: $\frac{\text{BOOST}}{\sqrt{3} \text{ NO LOAD CALI B}}$

Delta connection of Motor: STATOR RES: $\frac{\sqrt{3} \text{ BOOST}}{\text{NO LOAD CALI B}}$

- Set parameter LEAKAGE I NDUC in the menu SETUP PARAMETERS | VECTOR SETUP to 0.0 mH and run again at the base frequency (usually 50.0 Hz) with the unloaded motor still connected. Trimm the parameter MUTUAL I NDUCT until the parameter FI ELD in the same menu shows approx. 100.0 %. Use this set value of MUTUAL I NDUCT to determine the find values of the inductance parameters:
 - Enter 20 % of set MUTUAL I NDUCT to LEAKAGE I NDUC
 - Enter 80 % of set MUTUAL I NDUCT to final value of MUTUAL I NDUC

Save parameters, see page 4-9/5-14.

IMPORTANT: Remember to save the parameter settings.

Chapter 11 - APPLICATION MACROS

	Page
GENERAL ABOUT APPLICATION MACROS.....	11-2
APPLICATIONS MACRO 1 - Factory default setting	
Use of MACRO 1.....	11-2
Block diagrams.....	11-2
Operator menu.....	11-2
Terminal allocation.....	11-2
APPLICATIONS MACRO 2 - Run, Reverse commands	
Use of MACRO 2.....	11-3
Block diagrams.....	11-3
Operator menu.....	11-3
Terminal allocation.....	11-3
APPLICATIONS MACRO 3 - Motorpotentiometer	
Use of MACRO 3.....	11-6
Block diagrams.....	11-6
Operator menu.....	11-6
Terminal allocation.....	11-6
APPLICATIONS MACRO 4 - PID process controller	
Use of MACRO 4.....	11-9
Block diagrams.....	11-9
Operator menu.....	11-9
Terminal allocation.....	11-10
APPLICATIONS MACRO 5 - Selectable preset speeds	
Use of MACRO 5.....	11-13
Block diagrams.....	11-13
Operator menu.....	11-13
Terminal allocation.....	11-14
APPLICATIONS MACRO 6 - Closed-loop speed control	
Use of MACRO 6.....	11-17
Block diagrams.....	11-17
Operator menu.....	11-17
Terminal allocation.....	11-18

GENERAL ABOUT APPLICATION MACROS

The MM456 Frequency Inverter is supplied for integrated application Macros which preset (load the default values and software links) the MM456 Frequency Inverter for a particular function when loaded:

- **MACRO 1** corresponds to the factory default setting providing for basic speed control.
- **MACRO 2** is almost identical to **MACRO 1** except the default values and software links for separate "run forward" and "run reverse" commands are loaded.
- **MACRO 3** loads the software links for a motor potentiometer function with "Raise", "Lower" and "Preset" function used as a $\pm 10\%$ trimm which is added to the sum of the analog inputs.
- **MACRO 4** loads the software links for a PID controller operation.
- **MACRO 5** loads the software links for selectable preset speeds (MM45: 4 preset speeds, MM6: 8 preset speeds).
- **MACRO 6** loads the software links for closed-loop Speed control using an incremental encoder.
- **MACRO 0** removes all links and sets all parameters to their default values. This macro is for programming purposes only. A motor cannot be controlled until appropriate links are programmed.

For instruction on loading the macros please refer to **Restoring default values and loading application MACROS**, page 5-15.

There is a special short cut for selection of the factory default setting (**MACRO 1**), see **User reset to factory default setting**, page 4-7.

APPLICATIONS MACRO 1

Use of MACRO 1

MACRO 1 is the standard application Macro which sets the defaults and software links to the factory default setting. All descriptions in this Product Manual are based on this setting.

Block diagrams

The **General wiring diagram of control circuit** is Fig. 2.2 on page 2-4

The **Functional Block Diagram** is Fig. 2.3 on page 2-6.

The **Application functional block diagram** with software links as in **MACRO 1** (default supply condition) is Fig. 2.4 on page 2-7.

Operator menu

See page 5-2/3

Terminal allocation

See page 2-9/11.

APPLICATIONS MACRO 2 - Run, reverse commands

Use of MACRO 2

The only difference between MACRO 2 and the factory preset default values is the separate "run forward" and "run reverse" commands. This results in a slightly different terminal arrangement.

Block diagrams MACRO 2

The **General wiring diagram of MACRO 2** is Fig. 11.2a on page 11-4

The **Functional block diagram of MACRO 2** is Fig. 11.2b on page 11-4.


The **Application functional block diagram of MACRO 2** with software links as in MACRO 2 (default supply condition) is Fig. 11.3c on page 11-5.

Operator menu MACRO 2

See page 5-2/3

Terminal allocation MACRO 2

Terminal MM45	Terminal MM6	Designation	Signal, function	Explanation
1 : 6	1 : 12	AIN1 : 0 V	MM45: see page 2-9/10 MM6: see page 2-11	MM45: page 2-9/10 MM6: page 2-11
7	13	DIN1	Configurable digital input used here for "Run forwards": +24V = Run forward 0V = Stop (or reverse, see DIN 2)	- Stopping as set in RUN STOP MODE (see page 5-7)
8	14	DIN2	Configurable digital input used here for "Run reverse": +24V = Run reverse 0V = Stop (or forward, see DIN 1)	
9	15	DIN3	Configurable digital input used here to reset trips: +24V = Reset 0V = Normal	- Edge triggered
10 : 18	16 : 26	DIN4 : DOUT2/ DOUT3-B	MM45: see page 2-10 MM6: see page 2-11	MM45: page 2-9/10 MM6: page 2-11



WICHTIG: . Brücke 6-10 wenn externe Überwachung nicht angeschlossen
 IMPORTANT: . Link 6-10 if external Trip not used

Fig. 11.2a: General wiring diagram of MACRO 2 (terminal numbers valid with MM45)




Fig. 11.2b: Functional block diagram of MACRO 2 (Digital outputs with MM45, MM6 has relay outputs)




Fig. 11.2c: Application Functional block diagram with software links as in MACRO 2

APPLICATION MACRO 3 - Motorpotentiometer

Use of MACRO 3

MACRO 3 provides motorpotentiometer-like a raise/lower (push button) interface as an additional Setpoint Trim. The Setpoint is derived from the sum of **ANALOG INPUT 1** (AIN1, terminal 2), **ANALOG INPUT 2** (AIN2, terminal 4) and the output of the raise/lower ramp. This ramp is controlled by the 3 digital inputs **RAISE INPUT** (connected to DIN2, terminal 8), **LOWER INPUT** (connected to DIN3, terminal 9) and **RL RESET** (connected to DIN5, terminal 11) of the **RAISE/LOWER** function block.

The raise/lower trim is restricted to be $\pm 10.00\%$. This limit is set by the **RL MIN VALUE** and **RL MAX VALUE** parameters in the **RAISE/LOWER** function block.

Note that the raise/lower ramp output is automatically preserved in non-volatile memory during a power-down.

Block diagrams MACRO 3

The **General wiring diagram of MACRO 3** is Fig. 11.3a on page 11-7

The **Functional block diagram of MACRO 3** is Fig. 11.3b on page 11-7.

The **Application functional block diagram of MACRO 3** with software links as in MACRO 3 (default supply condition) is Fig. 11.3c on page 11-8.

Operator menu MACRO 3

See page 5-2/3

Terminal allocation MACRO 3

Terminal MM45	Terminal MM6	Designation	Signal, function	Exp anation
1 : 6	1 : 12	AIN1 : 0 V	MM45: see page 2-9/10 MM6: see page 2-11	MM45: page 2-9/10 MM6: page 2-11
7	13	DIN1	Configurable digital input, usually used as command "Run", for starting and stopping the drive: +24 V = Run 0 V = Stop	- Stopping as set in RUN STOP MODE (see page 5-7)
8	14	DIN2	Configurable digital input used here for "Raise": +24 V = Raise 0 V = No action	
9	15	DIN3	Configurable digital input used here for "Low": +24 V = Lower 0 V = No action	
10	16	DIN4	MM45: see page 2-9/10 MM6: see page 2-11	MM45: page 2-9/10 MM6: page 2-11
11	17	DIN5	Configurable digital input, usually used to reset motor potentiometer to RL RESET VALUE : +24 V = Reset to RL RESET VALUE 0 V = Normal	
12 : 18	16 : 26	DIN6 : DOUT2/ DOUT3-B	MM45: see page 2-10 MM6: see page 2-11	MM45: page 2-9/10 MM6: page 2-11




Fig. 11.3a: General wiring diagram of MAKRO 3 (Terminal numbers valid for MM45)




Fig. 11.3b: Functional block diagram of MAKRO 3 (Digital outputs with MM45, MM6 has relay outputs)




Fig. 11.3c: Application Functional block diagram with software links as in MAKRO 3

APPLICATION MACRO 4 - PID process control

Use of MACRO 4

MACRO 4 loads the software links for a preset PID controller operation.


Block diagrams MACRO 4

The **General wiring diagram of MACRO 4** is Fig. 11.4a on page 11-11

The **Functional block diagram of MACRO 4** is Fig. 11.4b on page 11-11.


The **Application functional block diagram of MACRO 4** with software links as in MACRO 4 (default supply condition) is Fig. 11.4c on page 11-12.

Operator menu MACRO 4



Terminal allocation MACRO 4

Terminal MM45	MM6	Designation	Signal, function	Explanation
1	-	0 V REF	Zero volt reference for analog signals or current loop connection	- Do not use for other purposes!!
2	1	AIN1	Configurable analog input in the range 0...+10 V, +2...+10 V, 0...+5 V, +1...+5 V, -10...+10 V, 0... 20 mA, 4... 20 mA, 20... 4 mA, 20... 0 mA used here as process setpoint.	- As set by the DIL switch AIN 1 AIN 1 TYPE (see page 5-8) - MAX and MIN SPEED see page 5-4 - Input impedance = 94 kΩ.
3	-	+10 V REF	see page 2-9	
4	2	AIN2	Configurable analog input in the range 0...+10 V, +2...+10 V, 0...+5 V, +1...+5 V, -10...+10 V, 0... 20 mA, 4... 20 mA, 20... 4 mA, 20... 0 mA used here as process feedback, otherwise as AIN1	- As AIN 1
5 : 10	3 : 16	AIN3 : DIN4	MM45: see page 2-10 MM6: see page 2-11/12	MM45: page 2-10 MM6: page 2-11/12
11	17	DIN5	Configurable digital input, used here to enable the PID controller: +24 V = Enable 0 V = Inhibit	
12 : 18	18 : 26	DIN6 : DOUT2/ DOUT3-B	MM45: see page 2-10 MM6: see page 2-12	MM45: page 2-10 MM6: page 2-12



WICHTIG: . Brücke 6-10 wenn externe Überwachung nicht angeschlossen
IMPORTANT: . Link 6-10 if external Trip not used

Fig. 11.4a: General wiring diagram of MAKRO 4 (Terminal numbers valid for MM45)




Fig. 11.4b: Funktionales Blockdiagramm von MAKRO 4 (Digitale Ausgänge mit MM45, MM6 hat Relaisausgänge)




Fig. 11.4: Application Functional block diagram with software links as in MAKRO 4

APPLICATION MACRO 5 - Selectable preset speeds

Use of MACRO 5

MACRO 5 loads the software links for selectable preset speeds (4 with MM45, 8 with MM6).


Block diagrams MACRO 5

The **General wiring diagram of MACRO 5** is Fig. 11.5a on page 11-11

The **Functional block diagram of MACRO 5** is Fig. 11.5b on page 11-11.

The **Application functional block diagram of MACRO 5** with software links as in MACRO 5 (default supply condition) is Fig. 11.5c on page 11-12.

Operator menu MACRO 5



Terminal allocation MACRO 5

Terminal		Designation	Signal, function	Explanation
MM45	MM6			
1 : 15	1 : 17	AIN1 : DIN5	MM45: see page 2-9/10 MM6: see page 2-11/12	MM45: page 2-9/10 MM6: page 2-11
16	18	DIN6	Configurable digital input used as preset select: +24 V = active 0 V = not active	MM45 and MM6
17	19	DIN7	Configurable digital input used as preset select: +24 V = active 0 V = not active	
	20	DIN8	Configurable digital input used as preset select: +24 V = active 0 V = not active	MM6 only
18	21 : 26	DOUT1(-A) : DOUT3(-B)	MM45: see page 2-10 MM6: see page 2-12	MM45: page 2-10 MM6: page 2-12




Fig. 11.5a: General wiring diagram of MAKRO 5 (Terminal numbers valid for MM45)




Fig. 11.5b: Functional block diagramm of MAKRO 5 (Digital outputs as with MM45, MM6 has relay outputs)




Fig. 11.5c: Application Functional block diagram with software links as in MAKRO 5

APPLICATION MACRO 6 - Closed-loop speed control

Use of MACRO 6

MACRO 6 loads the software links for a closed-loop speed control with an incremental encoder.

Block diagrams MACRO 6

The **General wiring diagram of MACRO 6** is Fig. 11.6a on page 11-11

The **Functional block diagram of MACRO 6** is Fig. 11.6b on page 11-11.


The **Appunction functional block diagram of MACRO 6** with software links as in MACRO 6 (default supply condition) is Fig. 11.6c on page 11-12.

Operator menu MACRO 6

SETPOINT (REMOTE) = YYY. Y %	see page 5-2
SPEED DEMAND = YYY. Y %	see page 5-2
DRIVE FREQUENCY = YYY. Y Hz	see page 5-3
MOTOR CURRENT = YYY. Y A	see page 5-3
LOAD = YYY. Y %	see page 5-3
DC LINK VOLTS = YYY. Y V	see page 28.3-11
PID OUT SCALING 1.0000	see page 28.3-11
PID P GAIN 1.0	see page 28.3-11
PID I GAIN 1.00 s	see page 28.3-11
PID D GAIN 0.000 s	see page 28.3-11
PID FILTER TC 2.000 s	see page 28.3-11
PID SETPOINT 0.00 %	see page 28.3-11
PID FEEDBACK 0.00 %	see page 28.3-11
PID ERROR = 0.00 %	see page 28.3-11
ENTER PASSWORD 0000	see page 5-3

Terminal allocation MACRO 6

Terminal MM45	MM6	Designation	Signal, function	Explanation
1	-	0 V REF	Zero volt reference for analog signals or current loop connection	- Do not use for other purposes!!
2	1	AIN1	Configurable analog input in the range 0...+10 V, +2...+10 V, 0...+5 V, +1...+5 V, -10...+10 V, 0...20 mA, 4...20 mA, 20...4 mA, 20...0 mA here as speed setpoint: +10 V = MAX SPEED forward 0 V = MIN SPEED	- As set by the DIL switch AIN 1 AIN 1 TYPE (see page 5-8) - MAX and MIN SPEED see page 5-4 - Input impedance = 94 k Ω .
3 : 10	1 : 16		MM45: see page 2-9/10 MM6: see page 2-11/12	MM45: Page 2-9/10 MM6: Page 2-11/12
11	17	DIN5	Configurable digital input used as PID controller: +24 V = active 0 V = not active	see page e 11-10
12 : 18	18 : 26		MM45: see page 2-10 MM6: see page 2-12	MM45: Page 2-10 MM6: Page 2-12



WICHTIG: . Brücke 6-10 wenn externe Überwachung nicht angeschlossen/
IMPORTANT: Link 6-10 if external Trip not used

Fig. 11.6a: General wiring diagram of MAKRO 6 (Terminal numbers valid for MM45)




Fig. 11.6b: Functional block diagramm of MAKRO 6 (Digital outputs as with MM45, MM6 has relay outputs)




Fig. 11.6c: Application Functional block diagram with software links as in MAKRO 6

Chapter 12 - APPENDICES

	Page
DATA OF MM407-3...440-3 FOR OPERATION AT 3AC 230 V	12-3
MM655-5...6110-5 FOR OPERATION AT 3AC 500 V	12-2
ORDERING INFORMATION	12-4

NOTE: These MM456 Frequency Inverters have a non-standard voltage range. Please enquire about delivery.

DATA MM407-3...440-3 FOR OPERATION WITH 3AC 230 V

Product code

Supply voltage:

Operation with constant torque (CT)

<ul style="list-style-type: none"> ◆ Typical applications: - Machinery - Transport technology - Long-travel and hoisting ◆ Overload capability: 150 % I_n / 60 s 	<ul style="list-style-type: none"> Motor power Motor current Motor cable E rope ⁵⁾ Motor cable North America ⁶⁾ Approx. losse: 6 kHz Switching frequency Supply current Supply fuse / Circuit breaker ¹⁾ Supply cable I rope ⁵⁾ Supply cable North America ⁶⁾ Earth leakage current Fuse for UL compliance ²⁾
---	---

Operation with quadratic torque at higher power (HVAC)

<ul style="list-style-type: none"> ◆ Main applications: - Pumps - Fan <p>Special setting for higher-rating necessary, see page 10-7</p>	<ul style="list-style-type: none"> Motor power P_{shaft} typical 2-pole P_{shaft} typical 4 pole Max. current Motor cable E rope ⁵⁾ Motor cable North America ⁶⁾ Approx. losse: 3 kHz Switching frequency Supply current Supply fuse / Circuit breaker ¹⁾ Supply cable I rope ⁵⁾ Supply cable North America ⁶⁾ Earth leakage current Fuse for UL compliance ²⁾
--	--

Integrated braking chopper:

<ul style="list-style-type: none"> Max. current Ext. braking resistor Available braking resistors for 	<ul style="list-style-type: none"> - ED ≤30 %, 0 s max. - Minimum v lue - light braking ; - high braking torque short term - high braking torque with heavy braking operation
--	--

Installation, Mounting:

<ul style="list-style-type: none"> Cooling Weight approx.: Dimensions: Air flow clearance: Power terminals: Terminals for braking chopper: Outline drawing: 	<ul style="list-style-type: none"> - Grundgerät - Programming Pad (Option) - Height - Height with top cover - Width - Depth - above, below / - left, right - front with wall mounting ⁷⁾ - max. conductor size - max. torque - max. conductor size - max. torque
--	--

MM407-3-EMC

MM415-3-EMC

3AC 230 V ±15 % 50...60 Hz ±5 Hz

0.75 kW	1.5 kW
4.0 A	7.0 A
1 mm ²	1 mm ²
14 AWG	14 AWG
46 W	81 W
3/6/9 kHz	3/6/9 kHz
5.0 A	9.0 A
8 A	10 A
1 mm ²	1/1.5 mm ²
14 AWG	14 AWG
>10 mA	>10 mA
10 A ¹⁾	10 A ¹⁾

1.1 kW ⁴⁾	2.2 kW ⁴⁾
1.0 kW	1.9 kW
0.9 kW	1.4 kW
4.0 A	7.0 A
1 mm ²	1 mm ²
14 AWG	14 AWG
46 W	81 W
3 kHz	3 kHz
5.0 A	9.0 A
8 A	10 A
1 mm ²	1/1.5 mm ²
14 AWG	14 AWG
>10 mA	>10 mA
10 A ¹⁾	10 A ¹⁾

4 A	4 A
100 Ω	100 Ω
200BR0004	100BR001
200Ω/0.04 kW	100Ω/0.08 kW
100BR001	100BR001
100Ω/0.08 kW	100Ω/0.08 kW
100BR006	100BR006
100Ω/0.6 kW	100Ω/0.6 kW

Convection	Convection
2.8 kg	2.9 kg
0.1 kg	0.1 kg
198 mm	198 mm
198 mm	198 mm
155 mm	155 mm
155 mm	155 mm
80 mm	80 mm
15 mm	15 mm
15 mm	15 mm
4mm ² /10AWG	4mm ² /10AWG
1.0 Nm	1.0 Nm
4mm ² /10AWG	4mm ² /10AWG
1.0 Nm	1.0 Nm
3.1a	3.1a

1) Fuse or circuit breaker with delayed release

2) UL Listed JDDZ, class K5 or H; UI Listed JDRX, class H

3) For operation to UL

4) Reduced shaft power

DATA MM655...6110-5 FOR OPERATION WITH 3AC 500 V

MM422-3-EMC MM440-3-EMC

3AC 230 V $\pm 15\%$, 50...60 Hz ± 5 Hz

2.2 kW	4.0 kW
10.5 A	16.5 A
1/1.5 mm ²	2.5 mm ²
14 AWG	10 AWG
123 W	174 W
3/6/9 kHz	3/6/9 kHz
12 A	16 A
16 A	20 A
2.5 mm ²	2.5/4 mm ²
14 AWG	10 AWG
>10 mA	>10 mA
15 A ¹⁾	25 A ¹⁾

3.0 kW ⁴⁾	4.0 kW ⁴⁾
3.0 kW	4.0 kW
2.8 kW	4.0 kW
10.5 A	16.5 A
1/1.5 mm ²	2.5 mm ²
14 AWG	14 AWG
123 W	174 W
3 kHz	3 kHz
12 A	16 A
16 A	20 A
2.5 mm ²	2.5/4 mm ²
14 AWG	12 AWG
>10 mA	>10 mA
15 A ¹⁾	20 A ¹⁾

10 A	15 A
56 Ω	22 Ω
100BR001	100BR001
100 Ω /0.08 kW	100 Ω /0.08 kW
100BR006	100BR006
100 Ω /0.08 kW	100 Ω /0.06 kW
100BR012	100BR012
100 Ω /1.2 kW	100 Ω /1.2 kW

Fan	Fan
4.1 kg	4.1 kg
0.1 kg	0.1 kg
233 mm	233 mm
233 mm	233 mm
171 mm	171 mm
181 mm	181 mm
80 mm	80 mm
15 mm	15 mm
15 mm	15 mm
4mm ² /10AWG	4mm ² /10AWG
1.0 Nm	1.0 Nm
4mm ² /10AWG	4mm ² /10AWG
1.0 Nm	1.0 Nm
3.1b	3.1b

MM655/500 MM675/500 MM6110/500

3AC 500 V $\pm 10\%$, 50...60 Hz ± 5 Hz

Operation with constant torque (CT)

5.5 kW	7.5 kW	11 kW
10 A	12.5 A	18 A
1/1.5 mm ²	1.5/2.5 mm ²	2.5/4 mm ²
220 W	260 W	330 W
3/6 kHz	3/6 kHz	3/6 kHz
14 A	22 A	26 A
3x20 A	3x25 A	3x32 A
2.5/4 mm ²	4/6 mm ²	6/10 mm ²
12 AWG	10 AWG	8 AWG
>10 mA	>10 mA	>10 mA

Operation with quadratic torque at higher power (HVAC)

7.5 kW	11 kW	15 kW
7.5 kW	11 kW	15 kW
7.5 kW	11 kW	15 kW
12.5 A	18 A	24 A
1.5/2.5 mm ²	2.5/4 mm ²	4/6 mm ²
270 W	350 W	450 W
3 kHz	3 kHz	3 kHz
20 A	26 A	32 A
3x25 A	3x32 A	3x40 A
4/6 mm ²	6/10 mm ²	10 mm ²
>10 mA	>10 mA	>10 mA

Integrated braking chopper

7.5 A	15 A	15 A
100 Ω	50 Ω	50 Ω
100BR001	100BR001	100BR006
100 Ω /0.08 kW	100 Ω /0.08 kW	100 Ω /0.6 kW
39BR006	39BR006	39BR012
39 Ω /0.6 kW	39 Ω /0.6 kW ⁸⁾	39 Ω /1.2 kW ⁸⁾
100BR012	39BR012	39BR050
100 Ω /1.2 kW	39 Ω /1.2 kW ⁸⁾	39 Ω /5.0 kW ⁸⁾

Installation, Mounting

Fan	Fan	Fan
8.8 kg	8.9 kg	9.0 kg
0.1 kg	0.1 kg	0.1 kg
348 mm	348 mm	348 mm
365 mm	365 mm	365 mm
201 mm	201 mm	201 mm
208 mm	208 mm	208 mm
70 mm	70 mm	70 mm
20 mm	20 mm	20 mm
0 mm	0 mm	0 mm
2.5mm ² /12AWG	6mm ² /8AWG	6mm ² /8AWG
1.5 Nm	1.5 Nm	1.5 Nm
2.5mm ² /12AWG	2.5mm ² /12AWG	2.5mm ² /12AWG
1.0 Nm	1.0 Nm	1.0 Nm
3.1c	3.1c	3.1c

Size of cables in accordance with: 5) EN60204-1 (see page 3-7) 7) With NEMA1 8) Only with 3AC 400 V,

ORDERING INFORMATION

Function	Order code	Technical data	Order No.

Please enquire

Chapter 13 - INDEX

	Page
GENERAL	13-2
MENUS AND PARAMETERS	13-4

GENERAL

<u>Word</u>	<u>Page</u>	<u>Word</u>	<u>Page</u>
Air flow clearance	1-8, 3-3	EMC responsibility	8-9
Altitude.....	1-6	Enclosure mounting	3-13
Analog inputs/outputs	1-6/10, 6-9	Encoder	9-16
Application software	1-5	Environmental requirements	1-6
Automatic trip reset	6-4	Factory default setting.....	4-8, 5-15
Autotune	10-10	Flux control.....	1-5
Base frequency	1-11, 5-4	Function blocks.....	5-10
Basic functions	2-2	Function keys	4-4
Boost	5-6	Functional block diagram	2-5
Brake motors	10-5	General wiring diagram.....	2-4
Braking chopper	1-8	High-speed motors	10-6
Braking resistors (external)	1-8, 9-7	Humidity	1-6
Braking	2-2	HVAC, Rating for fans/pumps.....	1-8, 10-9
Cable sizes.....	3-7	Immunity.....	8-6
Cable-lengths.....	3-17	Inputs	5-8, 6-9
CAN option module	9-12	Installation	3-5
CE-Marking.....	8-2/4/7	Intrinsic function.....	8-3/4
Checksum fail.....	6-15	Jog.....	4-5, 5-7
Chokes for line and motor	9-4, 10-6	Key inactive messages	6-15
Circuit breaker.....	3-7	KIMOVIS PC Software	9-13
Class A, B.....	8-6	Language.....	4-7
Closed-loop speed control (MACRO 6).....	11-17	Layout considerations	3-17
Configurable inputs and outputs.....	2-13	LCD plain-language display	4-3
Configuration mode.....	5-16	LEDs	4-6
Control terminals.....	1-10, 2-9	Loading macros.....	5-15
Control wiring	3-8	Loading parameters.....	4-8, 5-16
Cooling.....	1-8	LOCAL control mode	4-5
Current limit	1-6	Logic functions	1-5
Default values	5-15	Losses	1-8
Diagnostics (main menu).....	6-2/5	Low Voltage Directive.....	8-2/12
Digital in- and output	1-6/10, 2-3, 6-9	Machinery directive	8-13
Dimensions.....	1-8	Maintenance.....	7-2
Dynamic braking	2-2	Manufacturer's declaration for EMC.....	8-11
Earth bus bar	3-14	Manufacturer's machine-safety declaration	8-13
Earth-fault monitoring.....	3-12	Max. and min. speeds.....	5-4
Earthing	1-7, 3-8	Menu structure	4-6
EC Declaration of Conformity for EMC	8-10	Menus (main menu)	5-12
EMC Directive	8-3	Minimum connection	10-2
EMC emission and immunity	8-8	MM407-3..440-3 for operation with 3AC 230 V ..	12-2
EMC environment	8-5	MM655-5..6110-5 for operation with 3AC 500 V ..	12-3
EMC filters	3-9, 8-7, 9-3	Motor chokes	3-17, 9-2/4, 10-6
EMC hot area	3-14/15	Motor current	1-8, 5-5
EMC installation instructions.....	3-9	Motor data.....	5-5

<u>Word</u>	<u>Page</u>	<u>Word</u>	<u>Page</u>
Motor parameters.....	10-11	Resolution.....	1-10
Motorpotentiometer (MACRO 3).....	11-6	Returned equipment.....	7-2
Mounting	3-2	RS232 interface	9-10
Multiple motor operation.....	10-7	RS485/422 interface	9-11
NEMA 1 top cover	9-6	Run stop mode.....	5-7
Operating data	5-3, 6-6	Run, reverse commands (MACRO 2).....	11-3
Operating panel	9-10	Safety considerations	4-9
Operation temperature	1-6	Safety	1-7
Operation with constant torque	1-8	Sample rate	1-10
Operation with quadratic torque (HVAC) 1-8, 10-9		Save parameters	4-8, 5-14
Operator (main menu).....	5-2	Save parameters/system (main menu).....	5-13
Options	1-2, 9-2	Screening and wiring	3-13/16
Ordering information.....	1-12	Sensorless vector fluxing mode	10-10
Outline drawings	3-3	Set values.....	5-2, 6-5
Output frequency	1-5	Setting-up and energizing	4-9
Outputs	6-9	Setting-up the drive	4-11
Overload capacity	1-8	Setup parameters (main menu)	5-4
Overload protection.....	1-11, 3-7	Short-circuit current.....	1-7
Overload protection.....	3-7	Short-circuit protection.....	3-7
Parameter sets	1-5	Skip frequencies	1-5
Password.....	1-5, 5-3/11	Slip compensation.....	1-5
PID process control (MACRO 4)	11-9	Slip-ring induction motors.....	10-5
Pole-change motors	10-6	Speed control.....	1-5
Pollution	1-6	Standards	1-7
Power terminals	1-8, 2-8	Star-point earthing	3-15
Power wiring	3-7	Starting torque (high).....	10-8
Preset speeds (MACRO 5).....	11-13	Stopping modes	1-5
Processing functions.....	1-5	Supply and motor cable	1-8, 3-7
PROFIBUS-DP option module	9-11	Supply current	1-8
Programming pad	1-5, 4-2, 9-9	Supply fuse	1-8, 3-7
Programming pad	4-2	Supply voltage	1-8/10
Programming	4-4	Switching at the inverter output.....	10-8
Protection	1-6	Switching frequency	1-5
Protection	1-7, 3-2	Synchronous motors	10-5
Quick setup.....	5-4	Temperatures	1-6
Radiated emission.....	3-12, 8-6	Trip messages	6-2
Ramps.....	1-5, 5-4	Trip messages	6-2/13
Reference and auxiliary supplies	1-10	Trips status (main menu)	5-12, 6-2/11
Relais modules.....	9-10	Trips.....	5-8/12, 6-3/7/13
Repair	7-2	UL for USA and Canada.....	1-11, 8-14, 12-3
Reset to factory default values	4-8	V/f characteristic.....	1-6, 5-5
Reset	6-3	Vector parameters.....	5-9
Resetting a tripped condition.....	6-3	Weight	1-8

MENU PARAMETERS

Menu/Parameter	Page	Menu/Parameter	Page
/COAST STOP	28.2-3	BRAKE RESISTANCE	28.4-15
/FAST STOP	28.2-3	BRAKING	6-6, 26-6, 28.4-15
/STOP	28.2-2	CHANGE PASSWORD	5-11, 25-11, 28.6-4
A DIN 1/2 HYST	28.1/2-7	COEFFICIENT A...C	28.6-7/8
A DIN 1/2 INVERT	28.1/2-7	COMMS COMMAND	28.7-4
A DIN 1/2 LEVEL	28.1/2-7	COMMS CONTROL	28.7-2...4
A DIN 1/2 VALUE	28.1/2-7	COMMS REF	28.7-2
ACTIVE TRIPS	6-7/11, 26-7/11, 28.5-2	COMMS SEQ	28.7-2
ACTIVE TRIPS+	6-8/11, 26-8/11, 28.5-2	COMMS SETPOINT	6-5, 26-5, 28.2-14
AIN 1...4 BREAK	28.1-3	COMMS STATUS	28.7-3
AIN 1...4 BREAK ENBL	28.1-3	COMMS TIMEOUT	28.7-2
AIN 1...4 BREAK VAL	28.1-3	CONFIGURATION ID	28.6-3
AIN 1...4 OFFSET	28.1-2	CONSTANT TORQUE/	5-5, 25-5, 28.4-5
AIN 1...4 SCALE	28.1-2	CURRENT FEEDBACK	28.4-5/6
AIN 1...4 TYPE	5-8, 25-8, 28.1-2	CURRENT LIMIT	28.4-7
AIN 1...4 VALUE	6-9, 26-9, 28.1-3	CURRENT LIMITING	5-3, 6-11, 25-3, 26-11, 28.4-7
ALL PARAMETERS	5-16, 25-16	CUSTOM SCREEN 1/2	28.6-7/8
ANALOG DIGIN	28.1-7	DC LINK VOLTS	5-3, 25-3, 6-6, 26-6, 28.4-15
ANALOG DIGIN 1/2	28.1-7	DECIMAL PLACE	28.6-7/8
ANALOG INPUT	28.1-2...4	DEFLUX DELAY	28.4-14
ANALOG INPUT 1...4	28.1-2/3	DEMAND (REMOTE)/	5-2, 25-2
ANALOG OUTPUT	28.1-8/9	DEMULTIPLXER	28.8-14
ANALOG OUTPUT 1/2	28.1-8	DESTINATION 1...50	27-2
AOUT 1/2 ABS	28.1-8	DIAGNOSTICS	6-5...10, 26-5...10
AOUT 1/2 OFFSET	28.1-8	DIGITAL INPUT	28.1-5/6
AOUT 1/2 SCALE	28.1-8	DIGITAL INPUT 1...8	28.1-5
AOUT 1/2 TYPE	28.1-8	DIGITAL OUTPUT	28.1-10
AOUT 1/2 VALUE	6-10, 26-10	DIGITAL OUTPUT 1...3	28.1-10
APPLICATION ONLY	5-16, 25-16	DIN 1...8 INVERT	28.1-5
AR ATTEMPT DLY 1/2	28.2-8	DIN 1...8 VALUE	6-9, 26-9, 28.1-5
AR ATTEMPTS	28.2-8	DISABLE CONFIG	5-16, 25-16
AR ATTEMPTS LEFT	28.2-9	DISABLED TRIPS	5-8, 6-11, 25-8, 26-11, 28.5-2
AR ENABLE	28.2-8	DISABLED TRIPS+	5-8, 6-11, 25-8, 26-11, 28.5-2
AR INITIAL DLY 1/2	28.2-8	DOUT 1...3 INVERT	28.1-10
AR PENDING	28.2-9	DOUT 1...3 VALUE	6-10, 26-10, 28.1-10
AR RESTARTING	28.2-9	DRIVE ENABLE	28.2-3
AR TIME LEFT	28.2-9	DRIVE FREQUENCY	5-3, 6-6, 25-3, 26-6, 28.4-14
AR TRIGGERS 1/2	28.2-8	DYNAMIC BRAKING	28.4-15
AR TRIGGERS+ 1/2	28.2-8	ENABLE CONFIG/	5-16, 25-16
AT ZERO SPEED	28.2-19	ENABLED KEYS	28.6-2
AUTO BACKUP	28.6-3	ENCODER	28.1-11
AUTO BOOST	28.4-9	ENCODER INVERT	28.1-11
AUTO RESTART	28.2-8/9	ENCODER LINES	28.1-11
AUTOTUNE	28.4-11	ENCODER MODE	28.1-11
AUTOTUNE ACTIVE	28.4-11	ENCODER POSITION	28.1-11
AUTOTUNE ENABLE	5-9, 25-9, 28.4-11	ENCODER RESET	28.1-11
AUTOTUNE MODE	28.4-11	ENCODER SPEED	6-6, 26-6, 28.1-11
BASE FREQUENCY	5-4, 25-4, 28.4-8	ENCODER SPEED	6-6, 26-6, 28.1-11
BASE VOLTS	28.4-12	ENCODER SUPPLY	28.1-11
BOOST	28.4-14	ENTER PASSWORD	5-3/11, 25-3/11, 26.6-4
BRAKE 1S RATING	28.4-15	EXTERNAL TRIP	28.5-4
BRAKE CONTROL	28.3-12/13	FAST STOP LIMIT	28.2-17
BRAKE ENABLE	28.4-15	FAST STOP MODE	28.2-17
BRAKE HOLD	28.3-12	FAST STOP RATE	28.2-17
BRAKE OFF FREQ	28.3-12	FEEDBACK SOURCE	28.4-7
BRAKE OFF HOLD	28.3-12	FIELD	5-10, 25-10, 6-6, 26-6, 28.4-6
BRAKE ON FREQ	28.3-12	FINAL STOP RATE	28.2-17
BRAKE ON HOLD	28.3-12	FIRST TRIP	6-8/11, 26-8/11, 28.5-3
BRAKE ON LOAD	28.3-12	FIXED BOOST	5-6, 25-6, 28.4-9
BRAKE ON LOAD	28.3-12	FLUXING	28.4-8
BRAKE POWER	28.4-15	FLY CATCH ACTIVE	28.4-18
BRAKE RELEASE	28.3-12		

Menu/Parameter	Page	Menu/Parameter	Page
FLY CATCH ENABLE	28.4-17	MAX SPEED	5-4, 25-4, 28.4-2
FLY CATCHING	28.4-17/18	MAX SPEED	28.4-2
FLY MIN SPEED	28.4-18	MAX SPEED CLAMP	28.2-13
FLY REFLUX TIME	28.4-18	MENUS	5-12, 25-12, 28.6
FLY SEARCH BOOST	28.4-17	MIN SPEED	5-4, 25-4, 28.3-9
FLY SEARCH MODE	28.4-17	MIN SPEED CLAMP	28.2-13
FLY SEARCH TIME	28.4-18	MIN SPEED INPUT	28.3-9
FLY SEARCH VOLTS	28.4-17	MIN SPEED MODE	28.3-9
FLY SETPOINT	28.4-18	MIN SPEED OUTPUT	28.3-9
FLY START MODE	28.4-17	MINIMUM SPEED	28.3-9
FORMULA	28.6-7/8	MISCELLANEOUS	28.8
FULL LOAD CALIB	5-5, 25-5, 28.4-5	MOTOR CONNECTION	5-9, 25-9, 28.4-10
FUNCTION BLOCKS	28	MOTOR CONTROL	28.4
GROUP ID (GID)	28.7-5	MOTOR CURRENT	5-3/6, 6-6, 25-3/6, 26-6, 28.4-5
HEALTHY	28.2-4	MOTOR LIMIT	5-6, 25-6
HIGH LIMIT	28.6-8	MOTOR I LIMIT	28.4-7
I MAGNETISING	28.4-6	MOTOR POLES	5-9, 25-9, 28.4-4
I TORQUE	28.4-6	MOTOR VOLTS	5-9, 25-9, 28.4-12
I*T THRESHOLD	28.5-5	MULTIPLEXER	28.8-13
I*T TIME	28.5-5	MUTUAL INDUCT	5-10, 25-10, 28.4-10
I*T TRIP	28.5-5	NAME	28.6-7/8
I*T UPPER LIMIT	28.5-5	NAMEPLATE RPM	5-9, 25-9, 28.4-4
I/O TRIPS	28.5-4	NO LOAD CALIB	5-5, 25-5, 28.4-5
INJ ACTIVE	28.4-16	OP DATABASE	28.6-3
INJ BASE VOLTS	28.4-16	OP MENU 2...15	28.6-5
INJ BRAKING	28.4-16	OP STATION	28.6-2/3
INJ DC LEVEL	28.4-16	OP VERSION	28.6-3
INJ DC PULSE	28.4-16	OPERATOR MENU	5-2/3, 25-2/3
INJ DEFLUX TIME	28.4-16	OPERATOR MENU	28.6-5/6
INJ FINAL DC	28.4-16	OUTPUT	28.8-3/10
INJ FREQUENCY	28.4-16	OUTPUT 0...15	28.8-14
INJ I-LIM LEVEL	28.4-16	OUTPUT CONTACTOR	28.2-4
INJ TIMEOUT	28.4-16	PARAMETER SAVE	5-13...16, 25-13...16
INPUT	28.8-14	PASSWORD	5-11, 25-11, 26.6-4
INPUT 0...15	28.8-13	PATTERN GEN	28.4-14
INPUT 1...4 BREAK	28.5-4	PATTERN GEN FREQ	28.4-14
INPUT A...C	28.8-3	PID	28.3-10/11
INPUT A...C	28.8-10	PID D TIME CONST	28.3-11
INPUTS & OUTPUTS	28.1	PID ENABLE	28.3-10
INVERT THERMIST	28.5-2	PID ERROR	28.3-11
JOG	28.2-18	PID FB NEGATE	28.3-10
JOG	28.2-3	PID FEEDBACK	28.3-10
JOG (REMOTE)/	5-2, 25-2	PID FILTER TC	28.3-11
JOG ACCEL RATE	28.2-18	PID I TIME CONST	28.3-10
JOG DECEL RATE	28.2-18	PID INTEGRAL OFF	28.3-10
JOG DMD (LOCAL)	5-2, 25-2	PID OUT NEG LIM	28.3-11
JOG SETPOINT	5-7, 6-5, 25-7, 26-5, 28.2-18	PID OUT POS LIM	28.3-11
JOGGING	28.2-4	PID OUT SCALING	28.3-11
LANGUAGE	5-12, 25-12, 28.6-2	PID OUTPUT	28.3-11
LEAKAGE INDUCT	5-10, 25-10, 28.4-10	PID P GAIN	28.3-10
LIMIT FREQUENCY	28.4-9	PID SETPOINT	28.3-10
LINKS	27-2/3	PID SP NEGATE	28.3-10
LOAD	5-3, 6-6, 25-3, 26-6, 28.4-6	POWER FACTOR	5-5, 25-5, 28.4-5
LOAD FROM MEMORY	5-16, 25-16	POWER UP MODE	28.2-10
LOAD FROM OP	5-16, 25-16	POWER UP START	28.2-3
LOAD MACRO 0...99	5-15, 25-15	PRESET	28.3-4...6
LOCAL CONTROL	28.2-10...12	PRESET 1...8	28.3-4/5
LOCAL REVERSE	28.2-14	PRESET 1...8 INPUT 0...7	28.3-4
LOCAL SETPOINT	6-5, 26-5, 28.2-14	PRESET 1...8 OUTPUT1/2	28.3-4
LOGIC FUNC 1...10	28.8-10	PRESET 1...8 SELECT	28.3-4
LOGIC FUNCTION	28.8-9...12	PROTECT LOCAL SP	28.6-4
LOW LIMIT	28.6-8	PROTECT OP MENU	28.6-4
LOWER INPUT	28.3-2	QUADRATIC TORQUE	5-5, 25-5, 28.4-5
MAIN SEQ STATE	28.2-4	QUICK SETUP	5-4...8, 25-4...8,

Menu/Parameter	Page	Menu/Parameter	Page
RAISE INPUT	28.3-2	SOURCE 1...50	27-2
RAISE/LOWER	28.3-2/3	SPEED DEMAND	5-2, 6-5, 25-2, 26-5, 28.2-13
RAISE/LOWER OUT	28.3-3	SPEED SETPOINT	28.2-13
RAMP ACCEL RATE	5-4, 25-4, 28.2-15	SPEED TRIM	28.2-13
RAMP DECEL RATE	5-4, 25-4, 28.2-15	SRAMP ACCEL	28.2-16
RAMP HOLD	28.2-15	SRAMP CONTINUOUS	28.2-15
RAMP SYM MODE	28.2-15	SRAMP DECEL	28.2-16
RAMP SYM RATE	28.2-15	SRAMP JERK 1...4	28.2-16
RAMP TYPE	28.2-15	STABILISATION	28.4-8
RAMPING	28.2-16	STALL LIMIT	28.5-6
RANDOM PATTERN	28.4-14	STALL TIME	28.5-6
READY	28.2-4	STALL TRIP	28.5-6
REF MODES	28.2-10	START UP SCREEN	28.6-5
REFERENCE	28.2-13/14	STATOR RES	5-9, 25-9, 28.4-10
REGEN I LIMIT	28.4-7	STB ENABLE	28.4-8
REGEN LIM ENABLE	28.4-7	STOP	28.2-17
REM TRIP RESET	28.2-3	STOP DELAY	28.2-17
REMOTE COMMS SEL	28.7-2	STOP RATE	28.2-17
REMOTE REF	28.2-10	STOP ZERO SPEED	28.2-17
REMOTE REF MODES	28.7-2	STOPPING	28.2-4
REMOTE REV OUT	28.2-4	SUPPLY VOLTAGE	5-9, 25-9, 28.4-10
REMOTE REVERSE	28.2-3	SWITCH ON ENABLE	28.2-4
REMOTE REVERSE	28.2-13	SWITCHED ON	28.2-4
REMOTE SEQ	28.2-10	SYSTEM	5-15/16,
REMOTE SEQ MODES	28.7-2	SYSTEM PORT (P3)	28.7-5
REMOTE SETPOINT	6-5, 26-5, 28.2-13	SYSTEM RAMP	28.2-15/16
RESTORE DEFAULTS	5-15, 25-15	SYSTEM RESET	28.2-4
REVERSE	28.2-14	TAG NO	28.6-7/8
RL MAX VALUE	28.3-2	TEC OPTION	28.7-6
RL MIN VALUE	28.3-2	TEC OPTION FAULT	28.7-6
RL RAMP RATE	28.3-2	TEC OPTION IN 1/5	28.7-6
RL RESET	28.3-2	TEC OPTION OUT 1/2	28.7-6
RL RESET VALUE	28.3-2	TEC OPTION TYPE	28.7-6
RUN FWD	28.2-2	TEC OPTION VER	28.7-6
RUN REV	28.2-2	TRIM IN LOCAL	28.2-13
RUN STOP MODE	5-7, 25-7, 28.2-17	TRIP 1 (NEWEST)	6-12, 26-12, 28.5-6
RUNNING	28.2-3	TRIP 10 (OLDEST)	6-12, 26-12, 28.5-6
SAVE TO MEMORY	5-14, 25-14	TRIP 2...9	6-12, 26-12, 28.5-6
SAVE TO OP	5-14, 25-14	TRIP RST BY RUN	28.2-3
SCALE INPUT	28.4-2	TRIP WARNINGS	6-11, 26-11, 28.5-2
SCALE OUTPUT	28.4-2	TRIP WARNINGS+	6-11, 26-11, 28.5-2
SEQ & REF	28.2	TRIPPED	28.2-3
SEQ DIRECTION	28.2-10	TRIPS	28.5
SEQ MODES	28.2-10	TRIPS HISTORY	28.5-6
SEQUENCING LOGIC	28.2-2...7	TRIPS STATUS	6-11/12, 26-11/12, 28.5-2/3
SERIAL LINKS	28.7	TYPE	28.8-3/10
SETPOINT FUNCS	28.3	ULC ENABLE	28.4-13
SETPOINT SCALE	28.4-2	UNDERLAP COMP	28.4-13
SETPOINT (LOCAL)/	5-2, 25-2	UNIT ID (UID)	28.7-5
SETPOINT (REMOTE)/	5-2, 25-2	UNITS	28.6-7/8
SETUP PARAMETERS	5-4...10, 25-4...10	V/F SHAPE	5-5, 25-5, 28.4-8
SKIP FREQ BAND 1...4	28.3-7	VALUE FUNC 1...10	28.8-3
SKIP FREQ INPUT	28.3-7	VALUE FUNC 10	28.8-3
SKIP FREQ OUTPUT	28.3-7	VALUE FUNCTION	28.8-2...8
SKIP FREQUENCIES	28.3-7/8	VECTOR ENABLE	5-9, 25-9, 28.4-10
SKIP FREQUENCY 1...4	28.3-7	VECTOR SETUP	5-9...10, 28.4-10
SLEW ACCEL LIMIT	28.4-3	VIEW LEVEL	5-12, 25-12, 28.6-2
SLEW DECEL LIMIT	28.4-3	VOLTAGE CONTROL	28.4-12
SLEW ENABLE	28.4-3	VOLTAGE MODE	28.4-12
SLEW RATE LIMIT	28.4-3	VOLTS	28.4-14
SLIP ACTIVE	28.4-4	ZERO SPEED	28.2-19
SLIP COMP	28.4-4	ZERO SPEED BAND	28.2-19
SLIP ENABLE	28.4-4	ZERO SPEED IN	28.2-19
SLIP MOTOR LIMIT	28.4-4	ZERO SPEED LEVEL	28.2-19
SLIP REGEN LIMIT	28.4-4		



SoftCompact®
bisher/previous
LEKTROMIK® K

Elektronische Motor-Anlaufgeräte
und Steller in Modultechnik

Electronic soft starters
and phase control modules



SoftPower®
bisher/previous
LEKTROMIK® S

Elektronische Motor-Anlaufgeräte
bis 2000 kW, vollgesteuert

Electronic soft starters up to 2000 kW
fully controlled

STANDARD OPTIONEN

- I Pumpen-Anlaufoptimierung,
Leistungsüberwachung,
Strom- und $\cos \varphi$ -regelung
- N Drehzahlregelung

STANDARD-OPTIONS

- I Optimised start for pumps
Power monitoring, current
and $\cos \varphi$ control
- N Speed control



BrakeControl
bisher/previous
LEKTROMIK® B

Elektronische Bremsgeräte
bis 200 kW

Electronic braking controllers
up to 200 kW



MotorMaster®
MotorControl®
bisher/previous
TRANSOMIK®

Digitale Frequenzumrichter
0,37...1,5 kW, 1AC 230 V
0,37...315 kW, 3AC 400 V
Elektronische Frequenzumrichter
0,37...1,5 kW, 1AC 230 V
2,2...15 kW, 3AC 400 V

Digital frequency inverters
0.37...1.5 kW, 1AC 230 V
0.37...315 kW, 3AC 400 V
Electronic frequency inverters
0.37...1.5 kW, 1AC 230 V
2.2...15 kW, 3AC 400 V



BrakeMaster®
bisher/previous
TRANSOMIK® B, BC

Elektronische Bremschopper für
Frequenzumrichter bis 90 kW,
kaskadierbar für höhere Leistungen

Electronic braking choppers for
frequency inverters up to 90 kW,,
can be cascaded for higher powers



OEM Fertigung

Entwicklung und Fertigung kunden-
spezifischer Serien-Geräte der
Leistungselektronik

OEM MANUFACTURING

Development and volume
manufacturing of power electronic
equipment to customer specifications

**Ihr kompetenter Partner
für Antriebstechnik**

**Your competent partner for
electronic Power Drive Systems**

Diverse Vertretungen mit Branchen-
spezialisierung, wie: Klimatechnik,
Kältetechnik, Schaltschrankbau,
Maschinenbau

Kooperationspartner in Australien,
Kanada, Japan, Hong Kong, Korea

Various representatives specialised
in specific areas such as: Ventilation,
Refrigeration, Panel building, Motor
systems

Cooperation partners in Australia,
Canada, Japan, Hong Kong, Korea