

OVERVIEW ON SOFTWARE VERSIONS OF *FRIGOSOFT*

For *FrigoPack FEP*:

- FS 1.6: Basic refrigeration with up to 2 compressors
- FS 2.6: Standard refrigeration with up to 4 compressors
"Floating" control of condensing temperature
Also suitable for air cooling
- FS 3.6: Chillers for single and multiple circuits
"Floating" control of condensing temperature
Also suitable for cooling and dehumidification in ducted air systems
- FS 4.6 For use with external controllers with a 0 ... +10 V output

For *FrigoPackE FEP*:

- FS 1.6: Basic refrigeration with up to 2 compressors
- FS 4.6 For use with external controllers with a 0 ... +10 V output

For *FrigoPackE FMV*:

- FS E1: Basic refrigeration with up to 2 compressors
- FS E2: Basic refrigeration with up to 2 compressors, Isesco applications
- FS E2N: NEW from 1.4.2015: replaces FS E1 and FS E2**

For *FrigoPackEC FMV*:

- FS E4: For use with external controllers with a 0 ... +10 V output
- FS E4N: NEW from 1.6.2016: replaces FS E4**

For *CondensPack FMV*:

- FS EA: Speed control of refrigeration condenser fans

For all *FrigoPack FU+* (FPE FU+, FP FU+, FPEC FU+):

- FS X.7: Universal refrigeration software for all standard applications; automatic adaption by integrated module detection. Depending on the module installed, the following functionality is activated (analog to FP FEP):
 - FS 1.7 (Module BM1): Basic Pressure Control (max. 2 compressors, FPE FU+)
 - FS 2.7 (Module BM1, CM1, EM1): Advanced Control (Full version FP FU+)
 - FS 4.7 (No module): External Control with 0...10V signal (FPEC FU+)